

User Access Verification

Username: sujith

Password:

% Login invalid

Username: sujith

Password:

ROUTER>en

Password:

ROUTER#conf ter

Enter configuration commands, one per line. End with CNTL/Z.

ROUTER(config)#hostname Router1

Router1(config)#ip domain-name surennetworks.com

Router1(config)#ip ssh version 2

Please create RSA keys to enable SSH (and of atleast 768 bits for SSH v2).

Router1(config)#crypto key generate rsa modulus 2048

The name for the keys will be: Router1.surennetworks.com

% The key modulus size is 2048 bits

% Generating 2048 bit RSA keys, keys will be non-exportable...

[OK] (elapsed time was 2 seconds)

Router1(config)#

*Jul 17 07:54:31.468: %SSH-5-ENABLED: SSH 2.0 has been enabled

Router1(config)#username sujith privilege 15 password sujith

Router1(config)#line vty 0 4

Router1(config-line)#transport input ssh

^

% Invalid input detected at '^' marker.

Router1(config-line)#transport input ssh

Router1(config-line)#login local

Router1(config-line)#exit

Router1(config)#



Computer

Cisco IP
Communic...

Recycle Bin



Control Panel



PuTTY

PuTTY Configuration

Category:

- Session
 - Logging
- Terminal
 - Keyboard
 - Bell
 - Features
- Window
 - Appearance
 - Behaviour
 - Translation
 - Selection
 - Colours
- Connection
 - Data
 - Proxy
 - Telnet
 - Rlogin
 - SSH**
 - Serial

Basic options for your PuTTY session

Specify the destination you want to connect to

Host Name (or IP address) Port

Connection type:
☐ Raw ☐ Telnet ☐ Rlogin ☒ SSH ☐ Serial

Load, save or delete a stored session

Saved Sessions


Default Settings

Load Save Delete

Close window on exit:
☐ Always ☐ Never ☒ Only on clean exit

About Help Open Cancel

lftpd32





QEMU (Win)



50.0.0.1 - PuTTY



login as: sujith

Using keyboard-interactive authentication.

Password:

Router1#en

Router1#conf ter

Enter configuration commands, one per line. End with CNTL/Z.

Router1(config)#

I