



USER GUIDE

BH03



Bluetooth 5.4



Calling



Group Intercom

Thank you very much for purchasing the J-TREK BH03 Cycling Communication System.

To ensure safe and proper use, please be sure to read this instruction manual before use.

The illustrations and content of this manual may differ partially from the actual product due to specification changes, etc.

This instruction manual also serves as the warranty certificate, so please keep it in a safe place.


CONTENTS

Safety Precautions	01
Parts Names	02
Operation Summary Table	03
Package Contents	04
Installation	05
Charging	06
Power On	07
Group Intercom	08 ~ 09
Pairing with Smartphone	10
Making and Answering Calls	10
Activate Voice Assistant	11
Change Language	11
Troubleshooting	11
Warranty Period and Contact Information	12

SAFETY PRECAUTIONS

	 Warning
	Do not place the device in environments with excessive dust, high humidity, or high temperatures.
	Do not disassemble or modify this product.
	Do not drop or strike this product.
	Do not wipe this product with corrosive liquids.
	Note that the communication range is affected by the surrounding environment.
	To prevent electromagnetic interference or compatibility issues, turn off the power or stop using this product in locations marked with signs such as "Intercom Prohibited".
	Do not use this product near medical devices, etc.
	For safe driving, check and comply with the laws and regulations regarding intercom use in your area. When using this product while touring, adjust the volume to an appropriate level and pay full attention to driving and road conditions.

PARTS NAMES



① ▲ Button

② ▼ Button

③ Function Button / LED

④ USB-C Charging Port

OPERATION SUMMARY TABLE


▲ : ▲ button

▼ : ▼ button


☎ :Function button

Function	Button	Operation
Power on/off	▲ & ☎	Press for 3 seconds
Volume up/down	▲ or ▼	Single tap
Phone pairing	☎	Press for 3 seconds
Answer phone call	☎	Single tap
End phone call	☎	Single tap
Reject phone call	☎	Press for 2 seconds
Auto answer on/off	▲	Double tap
Activate voice assistant	▼	Double tap
Reset	☎ & ▼	Press for 3 seconds
Change Language	▲ & ▼	Press for 3 seconds

■ Package Contents



BH03 main unit



Strap mount x2



Microphone sponges x2




USB-C charging cable



User Guide


INSTALLATION



BASIC OPERATION

	Tap Tap the button the specified number of times
	Press and Hold Press and hold the button for the specified amount of time
	Voice Prompt
	LED


Charging




It takes 0.5~1 hours to fully charge.

- Any third-party USB charger can be used, as long as it is approved by the FCC, CE, IC, or other locally recognized regulatory agencies.
- Using a non-approved charger may cause fire, explosion, leakage, and other hazards, potentially reducing the battery's lifespan or performance.

Power On




Power Off




Mute/Unmute Mic

Use the swivel microphone arm to mute/unmute the microphone.




Mute: "Mic off"




Unmute: "Mic on"

Volume



or





GROUP INTERCOM

Pair BH03 units that have no prior pairing record


1. Power on all devices.

2. Put all devices into pairing mode.




🔊 "Pairing"

3. Perform the search operation on any one device.



🔊 "Searching"

4. Wait until the pairing is complete.





🔊 "Intercom Connected"

BH03 enters intercom mode with paired records


1.Power on all devices.

2.All devices will pair automatically.




🔊 "Intercom Connected"

3.Activate the intercom function on any one device.




4.Wait for all devices to enter intercom mode.




• While in intercom mode, double-click the power button to toggle to smartphone audio (e.g., navigation/music). Double-click again to instantly return to intercom call.

PAIRING WITH SMARTPHONE

1.




2.




Making and Answering Calls


■ Answer/End a Call




■ Reject a Call




■ Auto answer on/off



■ Activate Voice Assistant




■ Change Language



Troubleshooting

■ Fault Reset

- If the BH03 is on but unresponsive, you can perform a fault reset to restore functionality.
- Ensure the USB-C charging cable is disconnected, then press and hold Function Button and minus button simultaneously for 3 seconds to reset the device.



WARRANTY PERIOD AND CONTACT INFORMATION

The warranty period for this product is one year from the date of purchase.

*The specifications of this product are subject to change without notice. Please understand in advance.

•Production and sales of this product may cease due to discontinuation of electronic components used. Please understand in advance.

•When contacting us, to ensure a prompt and accurate response, please confirm the following items before contacting us:

① Product Name

② Order Number

③ Serial Number affixed to the unit

④ Fault condition (please describe in as much detail as possible. If contacting by email, please include details regarding the malfunction symptoms.)

•For any questions or concerns regarding malfunctions, please contact the retailer where you purchased the product or the dedicated after-sales service email address below.

After-Sales Service Email Address



support@j-trek.com

Reception Hours: 10:00-12:00, 14:00-18:30

(Excludes Saturdays, Sundays, national holidays, year-end/new year holidays, and company-designated holidays)

