Table of Contents

Chapter	1
---------	---

Aircraft Engines	
General Requirements	1-
Power & Weight	1-2
Fuel Economy	1-2
Durability & Reliability	1-2
Operating Flexibility	1-3
Compactness	1-3
Powerplant Selection	1-3
Types of Engines	1-;
Inline Engines	1-3
Opposed or O-Type Engines	1-4
V-Type Engines	1-4
Radial Engines	1-4
Reciprocating Engines	1-
Design & Construction	1-5
Crankcase Section	1-5
Accessory Section	1-7
Accessory Gear Trains	1-7
Crankshafts	1-7
Crankshaft Balance	1-6
Dynamic Dampers	1-8
Connecting Rods	1-9
Master-and-Articulated Rod Assembly	1-9
Knuckle Pins	1-10
Plain-Type Connecting Rods	1-1
Fork-and-Blade Rod Assembly	1-1
Pistons	1-1
Piston Construction	1-12
Piston Pin	1-13
Piston Rings	1-1;
Piston Ring Construction	1-13
Compression Ring	
Oil Control Rings	1-13
Oil Scraper Ring	1-13
Cylinders	
Cylinder Heads	
Cylinder Barrels	1-15
Cylinder Numbering	
Firing Order	
Single-Row Radial Engines	
Double-Row Radial Engines	
Valves	
Valve Construction	
Valve Operating Mechanism	
Cam Rings	1-18

Camshaft	1-20
Tappet Assembly	1-20
Solid Lifters/Tappets	1-20
Hydraulic Valve Tappets/Lifters	1-20
Push Rod	1-21
Rocker Arms	1-21
Valve Springs	1-21
Bearings	1-22
Plain Bearings	1-22
Ball Bearings	1-22
Roller Bearings	1-22
Propeller Reduction Gearing	1-23
Propeller Shafts	1-23
Reciprocating Engine Operating Principles	1-25
Operating Cycles	
Four-Stroke Cycle	
Intake Stroke	
Compression Stroke	
Power Stroke	
Exhaust Stroke	
Two-Stroke Cycle	
Rotary Cycle	
Diesel Cycle	
Reciprocating Engine Power & Efficiencies	
Work	
Horsepower	
Piston Displacement	
Area of a Circle	
Compression Ratio	
Indicated Horsepower	
Brake Horsepower	
Friction Horsepower	
Friction & Brake Mean Effective Pressures	
Thrust Horsepower	1-33
Efficiencies	1-33
Thermal Efficiency	1-33
Mechanical Efficiency	1-35
Volumetric Efficiency	1-35
Propulsive Efficiency	1-36
Gas Turbine Engines	1-36
Types & Construction	1-36
Air Entrance	1-37
Accessory Section	1-38
Compressor Section	
Compressor Types	
Centrifugal-Flow Compressors	
Axial-Flow Compressor	
•	
Diffuser	
Combustion Section	
Turbine Section	
Exhaust Section	1-51

Gas Turbine Engine Bearings & Seals	1-52
Turboprop Engines	1-54
Turboshaft Engines	1-55
Turbofan Engines	
Turbine Engine Operating Principles	
Thrust	
Gas Turbine Engine Performance	1-59
Ram Recovery	1-60
Chapter 2	
Engine Fuel & Fuel Metering Systems	
Fuel System Requirements	
Vapor Lock	
Basic Fuel System	
Fuel Metering Devices for Reciprocating Engines	
Air-Fuel Mixtures	
Carburetion Principles	
Venturi Principles	
Application of Venturi Principle to Carburetor	
Metering & Discharge of Fuel	
Carburetor Systems	
Carburetor Types	
Carburetor Icing	
Float-Type Carburetors	
Float Chamber Mechanism System	
Main Metering System	
Idling System	
Mixture Control System	
Accelerating System	
Economizer System	
Pressure Injection Carburetors	
Typical Injection Carburetor	
Throttle Body	
Regulator Unit	
Fuel Control Unit	
Automatic Mixture Control (AMC)	
Stromberg PS Carburetor	
Accelerating Pump	
Manual Mixture Control	
Fuel-Injection Systems	
Bendix/Precision Fuel-Injection System	
Fuel Injector	
Airflow Section	
Regulator Section	
Fuel Metering Section	
Flow Divider	
Fuel Discharge Nozzles	
Continental/TCM Fuel-Injection System	
Fuel-Injection Pump	
Air-Fuel Control Unit	
Fuel Control Assembly	2-26

Fuel Manifold Valve	2-26
Fuel Discharge Nozzle	2-27
Carburetor Maintenance	2-27
Carburetor Removal	2-27
Installation of Carburetor	2-29
Rigging Carburetor Controls	2-29
Adjusting Idle Mixtures	2-29
Idle Speed Adjustment	2-30
Fuel System Inspection & Maintenance	2-31
Complete System	2-31
Fuel Tanks	2-32
Lines & Fittings	2-32
Selector Valves	
Pumps	2-32
Main Line Strainers	2-32
Fuel Quantity Gauges	
Fuel Pressure Gauge	
Pressure Warning Signal	
Water Injection Systems for Reciprocating Engines	
Turbine Engine Fuel System—General Requirements	
Turbine Fuel Controls	
Hydromechanical Fuel Control	
Hydromechanical/Electronic Fuel Control	
FADEC Fuel Control Systems	
FADEC for an Auxiliary Power Unit	
FADEC Fuel Control Propulsion Engine	
Fuel System Operation	
Water Injection System	
Fuel Control Maintenance	
Engine Fuel System Components	
Main Fuel Pumps (Engine Driven)	
Fuel Heater	
Fuel Filters	
Fuel Spray Nozzles & Fuel Manifolds	
Simplex Fuel Nozzle	
Duplex Fuel Nozzle	
Airblast Nozzles	
Flow Divider	
Fuel Pressurizing & Dump Valves	
Combustion Drain Valves	
Fuel Quantity Indicating Units	
ruei Quantity indicating Office	2-40
Chapter 3	
nduction & Exhaust Systems	
Reciprocating Engine Induction Systems	3-1
Basic Carburetor Induction System	
Induction System Icing	
Induction System Filtering	
Induction System Inspection & Maintenance	
Extinguishing Engine Fires	
Induction System Troubleshooting	
maaciion system maabicshooting	

Supercharged Induction Systems	3-5
Internally Driven Superchargers	3-6
Turbosuperchargers	3-7
Normalizer Turbocharger	3-9
Ground-Boosted Turbosupercharger System	3-9
A Typical Turbosupercharger System	
Turbocharger Controllers & System Descriptions	
Variable Absolute Pressure Controller (VAPC)	
Sloped Controller	
Absolute Pressure Controller	
Turbocharger System Troubleshooting	
Turbine Engine Inlet Systems	
Divided-Entrance Duct	
Variable-Geometry Duct	
Compressor Inlet Screens	
Bellmouth Compressor Inlets	
Turbofon Engine Inlet Sections	
Turbofan Engine Inlet Sections	
Reciprocating Engine Exhaust Systems	
Radial Engine Exhaust Collector Ring System Manifold & Augmentor Exhaust Assembly	
Reciprocating Engine Exhaust System Maintenance Practices	
Exhaust System Inspection	
Muffler & Heat Exchanger Failures	
Exhaust Manifold & Stack Failures	
Internal Muffler Failures	
Exhaust Systems with Turbocharger	
Augmentor Exhaust System	
Exhaust System Repairs	
Turbine Engine Exhaust Nozzles	
Convergent Exhaust Nozzle	
Convergent-Divergent Exhaust Nozzle	
Thrust Reversers	
Afterburning/Thrust Augmentation	
Thrust Vectoring	
Engine Noise Suppression	
Turbine Engine Emissions	
Chapter 4	
Engine Ignition & Electrical Systems	
Reciprocating Engine Ignition Systems	
Magneto-Ignition System Operating Principles	
High-Tension Magneto System Theory of Operation	
Magnetic Circuit	
Primary Electrical Circuit	
Secondary Electrical Circuit	
Magneto & Distributor Venting	
Ignition Harness	
Ignition Switches	
Single & Dual High-Tension System Magnetos	4-10

Magneto Mounting Systems	4-10
High- & Low-Tension Magneto Systems	4-11
Types of DC Generators	4-12
Series Wound DC Generators	4-12
Parallel (Shunt) Wound DC Generators	4-12
Compound Wound DC Generators	
Generator Ratings	4-13
DC Generator Maintenance	
FADEC System Description	
Low-Voltage Harness	
Electronic Control Unit (ECU)	
PowerLink Ignition System	
Engine Indicating & Crew Alerting System (EICAS)	
Auxiliary Ignition Units	
Booster Coil	
Impulse Coupling	4-19
High-Tension Retard Breaker Vibrator	
Low-Tension Retard Breaker Vibrator	
Spark Plugs	
Reciprocating Engine Ignition System Maintenance & Inspection	4-26
Magneto-Ignition Timing Devices	
Built-In Engine Timing Reference Marks	
Timing Discs	
Piston Position Indicators	4-27
Timing Lights	4-28
Checking the Internal Timing of a Magneto	4-29
High-Tension Magneto E-Gap Setting (Bench Timing)	4-29
Timing the High-tension Magneto to the Engine	4-30
Performing Ignition System Checks	4-31
Ignition Switch Check	4-31
Maintenance & Inspection of Ignition Leads	4-31
Replacement of Ignition Harness	4-33
Checking Ignition Induction Vibrator Systems	4-33
Spark Plug Inspection & Maintenance	4-33
Carbon Fouling of Spark Plugs	4-33
Oil Fouling of Spark Plugs	4-34
Lead Fouling of Spark Plugs	4-34
Graphite Fouling of Spark Plugs	4-35
Gap Erosion of Spark Plugs	4-35
Spark Plug Removal	4-35
Spark Plug Reconditioning Service	4-36
Inspection Prior to Installation	4-37
Spark Plug Installation	4-38
Spark Plug Lead Installation	4-38
Breaker Point Inspection	4-39
Dielectric Inspection	4-41
Ignition Harness Maintenance	4-41
High-Tension Ignition Harness Faults	4-41
Harness Testing	
Turbine Engine Ignition Systems	4-43
Capacitor Discharge Exciter Unit	4-44

Igniter Plugs	4-45
Turbine Ignition System Inspection & Maintenance	4-45
Inspection	4-45
Check System Operation	4-46
Repair	
Removal, Maintenance, & Installation of Ignition System Components	4-46
Ignition System Leads	
Igniter Plugs	
Powerplant Electrical Systems	
Wire Size	
Factors Affecting the Selection of Wire Size	
Factors Affecting Selection of Conductor Material	
Voltage Drop in Aircraft Wire & Cable	
Conductor Insulation	
Identifying Wire & Cable	
Electrical Wiring Installation	
Wire Groups & Bundles	
Twisting Wires	
Spliced Connections in Wire Bundles	
Slack in Wiring Bundles	
Bend Radii	
Routing & Installation	
Protection Against Chafing	
Protection Against High Temperature	
Protection Against Solvents & Fluids	
Protection of Wires in Wheel Well Area	
Routing Precautions	
Installation of Cable Clamps	
Lacing & Tying Wire Bundles	
Single-Cord Lacing	
Double-Cord Lacing	
Lacing Branch-Offs	
Tying	
Cutting Wire & Cable	
Stripping Wire & Cable	4-61
Solderless Terminals & Splices	
Copper Wire Terminals	
Crimping Tools	
Aluminum Wire Terminals	
Splicing Copper Wires Using Preinsulated Wires	
Emergency Splicing Repairs	
Splicing with Solder & Potting Compound	
Connecting Terminal Lugs to Terminal Blocks	
Bonding & Grounding	
General Bonding & Grounding Procedures	
Connectors	
Types of Connectors	
Connector Identification	
Installation of Connectors	
Conduit	
Electrical Equipment Installation	
LIGOLITORI LYUIPITIOTIL ITTOLAIIALIUTT	

Electrical Load Limits	_
Controlling or Monitoring the Electrical Load	4-70
Circuit Protection Devices	4-70
Switches	4-71
Relays	4-71
Chapter 5	
Engine Starting Systems	
Introduction	5-1
Reciprocating Engine Starting Systems	
Inertia Starters	
Direct Cranking Electric Starter	
Direct Cranking Electric Starting System for Large Reciprocating Engines	
Direct Cranking Electric Starting System for Small Aircraft	
Reciprocating Engine Starting System Maintenance Practices	
Troubleshooting Small Aircraft Starting Systems	
Gas Turbine Engine Starters	
Electric Starting Systems & Starter Generator Starting System	
Troubleshooting a Starter Generator Starting System	
Air Turbine Starters	
Air Turbline Starters	
All Turbline Starter Troubleshooting Guide	5-10
Chapter 6	
Lubrication & Cooling Systems	
Principles of Engine Lubrication	6.1
Types of Friction	
Functions of Engine Oil	
Requirements & Characteristics of Reciprocating Engine Lubricants	
· · · · · · · · · · · · · · · · · · ·	
Viscosity	
Viscosity Index	
Flash Point & Fire Point	
Cloud Point & Pour Point	
Specific Gravity	
Reciprocating Engine Lubrication Systems	
Combination Splash & Pressure Lubrication	
Lubrication System Requirements	
Dry Sump Oil Systems	
Oil Tanks	
Oil Pump	
Oil Filters	6-7
Oil Pressure Regulating Valve	6-7
Oil Pressure Gauge	6-8
Oil Temperature Indicator	6-9
Oil Cooler	6-9
Oil Cooler Flow Control Valve	6-9
Surge Protection Valves	6-10
Airflow Controls	
Dry Sump Lubrication System Operation	
Wet-Sump Lubrication System Operation	
Lubrication System Maintenance Practices	
Oil Tank	

Oil Cooler	6-14
Oil Temperature Bulbs	6-15
Pressure & Scavenge Oil Screens	6-15
Oil Pressure Relief Valve	6-16
Recommendations for Changing Oil	6-17
Draining Oil	6-17
Oil & Filter Change & Screen Cleaning	6-17
Oil Filter Removal Canister Type Housing	6-17
Oil Filter/Screen Content Inspection	
Assembly of & Installation of Oil Filters	6-18
Troubleshooting Oil Systems	
Requirements for Turbine Engine Lubricants	
Turbine Oil Health & Safety Precautions	6-19
Spectrometric Oil Analysis Program	6-20
Typical Wear Metals & Additives	6-20
Turbine Engine Lubrication Systems	6-20
Turbine Lubrication System Components	6-21
Oil Tank	
Oil Pump	
Turbine Oil Filters	
Oil Pressure Regulating Valve	
Oil Pressure Relief Valve	
Oil Jets	
Lubrication System Instrumentation	
Lubrication System Breather Systems (Vents)	
Lubrication System Check Valve	
Lubrication System Thermostatic Bypass Valves	
Air-Oil Coolers	
Fuel-Oil Coolers	
Deoiler	
Magnetic Chip Detectors	
Typical Dry-Sump Pressure Regulated Turbine Lubrication System	
Pressure System	
Scavenge System	
Breather Pressurizing System	
Typical Dry-Sump Variable Pressure Lubrication System	
Pressure Subsystem	
Scavenger Subsystem	
Breather Subsystem	
Turbine Engine Wet-Sump Lubrication System	
Turbine Engine Oil System Maintenance	
Engine Cooling Systems	
Reciprocating Engine Cooling Systems	
Reciprocating Engine Cooling System Maintenance	
Maintenance of Engine Cowling	
Engine Cylinder Cooling Fin Inspection	
Cylinder Baffle & Deflector System Inspection	
Cylinder Temperature Indicating Systems	
Exhaust Gas Temperature Indicating Systems	
Turbine Engine Cooling	
Accessory Zone Cooling	6-38

Turbine Engine Insulation Blankets	6-40
Chapter 7	
Propellers	
General	7_1
Basic Propeller Principles	
Propeller Aerodynamic Process	
Aerodynamic Factors	
Propeller Controls & Instruments	
Propeller Location	
Tractor Propeller	
Pusher Propellers	
Types of Propellers	
Fixed-Pitch Propeller	
Test Club Propeller	
Ground-Adjustable Propeller	
Controllable-Pitch Propeller	
Constant-Speed Propellers	
Feathering Propellers	
Reverse-Pitch Propellers	
Propeller Governor	
Governor Mechanism	
Underspeed Condition	
Overspeed Condition	
On-Speed Condition	
Governor System Operation	
Propellers Used on General Aviation Aircraft	
Fixed-Pitch Wooden Propellers	
Metal Fixed-Pitch Propellers	
Constant-Speed Propellers	
Hartzell Constant-Speed, Nonfeathering	
Constant-Speed Feathering Propeller	
Unfeathering	
Propeller Auxiliary Systems	
Ice Control Systems	
Anti-Icing Systems	
~ ·	
Deicing Systems	
Propeller Synchronization & Synchrophasing	
Autofeathering System	
Propeller Inspection & Maintenance	
Wood Propeller Inspection	
Metal Propeller Inspection	
Aluminum Propeller Inspection	
Composite Propeller Inspection	
Propeller Vibration	
Blade Tracking	
Checking & Adjusting Propeller Blade Angles	
Universal Propeller Protractor	
Propeller Balancing	
Static Balancing	
Dynamic Balancing	7-25

Balancing Procedure	7-25
Propeller Removal & Installation	7-26
Removal	7-26
Installation	7-27
Servicing Propellers	7-27
Cleaning Propeller Blades	7-27
Charging the Propeller Air Dome	7-27
Propeller Lubrication	7-27
Propeller Overhaul	7-29
The Hub	7-29
Prop Reassembly	7-29
Troubleshooting Propellers	7-30
Hunting & Surging	7-30
Engine Speed Varies with Flight Attitude (Airspeed)	7-30
Failure to Feather or Feathers Slowly	7-30
Turboprop Engines & Propeller Control Systems	7-30
Reduction Gear Assembly	7-31
Turbo-Propeller Assembly	7-31
Pratt & Whitney PT6 Hartzell Propeller System	7-31
Hamilton Standard Hydromatic Propellers	7-34
Principles of Operation	7-36
Feathering Operation	7-37
Unfeathering Operation	7-38
Setting the Propeller Governor	7-40
Engine Removal & Replacement	
Introduction	
IntroductionReasons for Removal of Reciprocating Engines	8-1
Introduction	8-1 8-1
Introduction	8-1 8-1 8-1
Introduction	8-1 8-1 8-1 8-1
Introduction Reasons for Removal of Reciprocating Engines Engine or Component Lifespan Exceeded Engine Sudden Stoppage or Propeller Strike Sudden Reduction in Speed Metal Particles in the Oil	
Introduction Reasons for Removal of Reciprocating Engines Engine or Component Lifespan Exceeded Engine Sudden Stoppage or Propeller Strike Sudden Reduction in Speed Metal Particles in the Oil Spectrometric Oil Analysis Engine Inspection Program	
Introduction Reasons for Removal of Reciprocating Engines Engine or Component Lifespan Exceeded Engine Sudden Stoppage or Propeller Strike Sudden Reduction in Speed Metal Particles in the Oil Spectrometric Oil Analysis Engine Inspection Program Turbine Engine Condition Monitoring Programs	
Introduction Reasons for Removal of Reciprocating Engines Engine or Component Lifespan Exceeded Engine Sudden Stoppage or Propeller Strike Sudden Reduction in Speed Metal Particles in the Oil Spectrometric Oil Analysis Engine Inspection Program Turbine Engine Condition Monitoring Programs Engine Operational Problems	8-1 8-1 8-1 8-1 8-1 8-2 8-2 8-2
Introduction Reasons for Removal of Reciprocating Engines Engine or Component Lifespan Exceeded Engine Sudden Stoppage or Propeller Strike Sudden Reduction in Speed Metal Particles in the Oil Spectrometric Oil Analysis Engine Inspection Program Turbine Engine Condition Monitoring Programs Engine Operational Problems General Procedures for Engine Removal & Installation	
Introduction Reasons for Removal of Reciprocating Engines Engine or Component Lifespan Exceeded Engine Sudden Stoppage or Propeller Strike Sudden Reduction in Speed Metal Particles in the Oil Spectrometric Oil Analysis Engine Inspection Program Turbine Engine Condition Monitoring Programs Engine Operational Problems General Procedures for Engine Removal & Installation Preparation of Engines for Installation	
Introduction Reasons for Removal of Reciprocating Engines Engine or Component Lifespan Exceeded Engine Sudden Stoppage or Propeller Strike Sudden Reduction in Speed Metal Particles in the Oil Spectrometric Oil Analysis Engine Inspection Program Turbine Engine Condition Monitoring Programs Engine Operational Problems General Procedures for Engine Removal & Installation Preparation of Engines for Installation QECA Buildup Method for Changing of Engines	8-1 8-1 8-1 8-1 8-2 8-2 8-2 8-3 8-3 8-3
Introduction Reasons for Removal of Reciprocating Engines Engine or Component Lifespan Exceeded Engine Sudden Stoppage or Propeller Strike Sudden Reduction in Speed Metal Particles in the Oil Spectrometric Oil Analysis Engine Inspection Program Turbine Engine Condition Monitoring Programs Engine Operational Problems General Procedures for Engine Removal & Installation Preparation of Engines for Installation QECA Buildup Method for Changing of Engines Depreservation of an Engine	8-1 8-1 8-1 8-1 8-2 8-2 8-2 8-2 8-3 8-3 8-3
Introduction Reasons for Removal of Reciprocating Engines Engine or Component Lifespan Exceeded Engine Sudden Stoppage or Propeller Strike Sudden Reduction in Speed Metal Particles in the Oil Spectrometric Oil Analysis Engine Inspection Program Turbine Engine Condition Monitoring Programs Engine Operational Problems General Procedures for Engine Removal & Installation Preparation of Engines for Installation QECA Buildup Method for Changing of Engines Depreservation of an Engine Inspection & Depreservation of Accessories	8-1 8-1 8-1 8-1 8-2 8-2 8-2 8-3 8-3 8-3 8-3 8-4
Introduction Reasons for Removal of Reciprocating Engines Engine or Component Lifespan Exceeded Engine Sudden Stoppage or Propeller Strike Sudden Reduction in Speed Metal Particles in the Oil Spectrometric Oil Analysis Engine Inspection Program. Turbine Engine Condition Monitoring Programs Engine Operational Problems General Procedures for Engine Removal & Installation Preparation of Engines for Installation QECA Buildup Method for Changing of Engines Depreservation of an Engine Inspection & Depreservation of Accessories Inspection & Replacement of Powerplant External Units & Systems	8-1 8-1 8-1 8-1 8-2 8-2 8-2 8-3 8-3 8-3 8-3 8-3 8-4 8-5
Introduction Reasons for Removal of Reciprocating Engines Engine or Component Lifespan Exceeded Engine Sudden Stoppage or Propeller Strike Sudden Reduction in Speed Metal Particles in the Oil Spectrometric Oil Analysis Engine Inspection Program Turbine Engine Condition Monitoring Programs Engine Operational Problems General Procedures for Engine Removal & Installation Preparation of Engines for Installation QECA Buildup Method for Changing of Engines Depreservation of an Engine Inspection & Depreservation of Accessories Inspection & Replacement of Powerplant External Units & Systems Preparing the Engine for Removal	8-1 8-1 8-1 8-1 8-2 8-2 8-2 8-3 8-3 8-3 8-3 8-4 8-5 8-5
Introduction Reasons for Removal of Reciprocating Engines Engine or Component Lifespan Exceeded Engine Sudden Stoppage or Propeller Strike Sudden Reduction in Speed Metal Particles in the Oil Spectrometric Oil Analysis Engine Inspection Program Turbine Engine Condition Monitoring Programs Engine Operational Problems General Procedures for Engine Removal & Installation Preparation of Engines for Installation QECA Buildup Method for Changing of Engines Depreservation of an Engine Inspection & Depreservation of Accessories Inspection & Replacement of Powerplant External Units & Systems Preparing the Engine for Removal Draining the Engine	8-1 8-1 8-1 8-1 8-2 8-2 8-2 8-2 8-3 8-3 8-3 8-3 8-4 8-5 8-6
Introduction Reasons for Removal of Reciprocating Engines Engine or Component Lifespan Exceeded Engine Sudden Stoppage or Propeller Strike Sudden Reduction in Speed Metal Particles in the Oil Spectrometric Oil Analysis Engine Inspection Program. Turbine Engine Condition Monitoring Programs Engine Operational Problems General Procedures for Engine Removal & Installation Preparation of Engines for Installation QECA Buildup Method for Changing of Engines Depreservation of an Engine Inspection & Depreservation of Accessories Inspection & Replacement of Powerplant External Units & Systems Preparing the Engine for Removal Draining the Engine Electrical Disconnects	8-1 8-1 8-1 8-1 8-2 8-2 8-2 8-2 8-3 8-3 8-3 8-3 8-4 8-5 8-6
Introduction Reasons for Removal of Reciprocating Engines. Engine or Component Lifespan Exceeded Engine Sudden Stoppage or Propeller Strike Sudden Reduction in Speed Metal Particles in the Oil Spectrometric Oil Analysis Engine Inspection Program Turbine Engine Condition Monitoring Programs Engine Operational Problems General Procedures for Engine Removal & Installation Preparation of Engines for Installation QECA Buildup Method for Changing of Engines Depreservation of an Engine Inspection & Depreservation of Accessories Inspection & Replacement of Powerplant External Units & Systems Preparing the Engine Draining the Engine Electrical Disconnects Disconnection of Engine Controls	8-1 8-1 8-1 8-1 8-2 8-2 8-2 8-2 8-3 8-3 8-3 8-3 8-4 8-5 8-5 8-6
Introduction Reasons for Removal of Reciprocating Engines Engine or Component Lifespan Exceeded Engine Sudden Stoppage or Propeller Strike Sudden Reduction in Speed Metal Particles in the Oil Spectrometric Oil Analysis Engine Inspection Program Turbine Engine Condition Monitoring Programs Engine Operational Problems General Procedures for Engine Removal & Installation Preparation of Engines for Installation QECA Buildup Method for Changing of Engines Depreservation of an Engine Inspection & Replacement of Powerplant External Units & Systems Preparing the Engine for Removal Draining the Engine Electrical Disconnects Disconnection of Engine Controls Disconnection of Lines	8-1 8-1 8-1 8-1 8-2 8-2 8-2 8-3 8-3 8-3 8-3 8-4 8-5 8-5 8-6
Introduction Reasons for Removal of Reciprocating Engines Engine or Component Lifespan Exceeded Engine Sudden Stoppage or Propeller Strike Sudden Reduction in Speed Metal Particles in the Oil Spectrometric Oil Analysis Engine Inspection Program. Turbine Engine Condition Monitoring Programs Engine Operational Problems General Procedures for Engine Removal & Installation Preparation of Engines for Installation QECA Buildup Method for Changing of Engines Depreservation of an Engine Inspection & Depreservation of Accessories Inspection & Replacement of Powerplant External Units & Systems Preparing the Engine Electrical Disconnects Disconnection of Engine Controls Disconnection of Lines Other Disconnections	8-1 8-1 8-1 8-1 8-2 8-2 8-2 8-2 8-3 8-3 8-3 8-4 8-5 8-5 8-6 8-6 8-6 8-6 8-7 8-8
Introduction Reasons for Removal of Reciprocating Engines Engine or Component Lifespan Exceeded Engine Sudden Stoppage or Propeller Strike Sudden Reduction in Speed Metal Particles in the Oil Spectrometric Oil Analysis Engine Inspection Program. Turbine Engine Condition Monitoring Programs Engine Operational Problems General Procedures for Engine Removal & Installation Preparation of Engines for Installation QECA Buildup Method for Changing of Engines Depreservation of an Engine Inspection & Depreservation of Accessories Inspection & Replacement of Powerplant External Units & Systems Preparing the Engine Electrical Disconnects Disconnection of Engine Controls Disconnection of Lines Other Disconnections Removing the Engine	8-1 8-1 8-1 8-1 8-2 8-2 8-2 8-2 8-3 8-3 8-3 8-3 8-4 8-5 8-6 8-6 8-6 8-6 8-7 8-8 8-8
Introduction Reasons for Removal of Reciprocating Engines Engine or Component Lifespan Exceeded Engine Sudden Stoppage or Propeller Strike Sudden Reduction in Speed Metal Particles in the Oil Spectrometric Oil Analysis Engine Inspection Program. Turbine Engine Condition Monitoring Programs Engine Operational Problems General Procedures for Engine Removal & Installation Preparation of Engines for Installation QECA Buildup Method for Changing of Engines Depreservation of an Engine Inspection & Depreservation of Accessories Inspection & Replacement of Powerplant External Units & Systems Preparing the Engine Electrical Disconnects Disconnection of Engine Controls Disconnection of Lines Other Disconnections	8-1 8-1 8-1 8-1 8-2 8-2 8-2 8-2 8-3 8-3 8-3 8-3 8-4 8-5 8-5 8-6 8-6 8-6 8-6 8-7 8-8 8-8

Connections & Adjustments	8-10
Preparation of Engine for Ground & Flight Testing	8-12
Pre-Oiling	8-12
Fuel System Bleeding	8-13
Propeller Check	8-13
Checks & Adjustments After Engine Runup & Operation	8-13
Rigging, Inspections, & Adjustments	
Rigging Power Controls	
Adjusting the Fuel Control	
Turboprop Powerplant Removal & Installation	
Reciprocating Helicopter Engine & QECA	
Removal of Helicopter QECA	
Installation, Rigging, & Adjustment of Helicopter QECA	
Testing the Engine Installation	
Engine Mounts	
Mounts for Reciprocating Engines	
Mounts for Turbofan Engines Turbine Vibration Isolation Engine Mounts	
Preservation & Storage of Engines	
Corrosion-Preventive Materials	
Corrosion-Preventive Materials	
Dehydrating Agents	
Engine Preservation & Return to Service	
Engine Shipping Containers	
Inspection of Stored Engines	
Preservation & Depreservation of Gas Turbine Engines	
Chapter 9	
Chapter 9 Engine Fire Protection Systems	
Chapter 9 Engine Fire Protection Systems Introduction	9-1
Chapter 9 Engine Fire Protection Systems Introduction	9-1 9-1
Chapter 9 Engine Fire Protection Systems Introduction Components Engine Fire Detection Systems	9-1 9-1 9-2
Chapter 9 Engine Fire Protection Systems Introduction Components Engine Fire Detection Systems Thermal Switch System	9-1 9-1 9-2 9-2
Chapter 9 Engine Fire Protection Systems Introduction Components Engine Fire Detection Systems Thermal Switch System Thermocouple Systems	9-1 9-1 9-2 9-2
Chapter 9 Engine Fire Protection Systems Introduction Components Engine Fire Detection Systems Thermal Switch System Thermocouple Systems Optical Fire Detection Systems	
Chapter 9 Engine Fire Protection Systems Introduction Components Engine Fire Detection Systems Thermal Switch System Thermocouple Systems Optical Fire Detection Systems Pneumatic Thermal Fire Detection	
Chapter 9 Engine Fire Protection Systems Introduction Components Engine Fire Detection Systems Thermal Switch System Thermocouple Systems Optical Fire Detection Systems Pneumatic Thermal Fire Detection Continuous-Loop Detector Systems	9-1 9-1 9-2 9-2 9-2 9-3 9-3 9-3
Chapter 9 Engine Fire Protection Systems Introduction Components Engine Fire Detection Systems Thermal Switch System Thermocouple Systems Optical Fire Detection Systems Pneumatic Thermal Fire Detection Continuous-Loop Detector Systems Fire Zones	9-1 9-2 9-2 9-2 9-3 9-3 9-3
Chapter 9 Engine Fire Protection Systems Introduction Components Engine Fire Detection Systems Thermal Switch System Thermocouple Systems Optical Fire Detection Systems Pneumatic Thermal Fire Detection Continuous-Loop Detector Systems Fire Zones Engine Fire Extinguishing System	9-1 9-2 9-2 9-2 9-3 9-3 9-3 9-3 9-7
Chapter 9 Engine Fire Protection Systems Introduction Components Engine Fire Detection Systems Thermal Switch System Thermocouple Systems Optical Fire Detection Systems Pneumatic Thermal Fire Detection Continuous-Loop Detector Systems Fire Zones Engine Fire Extinguishing System Fire Extinguishing Agents	9-1 9-2 9-2 9-2 9-3 9-3 9-3 9-7
Chapter 9 Engine Fire Protection Systems Introduction Components Engine Fire Detection Systems Thermal Switch System Thermocouple Systems Optical Fire Detection Systems Pneumatic Thermal Fire Detection Continuous-Loop Detector Systems Fire Zones Engine Fire Extinguishing System Fire Extinguishing Agents Turbine Engine Ground Fire Protection	9-1 9-1 9-2 9-2 9-2 9-3 9-3 9-3 9-3 9-7 9-7
Chapter 9 Engine Fire Protection Systems Introduction Components Engine Fire Detection Systems Thermal Switch System Thermocouple Systems Optical Fire Detection Systems. Pneumatic Thermal Fire Detection Continuous-Loop Detector Systems Fire Zones Engine Fire Extinguishing System Fire Extinguishing Agents Turbine Engine Ground Fire Protection Containers	9-1 9-2 9-2 9-2 9-3 9-3 9-3 9-7 9-7 9-7
Chapter 9 Engine Fire Protection Systems Introduction Components Engine Fire Detection Systems Thermal Switch System Thermocouple Systems Optical Fire Detection Systems Pneumatic Thermal Fire Detection Continuous-Loop Detector Systems Fire Zones Engine Fire Extinguishing System Fire Extinguishing System Turbine Engine Ground Fire Protection Containers Discharge Valves	9-1 9-2 9-2 9-2 9-3 9-3 9-3 9-7 9-7 9-7 9-8
Chapter 9 Engine Fire Protection Systems Introduction Components Engine Fire Detection Systems Thermal Switch System Thermocouple Systems Optical Fire Detection Systems Pneumatic Thermal Fire Detection Continuous-Loop Detector Systems Fire Zones Engine Fire Extinguishing System Fire Extinguishing Agents Turbine Engine Ground Fire Protection Containers Discharge Valves Pressure Indication	9-1 9-2 9-2 9-2 9-3 9-3 9-3 9-7 9-7 9-8 9-8
Chapter 9 Engine Fire Protection Systems Introduction Components Engine Fire Detection Systems Thermal Switch System Thermocouple Systems Optical Fire Detection Systems Pneumatic Thermal Fire Detection Continuous-Loop Detector Systems Fire Zones Engine Fire Extinguishing System Fire Extinguishing Agents Turbine Engine Ground Fire Protection Containers Discharge Valves Pressure Indication Two-Way Check Valve	9-1 9-2 9-2 9-2 9-3 9-3 9-3 9-3 9-7 9-7 9-7 9-8
Chapter 9 Engine Fire Protection Systems Introduction Components Engine Fire Detection Systems Thermal Switch System Thermocouple Systems Optical Fire Detection Systems. Pneumatic Thermal Fire Detection Continuous-Loop Detector Systems Fire Zones Engine Fire Extinguishing System Fire Extinguishing Agents Turbine Engine Ground Fire Protection Containers Discharge Valves Pressure Indication Two-Way Check Valve Discharge Indicators	9-1 9-1 9-2 9-2 9-2 9-3 9-3 9-3 9-3 9-7 9-7 9-7 9-8 9-8 9-8
Chapter 9 Engine Fire Protection Systems Introduction Components Engine Fire Detection Systems Thermal Switch System Thermocouple Systems Optical Fire Detection Systems Pneumatic Thermal Fire Detection Continuous-Loop Detector Systems Fire Zones Engine Fire Extinguishing System Fire Extinguishing Agents Turbine Engine Ground Fire Protection Containers Discharge Valves Pressure Indication Two-Way Check Valve Discharge Indicators Thermal Discharge Indicator (Red Disc)	9-1 9-2 9-2 9-2 9-3 9-3 9-3 9-3 9-7 9-7 9-7 9-7 9-8 9-8 9-8
Chapter 9 Engine Fire Protection Systems Introduction Components Engine Fire Detection Systems Thermal Switch System Thermocouple Systems Optical Fire Detection Systems. Pneumatic Thermal Fire Detection Continuous-Loop Detector Systems Fire Zones Engine Fire Extinguishing System Fire Extinguishing Agents Turbine Engine Ground Fire Protection Containers Discharge Valves Pressure Indication Two-Way Check Valve Discharge Indicator (Red Disc) Yellow Disc Discharge Indicator	9-1 9-2 9-2 9-2 9-3 9-3 9-3 9-3 9-7 9-7 9-7 9-8 9-8 9-8 9-8 9-9 9-9
Chapter 9 Engine Fire Protection Systems Introduction Components Engine Fire Detection Systems Thermal Switch System Thermocouple Systems Optical Fire Detection Systems Pneumatic Thermal Fire Detection Continuous-Loop Detector Systems Fire Zones Engine Fire Extinguishing System Fire Extinguishing Agents Turbine Engine Ground Fire Protection Containers Discharge Valves Pressure Indication Two-Way Check Valve Discharge Indicator (Red Disc) Yellow Disc Discharge Indicator Fire Switch	9-1 9-2 9-2 9-2 9-3 9-3 9-3 9-3 9-7 9-7 9-7 9-7 9-8 9-8 9-8 9-8 9-9 9-9
Chapter 9 Engine Fire Protection Systems Introduction Components Engine Fire Detection Systems Thermal Switch System Thermocouple Systems Optical Fire Detection Systems. Pneumatic Thermal Fire Detection Continuous-Loop Detector Systems Fire Zones Engine Fire Extinguishing System Fire Extinguishing Agents Turbine Engine Ground Fire Protection Containers Discharge Valves Pressure Indication Two-Way Check Valve Discharge Indicator (Red Disc) Yellow Disc Discharge Indicator	9-1 9-1 9-1 9-2 9-2 9-2 9-3 9-3 9-3 9-3 9-7 9-7 9-7 9-7 9-8 9-8 9-8 9-8 9-9 9-9

Fire Detection System Troubleshooting	9-11
Fire Extinguisher System Maintenance Practices	
Boeing 777 Aircraft Fire Detection & Extinguishing System	9-13
Overheat Detection	
Fire Detection	9-13
Nacelle Temperature Recording	9-13
Continuous Fault Monitoring	9-13
Single/Dual Loop Operation	9-14
System Test	9-14
Boeing 777 Fire Extinguisher System	9-14
Fire Extinguisher Containers	9-14
Squib	9-16
Engine Fire Switches	9-16
Engine Fire Operation	9-17
APU Fire Detection & Extinguishing System	
APU Fire Warning	9-18
Fire Bottle Discharge	9-18
Chapter 10	
Engine Maintenance & Operation	40.4
Reciprocating Engine Overhaul	
Top Overhaul & Major Danaira	
Major Overhaul & Major Repairs	
Receiving Inspection	
Disassembly	
Inspection Process	
Visual Inspection	
Cylinder Head	
Piston, Valve Train, & Piston Pin	
Crankshaft & Connecting Rods	
Cleaning	
Degreasing	
Removing Hard Carbon	10-5
Structural Inspection	10-6
Dye Penetrant Inspection	10-6
Eddy Current Inspection	10-7
Ultrasonic Inspection	10-7
Pulse-Echo	10-7
Through Transmission	10-7
Resonance	10-7
Magnetic Particle Inspection	10-7
X-ray	10-7
Dimensional Inspection	10-7
Cylinder Barrel	
Rocker Arms & Shafts	
Crankshaft	
Checking Alignment	
Repair & Replacement	
Cylinder Assembly Reconditioning	
Piston & Piston Pins	10-11

	Valves & Valve Springs	
	Refacing Valve Seats	10-13
	Valve Reconditioning	10-14
	Valve Lapping & Leak Testing	10-17
	Piston Repairs	10-17
	Cylinder Grinding & Honing	10-17
Rea	assembly	
Ins	tallation & Testing	10-19
	Testing Reciprocating Engines	
	Test Cell Requirements	
	Engine Instruments	
	Carburetor Air Temperature (CAT) Indicator	
	Fuel Pressure Indicator	
	Oil Pressure Indicator	
	Oil Temperature Indicator	
	Fuel-Flow Meter	
	Manifold Pressure Indicator	
	Tachometer Indicator	
	Cylinder Head Temperature Indicator	
	Torquemeter	
	•	
D۵	Warning Systemsciprocating Engine Operation	
re.	Engine Instruments	
	• ·	
	Engine Starting	
	Pre-Oiling	
	Hydraulic Lock	
	Engine Warm-Up	
	Ground Check	
	Fuel Pressure & Oil Pressure Check	
	Propeller Pitch Check	
	Power Check	
	Idle Speed & Idle Mixture Checks	
	Engine Stopping	
Bas	sic Engine Operating Principles	10-29
	Combustion Process	
	Detonation	
	Pre-Ignition	
	Backfiring	10-30
	Afterfiring	10-31
Fac	ctors Affecting Engine Operation	10-31
	Compression	10-31
	Fuel Metering	10-31
	Idle Mixture	10-33
	Induction Manifold	10-33
	Operational Effect of Valve Clearance	10-33
Eng	gine Troubleshooting	
•	Valve Blow-By	
Cvl	inder Compression Tests	
,	Differential Pressure Tester	
	Cylinder Replacement	
Cyl	inder Removal	

Cylinder Installation	10-42
Cold Cylinder Check	10-43
Turbine Engine Maintenance	10-44
Compressor Section	
Inspection & Cleaning	10-45
Causes of Blade Damage	10-45
Blending & Replacement	10-47
Combustion Section Inspection	10-47
Marking Materials for Combustion Section Parts	10-49
Inspection & Repair of Combustion Chambers	10-49
Fuel Nozzle & Support Assemblies	10-50
Turbine Disc Inspection	10-50
Turbine Blade Inspection	10-50
Turbine Blade Replacement Procedure	10-51
Turbine Nozzle Inlet Guide Vane Inspection	10-52
Clearances	10-52
Exhaust Section	10-54
Engine Ratings	10-54
Turbine Engine Instruments	10-54
Engine Pressure Ratio Indicator	10-54
Torquemeter (Turboprop Engines)	
Tachometer	
Exhaust Gas Temperature Indicator (EGT)	10-55
Fuel-Flow Indicator	
Engine Oil Pressure Indicator	10-55
Engine Oil Temperature Indicator	
Turbine Engine Operation	10-57
Ground Operation Engine Fire	
Engine Checks	10-57
Checking Takeoff Thrust	10-57
Ambient Conditions	
Engine Shutdown	10-58
Troubleshooting Turbine Engines	
Turboprop Operation	
Troubleshooting Procedures for Turboprop Engines	
Turbine Engine Calibration & Testing	10-59
Turbine Engine Analyzer Uses	
Analyzer Safety Precautions	
Continuity Check of Aircraft EGT Circuit	
Functional Check of Aircraft EGT Circuit	
EGT Indicator Check	
Resistance & Insulation Check	
Tachometer Check	
Troubleshooting EGT System	
One or More Inoperative Thermocouples in Engine Parallel Harness	
Engine Thermocouples Out of Calibration	
EGT Circuit Error	
Resistance of Circuit Out of Tolerance	
Shorts to Ground/Shorts Between Leads	
Troubleshooting Aircraft Tachometer System	

Chapter 11

ight-Sport Aircraft Engines	
Engine General Requirements	
Personnel Authorized to Perform Inspection & Maintenance on Light-Sport Engines	11-2
Authorized Personnel That Meet FAA Regulations	
Types of Light-Sport & Experimental Engines	
Light-Sport Aircraft Engines	
Two-Cycle, Two Cylinder Rotax Engine	
Rotax 447 UL Single Capacitor Discharge Ignition (SCDI) & Rotax 503 UL Dual Capacit	tor Discharge
Ignition (DCDI)	
Rotax 582 UL DCDI	
Description of Systems for Two-Stroke Engines	
Cooling System of Rotax 447 UL SCDI & Rotax 503 UL DCDI	
Cooling System of the Rotax 582 UL DCDI	
Lubrication Systems	
Oil Injection Lubrication of Rotax 503 UL DCDE & 582 UL DCDI	
Electric System	
Fuel System	
Fuel-Oil Mixing Procedure	
Opposed Light-Sport, Experimental, & Certificated Engines	
Rotax 912/914	
Description of Systems	
Cooling System	11-6
Fuel System	11-6
Lubrication System	11-7
Electric System	11-8
Turbocharger & Control System	11-8
HKS 700T Engine	11-9
Jabiru Light-Sport Engines	11-10
Jabiru 2200 Aircraft Engine	11-11
Aeromax Aviation 100 (IFB) Aircraft Engine	11-11
Direct Drive VW Engines	11-12
Revmaster R-2300 Engine	11-12
Great Plains Aircraft Volkswagen (VW)Conversions	11-14
Teledyne Continental 0-200 Engine	11-15
Lycoming 0-233 Series Light-Sport Aircraft Engine	11-15
General Maintenance Practices on Light-Sport Rotax Engines	
Maintenance Schedule Procedures & Maintenance Checklist	
Carburetor Synchronization	
Pneumatic Synchronization	
Idle Speed Adjustment	
Optimizing Engine Running	
Checking the Carburetor Actuation	
Lubrication System	
Oil Level Check	
Oil Change	
Cleaning the Oil Tank	
Inspecting the Magnetic Plug	
Checking the Friction Torque in Free Rotation	11-21 11-21
COECKOO DE FOCION TORME IN FIEE KOIZION	11-71

Daily Maintenance Checks	11-21
Pre-flight Checks	11-22
Troubleshooting & Abnormal Operation	11-22
Troubleshooting	11-23
Engine Keeps Running With Ignition OFF	11-23
Knocking Under Load	11-23
Abnormal Operation	11-23
Exceeding the Maximum Admissible Engine Speed	11-23
Exceeding Maximum Admissible Cylinder Head Temperature	11-23
Exceeding Maximum Admissible Exhaust Gas Temperature	
Engine Preservation	11-23
General Maintenance Practices for the Light-Sport Jabiru Engines	11-23
Engine & Engine Compartment Inspection	11-23
Lubrication System	11-24
Carburetor Adjustment & Checks	11-24
Spark Plugs	11-24
Exhaust System	11-24
Head Bolts	11-24
Tachometer & Sender	11-25
Engine Inspection Charts	11-25
Glossary	G-1
Index	I-1