MAINTENANCE PROCEDURE OF PREVENTIVE

I. DAILY MAINTENANCE

UNITS:-

ファファフ

,

9

- Check for any abnormal noise and Vibration.
- Check the AMPS.
- 3. Check the condition of the CO Sensors if required clean the CO sensors.
- Check the rotation of the STP exhaust unit

II. MONTHLY MAINTENANCE:-

UNITS:-

- Check all the items listed under daily maintenance.
- 2. Check the grease for motors, grease the if required.
- 3. Check the electrical connections for any loose any tight them if required.

III. QUARTERLY MAINTENANCE

UNITS:-

- 1. Check the all listed item under weekly maintenance.
- 2. Check the blower and motors alignment.

IV. HALF YEARLY MAINTENANCE

UNITS:-

- 1. Check the all listed item under Monthly maintenance.
- 2. Check the all motors and Dampers if required clean it.
- 3. Check the operation of dampers.

V. ANNUAL MAINTENANCE

UNITS:-

- 1. Check the all listed item under Quarterly maintenance.
- 2. Check the blower for any damage (crack on blades etc.), which may leads to unbalance and excessive vibration.
- 3. Check the blower and housing for accumulation of dirt.

A permanent daily record of system operating conditions recorded at regular intervals throughout each 24 hours operating period should be kept.