

Maintenance & Care of your Wetpour Floor (EPDM)

Ebaco Wet pour Playgrounds are hygienic, long lasting and need less maintenance, Its smooth, fine-pored surface vastly prevents dirt from penetrating, any refuse lying around remains on the surface so that it is immediately visible, It can therefore be cleaned with little workload, quickly and at low costs

To keep the surface to use it longer just needs some basic cleaning and maintenance method. Here you will find some tips how your playing surface can give consistent performance

- 1. Generally will be kept clean with wind and rain, however occasional manual cleaning is required, It can easily be cleaned using a broom, medium bristle scrub brush, garden hose with spray nozzle, pressure washer
- 2. Stubborn extensive soiling and other residues which spoil the appearance of the surface can be removed with thorough cleaning. We recommend using a power cleaner for this purpose (caution, do not use a rotating nozzle). This warrants above all that the joints and pores are cleaned. There is no need to use any kind of detergent
- 3. Really severe soiling and stains should be removed straight away as far as possible, because certain substances can settle in the surface and become difficult to remove or get rid of completely. Remove fresh stains with a brush, then wipe the surface down with clear water or use the power cleaner
- 4. Ensuring appropriate footwear is used on the surface (i.e. no high heeled shoes)
- 5. Leaves, tree flowers, pine needles and other detritus should not be allowed to remain on the surface for any length of time. If this happens they rapidly rot down forming a drainage-inhibiting 'skin' within the surface, and providing a growing medium foalgae moss and weeds.
- 6. No matter how much care is taken, weeds may occasionally appear on the surface usually as a result of wind blown seeds. Small numbers of weeds can be removed by hand without damaging the surface.
- 7. Rain helps clean the ground basically. In case of accumulating dirt's in standing water, leaving stains and piles of debris. Such kind of acts like an abrasive under the player's feet and damage on the surface. Need to be removed water from birdbaths as often as possible.

Use soft Nylon or hair type brooms for scrubbing the surface. But advised to scrub with hard bristles brush or brooms can damage the surface. Best way of cleaning tool is water jet with limit pressure shouldn't be more than 70 psi.