Computer Networks



Prof. Xudong Wang

Outline

- General Architecture of Physical Layer
- Signal Representation
- Digitization of Analog Signals
 - Sampling
 - Quantization
- Digital Signal Transmission and Reception
 - Channel
 - Modulation
 - Forward Error Control
 - Multiplexing
- Transmission Medium



General Architecture


See class notes

Bits, Number, and Information

- Bit: number with value 0 or 1
 - *n* bits: digital representation for $0, 1, ..., 2^n$
 - Byte or Octet, n = 8
 - Computer word, n = 16, 32, or 64
- n bits allows enumeration of 2^n possibilities
 - n-bit field in a header
 - *n*-bit representation of a voice sample
 - Message consisting of n bits
- The number of bits required to represent a message is a measure of its information content
 - More bits → More content

Signal Representation: Fourier Analysis


 A periodic signal with period T can be represented as sum of sinusoids using Fourier Series:



- • $|a_k|$ determines amount of power in kth harmonic
- •Amplitude specturm $|a_0|$, $|a_1|$, $|a_2|$, ...




Example Fourier Series



$$x_{1}(t) = 0 + \frac{4}{\pi} \cos(2\pi 4000t)$$

$$+ \frac{4}{3\pi} \cos(2\pi 3(4000)t)$$

$$+ \frac{4}{5\pi} \cos(2\pi 5(4000)t) + \dots$$



$$x_2(t) = 0 + \frac{4}{\pi} \cos(2\pi 1000t)$$


$$+ \frac{4}{3\pi} \cos(2\pi 3(1000)t)$$

$$+ \frac{4}{5\pi} \cos(2\pi 5(1000)t) + \dots$$


Spectrum

- Spectrum of a signal: magnitude of amplitudes as a function of frequency
- x₁(t) varies faster in time & has more high frequency content than x₂(t)
- Bandwidth W_s is defined as range of frequencies where a signal has nonnegligible power, e.g. range of band that contains 99% of total signal power

Spectrum of $x_1(t)$



Spectrum of $x_2(t)$





Non-Periodic Signals

Fourier Transform



Digitization of Analog Signals

Transmission Impairments



Communication Channel

- Pair of copper wires
- Coaxial cable
- Radio
- Light in optical fiber
- Light in air
- Infrared

Transmission Impairments

- Signal attenuation
- Signal distortion
- Spurious noise
- Interference from other signals

5/27/2020

Analog Long-Distance Communications

- Each repeater attempts to restore analog signal to its original form
- Restoration is imperfect
 - Distortion is not completely eliminated
 - Noise & interference is only partially removed
- Signal quality decreases with # of repeaters
- Communications is distance-limited
- Still used in analog cable TV systems
- Analogy: Copy a song using a cassette recorder


Transmission segment

Source Repeater Destination




Analog vs. Digital Transmission

Analog transmission: all details must be reproduced accurately



Digital transmission: only discrete levels need to be reproduced



12


Digital Long-Distance Communications

- Regenerator recovers original data sequence and retransmits on next segment
- Can design so error probability is very small
- Then each regeneration is like the first time!
- Analogy: copy an MP3 file
- Communications is possible over very long distances
- Digital systems vs. analog systems
 - Less power, longer distances, lower system cost
 - Monitoring, multiplexing, coding, encryption, protocols...



5/27/2020

System Architecture of Analog Signal Digitization and Transmission



2W samples / sec


4

Digitization of Analog Signals

- Sampling: obtain samples of x(t) at uniformly spaced time intervals
- Quantization: map each sample into an approximation value of finite precision
 - Pulse Code Modulation: telephone speech
 - CD audio
- 3. Compression: to lower bit rate further, apply additional compression method
 - Differential coding: cellular telephone speech
 - Subband coding: MP3 audio
 - Other coding schemes



Sampling of Analog Signal




5/27/2020




Sampling Theorem

Nyquist: Perfect reconstruction if sampling rate $1/T > 2W_s$




Quantization of Analog Samples




Quantizer maps input into closest of 2^m representation values

Quantization error: "noise" = x(nT) - y(nT)



Quantizer Performance (1)

 $M = 2^m$ levels, Dynamic range(-V, V) $\Delta = 2V/M$



If the number of levels M is large, then the error is approximately uniformly distributed between $(-\Delta/2, \Delta2)$

Average Noise Power = Mean Square Error:

$$\sigma_{\rm e}^2 = \int_{\frac{\Delta}{2}}^{\frac{\Delta}{2}} x^2 \frac{1}{\Delta} dx = \frac{\Delta^2}{12}$$

Quantizer Performance (2)

Figure of Merit:

Signal-to-Noise Ratio = Avg signal power / Avg noise power Let σ_x^2 be the signal power, then

SNR =
$$\frac{\sigma_x^2}{\Delta^2/12} = \frac{12\sigma_x^2}{4V^2/M^2} = 3(\frac{\sigma_x}{V})^2 M^2 = 3(\frac{\sigma_x}{V})^2 2^{2m}$$

The ratio $V/\sigma_x \approx 4$

The SNR is usually stated in decibels:

SNR db = 10
$$\log_{10} \sigma_x^2 / \sigma_e^2$$
 = 6m + 10 $\log_{10} 3\sigma_x^2 / V^2$

SNR db = 6*m* - 7.27 dB for
$$V/\sigma_x = 4$$
.

20



Example: Telephone Speech

W = 4KHz, so Nyquist sampling theorem

 \Rightarrow 2W = 8000 samples/second

Suppose error requirement = 1% error

 $SNR = 10 \log(1/.01)^2 = 40 dB$

Assume $V/\sigma_x = 4$, then

$$40 \text{ dB} = 6m - 7$$


 \Rightarrow m = 8 bits/sample

PCM ("Pulse Code Modulation") Telephone Speech:

Bit rate= 8000 x 8 bits/sec= 64 kbps



Differential PCM and Delta Modulation




5/27/2020



Digital Signal Transmission and Reception

4

Digital Binary Signal




Bit rate = 1 bit / T seconds

For a given communications medium:

- How do we increase transmission rate?
- How do we achieve reliable communications?
- Are there any limits to rate and reliability?

Pulse Transmission Rate

- Maximize pulse rate through a channel, that is, make T as small as possible
- If input is a narrow pulse, then typical output is a spread-out pulse with ringing
- Question: How frequently can these pulses be transmitted without interfering with each other?
- Answer: 2 x Wc pulses/second, why???
 where Wc is the bandwidth of the channel



Multilevel Pulse Transmission

- Assume channel of bandwidth W_{σ} and transmit 2 W_{c} pulses/sec (without interference)
- If pulses amplitudes are either -A or +A, then each pulse conveys 1 bit, so
 - Bit Rate = 1 bit/pulse x $2W_c$ pulses/sec = $2W_c$ bps
- If amplitudes are from $\{-A, -A/3, +A/3, +A\}$, then bit rate is 2 x 2 W_c bps
- By going to $M = 2^m$ amplitude levels, we achieve

Bit Rate = m bits/pulse x 2 W_c pulses/sec = 2 mW_c bps

In the absence of noise, the bit rate can be increased without limit by increasing m





Noise & Reliable Communications

- All physical systems have noise
 - Electrons always vibrate at non-zero temperature
 - Motion of electrons induces noise
- Presence of noise limits accuracy of measurement of received signal amplitude
- Errors occur if signal separation is comparable to noise level
- Bit Error Rate (BER) increases with decreasing signal-to-noise ratio
- Noise places a limit on how many amplitude levels can be used in pulse transmission

4

Signal-to-Noise Ratio (SNR) Example





 $SNR (dB) = 10 log_{10} SNR$

-

Channel Capacity: Shannon Theory

$$C = W_c \log_2 (1 + SNR)$$
 bps


- Arbitrarily reliable communications is possible if the transmission rate R < C.
- If R > C, then arbitrarily reliable communications is not possible.
- "Arbitrarily reliable" means the BER can be made arbitrarily small through sufficiently complex coding.
- C can be used as a measure of how close a system design is to the best achievable performance.
- Bandwidth W_c & SNR determine C



Channel Bandwidth

$$X(t) = a \cos(2\pi ft)$$
 Channel $\longrightarrow Y(t) = A(f) a \cos(2\pi ft)$

- If input is sinusoid of frequency f, then
 - output is a sinusoid of the same frequency f
 - Output is attenuated by an amount A(f) that depends on f
 - A(f)≈1, then input signal passes readily
 - $A(f)\approx 0$, then input signal is blocked
- Bandwidth Wc is range of frequencies passed by channel




Ideal low-pass channel


Example: Low-Pass Filter Channel

- Simplest non-ideal circuit that provides low-pass filtering
 - Inputs at different frequencies are attenuated by different amounts
 - Inputs at different frequencies are delayed by different amounts

Amplitude Response




Phase Response





Example: Band-Pass Filter Channel

- Some channels pass signals within a band that excludes low frequencies
 - Telephone modems, radio systems, ...
- Channel bandwidth is the width of the frequency band that passes non-negligible signal power



How good is a channel?

- Performance: What is the maximum reliable transmission rate?
 - Rate: Bit rate, R bps
 - Reliability: Bit error rate, BER=10^{-k}
- Cost: What is the cost of alternatives at a given level of performance?
 - Wired vs. wireless?
 - Electronic vs. optical?
 - Standard A vs. standard B?



Channel Characteristics



Signal Bandwidth

 In order to transfer data faster, a signal has to vary more quickly.

Channel Bandwidth

- A channel or medium has an inherent limit on how fast the signals it passes can vary
- Limits how tightly input pulses can be packed

Transmission Impairments

- Signal attenuation
- Signal distortion (due to channel)
- Spurious noise
- Interference from other signals
- Limits accuracy of measurements on received signal

5/27/2020

How to Increase Communication Rate?

The maximum reliable transmission rate over an ideal channel with bandwidth WHz, with Gaussian distributed noise, and with SNR S/N is

$$C = W \log_2 (1 + S/N)$$
 bits per second

- Given a channel bandwidth, what methods can be used for improving communication rate?
 - Modulation: a way of converting bits into baseband waveforms with different signal levels. Given a SNR, modulation improves bits per pulse
 - Channel coding: improves SNR for higher-rate modulation
 - DSP: e.g., channel equalizer; improves SNR
 - Power amplifier; improves SNR




Modulation: General Procedure

- Convert bits into symbols
- DAC
- The baseband signal modulates a sinusoid wave (carrier)

4

Modulation (on a bandpass channel)



- Bandpass channels pass a range of frequencies around some center frequency f_c
 - Radio channels, telephone & DSL modems
- Digital modulators embed information into waveform with frequencies passed by bandpass channel
- Sinusoid of frequency f_c is centered in middle of bandpass channel
- Modulators embed information into a sinusoid

Amplitude Modulation and Frequency Modulation



1


0

1

1


1

Amplitude Shift Keying



Map bits into amplitude of sinusoid: "1" send sinusoid; "0" no sinusoid Demodulator looks for signal vs. no signal

Frequency
Shift
Keying



Map bits into frequency: "1" send frequency f_c + δ ; "0" send frequency f_c - δ Demodulator looks for power around f_c + δ or f_c - δ



Phase Modulation


Information

1 0 1

1

1

Phase Shift Keying



- Map bits into phase of sinusoid:
 - "1" send A cos(2πft)

, i.e. phase is 0

• "0" send A $cos(2\pi ft+\pi)$

, i.e. phase is $\boldsymbol{\pi}$

- Equivalent to multiplying $cos(2\pi ft)$ by +A or -A
 - "1" send A cos(2πft)

, i.e. multiply by 1

• "0" send A $\cos(2\pi f t + \pi) = - A \cos(2\pi f t)$

, i.e. multiply by -1




Modulator & Demodulator

Modulate $\cos(2\pi f_c t)$ by multiplying by A_k for T seconds:

$$A_k$$
 \longrightarrow $Y_i(t) = A_k \cos(2\pi f_c t)$

$$\cos(2\pi f_c t)$$
 Transmitted signal during k th interval

Demodulate (recover A_k) by multiplying by $2\cos(2\pi f_c t)$ for T seconds and lowpass filtering (smoothing):




5/27/2020

Signaling rate and Transmission Bandwidth

Fact from modulation theory:

If
Baseband signal *x(t)*with bandwidth *B* Hz
then


Modulated signal $x(t)\cos(2\pi f_c t)$ has bandwidth 2B Hz



- If bandpass channel has bandwidth W_c Hz,
 - Then baseband channel has $W_d/2$ Hz available, so
 - modulation system supports $W_d/2 \times 2 = W_c$ pulses/second
 - That is, W_c pulses/second per W_c Hz = 1 pulse/Hz
 - Recall baseband transmission system supports 2 pulses/Hz


Quadrature Am

- Quadrature Amplitude Modulation (QAM)
- QAM uses two-dimensional signaling
 - A_k modulates in-phase $\cos(2\pi f_c t)$
 - B_k modulates quadrature phase $\cos(2\pi f_c t + \pi/4) = \sin(2\pi f_c t)$
 - Transmit sum of inphase & quadrature phase components



- Yi(t) and Yq(t) both occupy the bandpass channel
- QAM sends 2 pulses/Hz

QAM Demodulation





5/27/2020



Signal Constellations

- Each pair (Ak, Bk) defines a point in the plane
- Signal constellation set of signaling points





- 4 possible points per T sec.
- 2 bits / pulse

16 possible points per *T* sec. 4 bits / pulse

T

Telephone Modem Standards

Telephone Channel for modulation purposes has $W_c = 2400 \text{ Hz} \rightarrow 2400 \text{ pulses per second}$

Modem Standard V.32bis

• Trellis modulation maps m bits into one of 2^{m+1} constellation points

14,400 bps Trellis 128 2400x6

9600 bps Trellis 32 2400x4

4800 bps
 QAM 4 2400x2

Modem Standard V.34 adjusts pulse rate to channel

2400-33600 bps Trellis 960 2400-3429 pulses/sec


Error Control

- Digital transmission systems introduce errors
- Applications require certain reliability level
 - Data applications require error-free transfer
 - Voice & video applications tolerate some errors
- Error control used when transmission system does not meet application requirement
- Error control ensures a data stream is transmitted to a certain level of accuracy despite errors
- Two basic approaches:
 - Error detection & retransmission (ARQ)
 - Forward error correction (FEC)

这一章(之后几页介绍的Error Control方法)都是FEC


Key Concept

- All transmitted data blocks ("codewords") satisfy a pattern
- If received block doesn't satisfy pattern, it is in error
- Redundancy: Only a subset of all possible blocks can be codewords
- Blindspot: when channel transforms a codeword into another codeword



5/27/2020

Checkbits & Error Detection



5/27/2020 48

Single Parity Check

Append an overall parity check to k information bits

Info Bits: $b_1, b_2, b_3, ..., b_k$

Check Bit: $b_{k+1} = b_1 + b_2 + b_3 + ... + b_k$ modulo 2

Codeword: $(b_1, b_2, b_3, ..., b_k, b_{k+1})$

- All codewords have even # of 1s
- Receiver checks to see if # of 1s is even
 - All error patterns that change an odd # of bits are detectable
 - All even-numbered patterns are undetectable
- Parity bit used in ASCII code

Example of Single Parity Code

- Information (7 bits): (0, 1, 0, 1, 1, 0, 0)
- Parity Bit: $b_8 = 0 + 1 + 0 + 1 + 1 + 0 + 0 = 1$
- Codeword (8 bits): (0, 1, 0, 1, 1, 0, 0, 1)
- If single error in bit 3: (0, 1, 1, 1, 1, 0, 0, 1)
 - # of 1's =5, odd
 - Error detected
- If errors in bits 3 and 5: (0, 1, 1, 1, 0, 0, 0, 1)
 - # of 1's =4, even
 - Error not detected

How good is the single parity check code?


- Redundancy: Single parity check code adds 1 redundant bit per k information bits: overhead = 1/(k + 1)
- Coverage: all error patterns with odd # of errors can be detected
 - An error patten is a binary (k + 1)-tuple with 1s where errors occur and 0's elsewhere
 - Of 2^{k+1} binary (k + 1)-tuples, $\frac{1}{2}$ are odd, so 50% of error patterns can be detected
- Is it possible to detect more errors if we add more check bits?
- Yes, with the right codes

Two-Dimensional Parity Check


- More parity bits to improve coverage
- Arrange information as columns
- Add single parity bit to each column
- Add a final "parity" column
- Used in early error control systems


Bottom row consists of check bit for each column

Error-detecting capability



1	0	0	1	0	0	
0	0	0	0	0	1 ← Two e 0	
1	0	0	1	0	0 Two e	rrors
1	0	0	1	1	0 ←	1





1 0 0 1 1 1

1, 2, or 3 errors can always be detected; Not all patterns >=4 errors can be detected

Four errors

Other Error Detection Codes

- Many applications require very low error rate
- Need codes that detect the vast majority of errors
- Single parity check codes do not detect enough errors
- Two-dimensional codes require too many check bits
- The following error detecting codes used in practice:
 - Internet Check Sums
 - CRC Polynomial Codes

Internet Checksum

- Several Internet protocols (e.g. IP, TCP, UDP) use check bits to detect errors in the *IP header* (or in the header and data for TCP/UDP)
- A checksum is calculated for header contents and included in a special field.
- Checksum recalculated at every router, so algorithm selected for ease of implementation in software
- Let header consist of ∠, 16-bit words,
 b₀, **b**₁, **b**₂, ..., **b**_{/-1}
- The algorithm appends a 16-bit checksum b₁

4

Checksum Calculation

The checksum \mathbf{b}_1 is calculated as follows:

- Treating each 16-bit word as an integer, find $\mathbf{x} = \mathbf{b}_0 + \mathbf{b}_1 + \mathbf{b}_2 + ... + \mathbf{b}_{l-1}$ modulo $2^{16}-1$
- The checksum is then given by:

$$\mathbf{b}_{1} = -\mathbf{x} \mod 2^{16}-1$$

Thus, the headers must satisfy the following *pattern*:

$$\mathbf{0} = \mathbf{b}_0 + \mathbf{b}_1 + \mathbf{b}_2 + ... + \mathbf{b}_{L-1} + \mathbf{b}_L \text{ modulo}$$

 The checksum calculation is carried out in software using one's complement arithmetic



Internet Checksum Example

Use Modulo Arithmetic

- Assume 4-bit words
- Use mod 2⁴-1 arithmetic
- $\underline{b}_0 = 1100 = 12$
- $b_1 = 1010 = 10$
- $\underline{b}_0 + \underline{b}_1 = 12 + 10 = 7 \mod 15$
- $\underline{b}_2 = -7 = 8 \mod 15$
- Therefore
- <u>b</u>₂=1000

Use Binary Arithmetic

- Note 16 =1 mod15
- So: 10000 = 0001 mod15
- leading bit wraps around
- b0 + b1 = 1100 + 1010
- =10110
- **=** 10000+0110
- =0001+0110
- **=** =0111
- **=** =7
- Take 1s complement
- b2 = -0111 = 1000

-

Error Correction

- Error correction not only detects errors but also corrects
 - Error detection only schemes need ARQ to correct error
 - Error correction code can directly detect and correct codes → Forward error correction (FEC)
- Examples
 - Hamming codes
 - Convolutional codes
 - Turbo codes
 - LDPC (low-density parity check codes)

5/27/2020

Hamming Codes

- Class of *error-correcting* codes
 - Capable of correcting all single-error patterns
 - For each $m \ge 2$, there is a Hamming code of length $n = 2^m 1$ with n k = m parity check bits

m	$n = 2^{m}$	k = n-	m/n
	1	m	
3	7	4	3/7
4	15	11	4/15
5	31	26	5/31
6	63	57	6/63

m = 3 Hamming Code

- Information bits are b1, b2, b3, b4
- Equations for parity checks b5, b6, b7

$$b_5 = b_1 + b_3 + b_4$$

 $b_6 = b_1 + b_2 + b_4$
 $b_7 = b_2 + b_3 + b_4$

- There are $2^4 = 16$ codewords
- \bullet (0,0,0,0,0,0,0) is a codeword

Hamming (7,4) code

Information					Codeword								Weight	
	b_1	b_2	b_3	b_4			b_1	b_2	b_3	b_4	b_5	b_6	b_7	ν(<u>b</u>)
	0	0	0	0			0	0	0	0	0	0	0	0
	0	0	0	1			0	0	0	1	1	1	1	4
	0	0	1	0			0	0	1	0	1	0	1	3
	0	0	1	1			0	0	1	1	0	1	0	3
	0	1	0	0			0	1	0	0	0	1	1	3
	0	1	0	1			0	1	0	1	1	0	0	3
	0	1	1	0			0	1	1	0	1	1	0	4
	0	1	1	1			0	1	1	1	0	0	1	4
	1	0	0	0			1	0	0	0	1	1	0	3
	1	0	0	1			1	0	0	1	0	0	1	3
	1	0	1	0			1	0	1	0	0	1	1	4
	1	0	1	1			1	0	1	1	1	0	0	4
	1	1	0	0			1	1	0	0	1	0	1	4
	1	1	0	1			1	1	0	1	0	1	0	4
	1	1	1	0			1	1	1	0	0	0	0	3
	1	1	1	1			1	1	1	1	1	1	1	7

Parity Check Equations

Rearrange parity check equations:

$$0 = b_5 + b_5 = b_1 + b_3 + b_4 + b_5$$

$$0 = b_6 + b_6 = b_1 + b_2 + b_4 + b_6$$

$$0 = b_7 + b_7 = + b_2 + b_3 + b_4 + b_7$$

In matrix form:

$$\begin{bmatrix} 0 \\ 0 \\ 0 \\ 0 \end{bmatrix} = \begin{bmatrix} 1 & 0 & 1 & 1 & 1 & 0 & 0 \\ 1 & 1 & 0 & 1 & 1 & 0 & 0 \\ 0 & 1 & 1 & 1 & 0 & 0 & 1 \end{bmatrix} \begin{vmatrix} b_3 \\ b_4 \\ b_5 \end{vmatrix} = \mathbf{H} \underline{b}^t = \underline{0}$$

$$\begin{bmatrix} b_1 \\ b_2 \\ b_3 \\ b_4 \\ b_5 \\ b_6 \\ b_7 \end{bmatrix} = \mathbf{H} \underline{b}^t = \underline{0}$$

- All codewords must satisfy these equations
- Note: each nonzero 3-tuple appears once as a column in check matrix H



Error Detection with Hamming Code

$$\underline{s} = \mathbf{H} \underline{e} = \begin{bmatrix} 10111100 \\ 1101010 \\ 0111001 \end{bmatrix} \begin{bmatrix} 1 \\ 0 \\ 0 \end{bmatrix} = \begin{bmatrix} 1 \\ 0 \\ 0 \end{bmatrix}$$

Single error detected and can be corrected.

Error syndrome is shown in H

$$\underline{s} = \mathbf{H} \underline{e} = \begin{bmatrix} 10111100 \\ 1101010 \\ 0111001 \end{bmatrix} \begin{bmatrix} 0 \\ 0 \\ 1 \end{bmatrix}$$

$$\begin{bmatrix} 0 \\ 1 \\ 1 \end{bmatrix} + \begin{bmatrix} 1 \\ 0 \\ 0 \end{bmatrix} = \begin{bmatrix} 1 \\ 1 \\ 1 \end{bmatrix}$$

Double error detected


$$\underline{s} = \mathbf{H} \underline{e} = \begin{bmatrix} 10111100 \\ 1101010 \\ 0111001 \end{bmatrix}$$

$$\begin{bmatrix} 1 \\ 1 \\ 0 \end{bmatrix} + \begin{bmatrix} 0 \\ 1 \\ 1 \end{bmatrix} + \begin{bmatrix} 1 \\ 0 \\ 1 \end{bmatrix} = \underline{0}$$

Triple error not detected

1

Error-correction using Hamming Codes



The receiver first calculates the syndrome:

$$\underline{s} = H\underline{R} = H(\underline{b} + \underline{e}) = H\underline{b} + H\underline{e} = H\underline{e}$$

- If s = 0, then the receiver accepts R as the transmitted codeword
- If <u>s</u> is nonzero, then an error is detected
 - Hamming decoder assumes a single error has occurred
 - Each single-bit error pattern has a unique syndrome
 - The receiver matches the syndrome to a single-bit error pattern and corrects the appropriate bit
- Minimum distance of Hamming codes

General Hamming Codes

- For m > 2, the Hamming code is obtained through the check matrix H:
 - Each nonzero m-tuple appears once as a column of H
 - The resulting code corrects all single errors
- For each value of m, there is a polynomial code with g(x) of degree m that is equivalent to a Hamming code and corrects all single errors
 - For m = 3, $g(x) = x^3 + x + 1$

Polynomial Codes

- Polynomials instead of vectors for codewords
- Polynomial arithmetic instead of check sums
- Implemented using shift-register circuits
- Also called cyclic redundancy check (CRC) codes
- Most data communications standards use polynomial codes for error detection
- Polynomial codes also basis for powerful errorcorrection methods

5/27/2020 66



Binary Polynomial Arithmetic

Binary vectors map to polynomials

$$(i_{k-1}, i_{k-2}, ..., i_2, i_1, i_0) \rightarrow i_{k-1}x^{k-1} + i_{k-2}x^{k-2} + ... + i_2x^2 + i_1x + i_0$$

Addition:

$$(x^7 + x^6 + 1) + (x^6 + x^5) = x^7 + x^6 + x^6 + x^5 + 1$$

= $x^7 + (1+1)x^6 + x^5 + 1$
= $x^7 + x^5 + 1$ since $1+1=0 \mod 2$

Multiplication:

$$(x+1)(x^2+x+1) = x(x^2+x+1) + 1(x^2+x+1)$$
$$= x^3+x^2+x) + (x^2+x+1)$$
$$= x^3+1$$



Binary Polynomial Division

Division with Decimal Numbers

divisor
$$\frac{34}{1222}$$
 quotient dividend = quotient x divisor +remainder $\frac{35}{105}$ $\frac{105}{172}$ dividend $\frac{105}{140}$ remainder

Polynomial Division

 $x^3 + x + 1) x^6 + x^5$

 $\chi^6 + \chi^4 + \chi^3$

 $x^3 + x^2 + x$

dividend

= q(x) quotient

divisor $\frac{}{x^5 + x^4 + x^3}$

 $x^5 + x^3 + x^2$

 $\chi^4 + \chi^2$

 $\chi^4 + \chi^2 + \chi$

Note: Degree of r(x) is less than degree of divisor

Polynomial Coding

- Code has binary *generating polynomial* of degree n-k $g(x) = x^{n-k} + g_{n-k-1}x^{n-k-1} + ... + g_2x^2 + g_1x + 1$
- k information bits define polynomial of degree k-1 $i(x) = i_{k-1}x^{k-1} + i_{k-2}x^{k-2} + \dots + i_2x^2 + i_1x + i_0$
- Find remainder polynomial of at most degree n-k-1

$$g(x)) x^{n-k} i(x)$$

$$r(x)$$

$$x^{n-k} i(x) = q(x)g(x) + r(x)$$

■ Define the *codeword polynomial* of degree n-1

$$b(x) = x^{n-k}i(x) + r(x)$$
n bits

k bits

n-k bits

-

Polynomial example: k = 4, n-k = 3

Generator polynomial:
$$g(x) = x^3 + x + 1$$

Information:
$$(1,1,0,0)$$
 $i(x) = x^3 + x^2$

Encoding:
$$x^3i(x) = x^6 + x^5$$

 $x^3 + x^2 + x$

$$x^3 + x + 1$$
) $x^6 + x^5$
 $x^6 + x^4 + x^3$


$$x^{5} + x^{4} + x^{3}$$
 $x^{5} + x^{3} + x^{2}$
 $x^{4} + x^{2}$

$$x^4 + x^2 + x$$

Transmitted codeword:

$$b(x) = x^{6} + x^{5} + x$$

$$\underline{b} = (1,1,0,0,0,1,0)$$





The *Pattern* in Polynomial Coding (Decoding)


All codewords satisfy the following pattern:

$$b(x) = x^{n-k}i(x) + r(x) = q(x)g(x) + r(x) + r(x) = q(x)g(x)$$

- All codewords are a multiple of g(x)!
- Receiver should divide received n-tuple by g(x) and check if remainder is zero
- If remainder is nonzero, then received n-tuple is not a codeword

4

Undetectable error patterns



- e(x) has 1s in error locations & 0s elsewhere
- Receiver divides the received polynomial R(x) by g(x)
- Blindspot: If e(x) is a multiple of g(x), that is, e(x) is a nonzero codeword, then

$$R(x) = b(x) + e(x) = q(x)g(x) + q'(x)g(x)$$

- The set of undetectable error polynomials is the set of nonzero code polynomials
- Choose the generator polynomial so that selected error patterns can be detected.

4

Designing good polynomial codes (1)

- Select generator polynomial so that likely error patterns are not multiples of g(x)
- Detecting Single Errors
 - $e(x) = x^i$ for error in one location
 - If g(x) has more than 1 term, it cannot divide x^i
- Detecting Double Errors
 - $e(x) = x^{i} + x^{j} = x^{i}(x^{j-i}+1)$ where j>i
 - If g(x) has more than 1 term, it cannot divide x^i
 - If g(x) is a *primitive* polynomial, it cannot divide x^m+1 for all $m<2^{n-k}-1$ (Need to keep codeword length n less than $2^{n-k}-1$)
 - Primitive polynomials can be found by consulting coding theory books

4

Designing good polynomial codes (2)


- Detecting Odd Numbers of Errors
 - Suppose all codeword polynomials have an even # of 1s, then all odd numbers of errors can be detected
 - As well, b(x) evaluated at x = 1 is zero because b(x) has an even number of 1s
 - This implies x + 1 must be a factor of all b(x)
 - Pick g(x) = (x + 1) p(x) where p(x) is primitive
- Bursty Errors
 - All bursts of length n-k or less can be detected



Shift-Register Implementation of Polynomial Codes

- 1. Accept information bits $i_{k-1}, i_{k-2}, ..., i_2, i_1, i_0$
- 2. Append n k zeros to information bits
- 3. Feed sequence to shift-register circuit that performs polynomial division
- 4. After *n* shifts, the shift register contains the remainder

Division Circuit



Clock	(Input	Reg 0	Reg 1	Reg 2
0	-	0	0	0
1	$1 = i_3$	1	0	0
2	$1 = i_2$	1	1	0
3	$0=i_1$	0	1	1
4	$0 = i_0$	1	1	1
5	0	1	0	1
6	0	1	0	0
7	0	0	1	0
	Check bits:	$r_0 = 0$ $r(x) = x$	$r_1 = 1$	$r_2 = 0$



Standard Generator Polynomials

CRC = cyclic redundancy check

CRC-8:

$$= x^8 + x^2 + x + 1$$

ATM

• CRC-16: = $x^{16} + x^{15} + x^2 + 1$ $= (x + 1)(x^{15} + x + 1)$

Bisync

• CCITT-16: = $x^{16} + x^{12} + x^{5} + 1$

HDLC, XMODEM, V.41


IEEE 802, DoD, V.42

CCITT-32:= $x^{32} + x^{26} + x^{23} + x^{22} + x^{16} + x^{12} + x^{11} + x^{10} + x^8 + x^7 + x^5 + x^4 + x^2 + x + 1$

Multiplexing

- Goal
 - Improve efficiency by filling the pipe (transmission medium)
- Approaches
 - Frequency division
 - Time division
 - Code division
 - Wavelength division


Frequency Division Multiplexing




- (a) The original bandwidths.
- (b) The bandwidths raised in frequency.
- (b) The multiplexed channel.




Wavelength Division Multiplexing






Time Division Multiplexing (1)



The T1 carrier (1.544 Mbps).



Time Division Multiplexing (2)



Multiplexing T1 streams into higher carriers.



Code Division Multiplexing

- (a) Binary chip sequences for four stations
- (b) Bipolar chip sequences
- (c) Six examples of transmissions
- (d) Recovery of station C's signal

```
A: 0 0 0 1 1 0 1 1

B: 0 0 1 0 1 1 1 0

C: 0 1 0 1 1 1 0 0

D: 0 1 0 0 0 0 1 0

(a)

A: (-1 -1 -1 +1 +1 -1 +1 +1)

B: (-1 -1 +1 -1 +1 +1 +1 -1)

C: (-1 +1 -1 +1 +1 +1 -1 -1)

D: (-1 +1 -1 -1 -1 -1 +1 -1)
```

Six examples:

$$S_{1} \bullet C = (1 + 1 + 1 + 1 + 1 + 1 + 1 + 1)/8 = 1$$

$$S_{2} \bullet C = (2 + 0 + 0 + 0 + 2 + 2 + 0 + 2)/8 = 1$$

$$S_{3} \bullet C = (0 + 0 + 2 + 2 + 0 - 2 + 0 - 2)/8 = 0$$

$$S_{4} \bullet C = (1 + 1 + 3 + 3 + 1 - 1 + 1 - 1)/8 = 1$$

$$S_{5} \bullet C = (4 + 0 + 2 + 0 + 2 + 0 - 2 + 2)/8 = 1$$

$$S_{6} \bullet C = (2 - 2 + 0 - 2 + 0 - 2 - 4 + 0)/8 = -1$$
(d)



Transmission Media



Wired or Wireless Media


Wired Media

- Signal energy contained& guided within medium
- Spectrum can be re-used in separate media (wires or cables), more scalable
- Extremely high bandwidth
- Complex infrastructure: ducts, conduits, poles, right-of-way

Wireless Media

- Signal energy propagates in space, limited directionality
- Interference, so spectrum regulated
- Limited bandwidth
- Simple infrastructure: antennas & transmitters
- No physical connection between network & user
- Users can move

The Electromagnetic Spectrum





Guided Transmission Data


- Magnetic Media
- Twisted Pair
- Coaxial Cable
- Fiber Optics





Twisted pair

- Two insulated copper wires arranged in a regular spiral pattern to minimize interference
- Various thicknesses, e.g. 0.016 inch (24 gauge)
- Low cost
- **Telephone subscriber loop from** customer to CO
- **Old trunk plant connecting** telephone COs
- **Intra-building telephone from** wiring closet to desktop
- In old installations, loading coils added to improve quality in 3 kHz band, but more attenuation at higher frequencies



Twisted Pair Bit Rates

Standar d	Data Rate	Distance
T-1	1.544 Mbps	18,000 feet, 5.5 km
DS2	6.312 Mbps	12,000 feet, 3.7 km
1/4 STS-1	12.960 Mbps	4500 feet, 1.4 km
1/2 STS-1	25.920 Mbps	3000 feet, 0.9 km
STS-1	51.840 Mbps	1000 feet, 300 m

- Twisted pairs can provide high bit rates at short distances
- Asymmetric Digital Subscriber Loop (ADSL)
 - High-speed Internet Access
 - Lower 3 kHz for voice
 - Upper band for data
- Much higher rates possible at shorter distances
 - Strategy for telephone companies is to bring fiber close to home & then twisted pair
 - Higher-speed access + video

Cat3, Cat5, and UTP

- Category 3 unshielded twisted pair (UTP): ordinary telephone wires
- Category 5 UTP: tighter twisting to improve signal quality
- Shielded twisted pair (STP): to minimize interference; costly
- 10BASE-T Ethernet
 - 10 Mbps, Baseband, Twisted pair
 - Two Cat3 pairs
 - Manchester coding, 100 meters
- 100BASE-T4 Fast Ethernet
 - 100 Mbps, Baseband, Twisted pair
 - Four Cat3 pairs
 - Three pairs for one direction at-a-time
 - 100/3 Mbps per pair;
 - 3B6T line code, 100 meters
- Cat5 & STP provide other options




(a)




(b)


Digital Subscriber Line (1)








Operation of ADSL using discrete multitone modulation.



Bandwidth versus distanced over category 3 UTP for DSL.


Coaxial Cable

- Cylindrical braided outer conductor surrounds insulated inner wire conductor
- High interference immunity
- Higher bandwidth than twisted pair
- Hundreds of MHz
- Cable TV distribution
- Long distance telephone transmission
- Original Ethernet LAN medium




Cable Modem & TV Spectrum

- Cable TV network originally unidirectional
- Cable plant needs upgrade to bidirectional
- 1 analog TV channel is 6 MHz, can support very high data rates
- Cable Modem: shared upstream & downstream
 - 5-42 MHz upstream into network; 2 MHz channels; 500 kbps to 4 Mbps
 - >550 MHz downstream from network; 6 MHz channels; 36 Mbps




Cable Network Topology






Internet over Cable




Optical Fiber

- Light sources (lasers, LEDs) generate pulses of light that are transmitted on optical fiber
 - Very long distances (>1000 km)
 - Very high speeds (>40 Gbps/wavelength)
 - Nearly error-free (BER of 10⁻¹⁵)
- Profound influence on network architecture
 - Dominates long distance transmission
 - Distance less of a cost factor in communications
 - Plentiful bandwidth for new services



Transmission in Optical Fiber





- Very fine glass cylindrical core surrounded by concentric layer of glass (cladding)
- Core has higher index of refraction than cladding
- Light rays incident at less than critical angle θ_c is completely reflected back into the core

4

Multimode & Single-mode Fiber


Multimode fiber: multiple rays follow different paths






- Multimode: Thicker core, shorter reach
 - Rays on different paths interfere causing dispersion & limiting bit rate
- Single mode: Very thin core supports only one mode (path)
 - More expensive lasers, but achieves very high speeds

Fiber Cables






- (a) Side view of a single fiber.
- (b) End view of a sheath with three fibers.

Fiber Cables (2)

ltem	LED	Semiconductor laser
Data rate	Low	High
Fiber type	Multimode	Multimode or single mode
Distance	Short	Long
Lifetime	Long life	Short life
Temperature sensitivity	Minor	Substantial
Cost	Low cost	Expensive




Fiber Optic Networks (1)



A fiber optic ring with active repeaters.

-

Fiber Optic Networks (2)



A passive star connection in a fiber optics network.




Wireless Transmission

- Radio Transmission
- Microwave Transmission
- Infrared and Millimeter Waves
- Lightwave Transmission



Radio Spectrum




Wavelength (meters)

Omni-directional applications

Point-to-Point applications

4

Radio Transmission




- (a) In the VLF, LF, and MF bands, radio waves follow the curvature of the earth.
- (b) In the HF band, they bounce off the ionosphere.




Politics of the Electromagnetic Spectrum

The ISM bands in the United States.



Communication Satellites




Communication satellites and some of their properties, including altitude above the earth, round-trip delay time and number of satellites needed for global coverage.

Principal Satellite Bands


Band	Downlink	Uplink	Bandwidth	Problems
L	1.5 GHz	1.6 GHz	15 MHz	Low bandwidth; crowded
S	1.9 GHz	2.2 GHz	70 MHz	Low bandwidth; crowded
С	4.0 GHz	6.0 GHz	500 MHz	Terrestrial interference
Ku	11 GHz	14 GHz	500 MHz	Rain
Ka	20 GHz	30 GHz	3500 MHz	Rain, equipment cost



Satellite Hub








- (a) The Iridium satellites from six necklaces around the earth.
- (b) 1628 moving cells cover the earth.

Globalstar




- (a) Relaying in space.
- (b) Relaying on the ground.

The Mobile Telephone System

- First-Generation Mobile Phones: Analog Voice
- Second-Generation Mobile Phones: Digital Voice
- Third-Generation Mobile Phones: Digital Voice and Data
- Fourth-Generation

Advanced Mobile Phone System



- (a) Frequencies are not reused in adjacent cells.
- (b) To add more users, smaller cells can be used.


Channel Categories

The 832 channels are divided into four categories:

- Control (base to mobile) to manage the system
- Paging (base to mobile) to alert users to calls for them
- Access (bidirectional) for call setup and channel assignment
- Data (bidirectional) for voice, fax, or data


4

Digital Advanced Mobile Phone System




- (a) A D-AMPS channel with three users.
- (b) A D-AMPS channel with six users.

Global System for Mobile Communications (GSM)



GSM uses 124 frequency channels, each of which uses an eight-slot TDM system





A portion of the GSM framing structure.

CDMA

```
A: 0 0 0 1 1 0 1 1 A: (-1 -1 -1 +1 +1 -1 +1 +1)

B: 0 0 1 0 1 1 1 0 B: (-1 -1 +1 -1 +1 +1 +1 -1)

C: 0 1 0 1 1 1 0 0 C: (-1 +1 -1 +1 +1 +1 -1 -1)

D: 0 1 0 0 0 0 1 0 D: (-1 +1 -1 -1 -1 -1 +1 -1)

(a) (b)
```

Six examples:

$$S_1 \cdot C = (1 + 1 + 1 + 1 + 1 + 1 + 1 + 1)/8 = 1$$

 $S_2 \cdot C = (2 + 0 + 0 + 0 + 2 + 2 + 0 + 2)/8 = 1$
 $S_3 \cdot C = (0 + 0 + 2 + 2 + 0 - 2 + 0 - 2)/8 = 0$
 $S_4 \cdot C = (1 + 1 + 3 + 3 + 1 - 1 + 1 - 1)/8 = 1$
 $S_5 \cdot C = (4 + 0 + 2 + 0 + 2 + 0 - 2 + 2)/8 = 1$
 $S_6 \cdot C = (2 - 2 + 0 - 2 + 0 - 2 - 4 + 0)/8 = -1$
(d)


Third-Generation Mobile Phones: Digital Voice and Data

Basic services an IMT-2000 network should provide

- High-quality voice transmission
- Messaging (replace e-mail, fax, SMS, chat, etc.)
- Multimedia (music, videos, films, TV, etc.)
- Internet access (web surfing, w/multimedia.)



Wireless Local Loops




Architecture of an LMDS system.



Lightwave Transmission





Convection currents can interfere with laser communication systems.

A bidirectional system with two lasers is pictured here.