

Device User Guide

1. Projector

- 1.1** Turn on the **Switch**
(middle button on the wall panel)



- 1.2** Use the wall-mounted remote to lower the screen (**Down**).
Ensure the screen is retracted (**Up**) after use.



- 1.3** Press the **blue (Power On)** button on the projector remote
(located on the table).



- 1.4** Connect the HDMI cable
(on the table) to your device.



2. Audio & Microphone System

- 2.1** Turn on the **Main Switch** (*top right corner*) located at the audio rack under the front meeting table.
- 2.2** The mic system typically starts with the audio rack. If the status light is off (**Standby Mode**), press the **middle switch** on the mic unit to reactivate.



- 2.3** Plug the black USB cable (*on the table*) into your laptop. Set both **Speaker** and **Microphone** output to "**USB Audio Device**" on your computer.


- 2.3.1** Press the **silver button** to talk (*Red light = Active*). Press again to mute.



* The Chairperson unit features a "**Priority**" button; pressing this will temporarily mute all other microphones in the room.

3. Camera

- 3.1** Connect the **blue USB cable** (*on the table*) to your computer and select **"SOUNDVISION HD-400T"** as your Camera source in your meeting software.



- 3.2** Use the **camera remote** (*on the table*) to adjust the view:

3.2.1 Pan/Tilt: Use the **arrow buttons** to move the camera up, down, left, or right.

3.2.2 Zoom: Use the **magnifying glass** buttons (+ / -) to zoom in or out.



** The remote must be pointed toward the camera for optimal response.*

Troubleshooting

- **If the projector display is flickering or not appearing**
 1. **Check Display Settings:** Press **Windows + P** and select "Duplicate."
 2. **Switch Cable:** Try using the **spare HDMI cable** provided.
 3. **Restart:** Restart your computer to refresh the connection.
 4. **Adapter:** Connect via a **HDMI converter/adapter** if necessary
- **If the guest's computer has no HDMI port**
 1. **Request Adapter:** Ask for a **USB-C to HDMI adapter** from the staff.
 2. **Use Central PC:** Use the provided **Meeting Room PC** as a host, then have the guest **Share Screen** via Microsoft Teams or other virtual meeting platforms.

** To request an adapter or assistance with the Central PC, please contact
K.Nattawut (Nutt), (On-site Support)*

Thank you for helping us maintain our meeting space. Haad Thip Family

• Contact •

K.Nattawut (9442), 062-2566250 | DIO | Workplace
K.Chanuanchai (461), 094-3142565 | T&L | Meeting Room Equipment Management