LC-100 Synthetic Infeed

Clear a jam on the infeed

SAFETY GATE

Isolate electrical and pneumatic energy before clearing a jam. PDF p. 1

Tools / materials

Approved obstruction-removal tool PDF p. 2

Procedure

1. 1. Stop the infeed. PDF p. 2
2. 2. Verify stored energy is released. PDF p. 2
3. 3. Remove the obstruction using the approved tool. PDF p. 2

Decision flow

START -> energy isolated? no -> STOP; yes -> clear obstruction -> guard replaced and interlock verified? no -> STOP; yes -> COMPLETE

Exact specification

Guard fastener torque: 24 N·m ± 2 N·m. PDF p. 3

Restart / return to service

Replace the guard and verify the interlock before restart. PDF p. 4

Stop / escalate

STOP if energy cannot be isolated, the obstruction cannot be removed with the approved tool, or the interlock fails.

Source index

Sources: PDF p. 1 SAFE-001; PDF p. 2 STEP-001/002/003; PDF p. 3 SPEC-001; PDF p. 4 RESTART-001.

Reviewed job aid subordinate to the OEM manual and site safety procedures. Not a safety certification.