

CH340 Driver Installation

Please install Keil C51 before the following operation

1. Double click to open the ch341ser.exe file in this path, CH340_CH341/ USB to UART Driver/ stc-isp-15xx-v6.86B.



2. Click the Install button. Then the Install and Uninstall buttons will turn gray. After a while, the prompt will pop up showing the installation is successful.

