AESS – Akuvox Intercom, Phase 1 Wiring (Irvin) – Thu Oct 29

Remove old Lee Dan system • 2 outdoor stations on PoE • 3 Akuvox S562 indoor (Wi-Fi) – power only • Gonzalo programs in Phase 2

OUTDOOR STATION #1
Akuvox 1-button
Power + data over PoE (Cat6)

Cat6 home run → PoE port 1

OUTDOOR STATION #2
Akuvox 3-button
Power + data over PoE (Cat6)

Cat6 home run → PoE port 2

PoE SWITCH
(Anwar brings it tomorrow)
Central spot near her router
+ needs a power outlet

Cat6 patch (uplink)

CUSTOMER ROUTER
Her Wi-Fi (S562s connect to it)
Switch uplink → any LAN port

EXISTING DOOR RELEASE WIRES
Find, tag + leave at each outdoor station. Anwar confirms hookup on site.

IRVIN'S CHECKLIST

- ☐ Pick up a roll of 16/2 at the wholesaler (AM)
- ☐ Remove old Lee Dan panels + 3 IR204EL
- ☐ Cat6 from each outdoor station → switch
- ☐ Switch uplink → her router
- ☐ 16/2 from 3 indoor stations → 12V DC
- ☐ Label every wire • photos of every run
- ☐ Leave programming for Gonzalo (Phase 2)

INDOOR STATIONS – power only (they work on Wi-Fi)

INDOOR #1 – S562
Apt 1 – replaces Lee Dan IR204EL

INDOOR #2 – S562
Apt 2 – replaces Lee Dan IR204EL

INDOOR #3 – S562
Apt 3 – replaces Lee Dan IR204EL

12V DC TRANSFORMER
Power for the 3 indoor stations
Plug in only after all wires land

16/2 wire from each indoor station to the 12V DC transformer
Watch polarity: + to +, – to – • Test 12V at each station before mounting