

BioStar X

Part No.	Description
Base License	
BIOSTARX-STR	BioStar X Starter Edition with S/W License (5 doors & 100 users & 1 Max Operators)
BIOSTARX-ESS	BioStar X Essential Edition with S/W License (32 doors & 1,000 users & 10 Max Operators)
BIOSTARX-ADV	BioStar X Advanced Edition with S/W License (128 doors & 50,000 users & 20 Max Operators), Maps
BIOSTARX-ENT	BioStar X Enterprise Edition with S/W License (500 doors & 100,000 users & 40 Max Operators), Maps, Advanced AC
BIOSTARX-ELT	BioStar X Elite Edition with S/W License (2,000 doors & 500,000 users & 100 Max Operators), Maps, Advanced AC **Up to 1,000 devices connected via Ethernet (direct TCP/IP connection) can be supported regardless of the Base License. To connect more than 1,000 Ethernet-connected devices, MCS is required. (2,000 doors ≠ 2,000 devices)
BIOSTARX-DEV	BioStar X Device Manager with S/W License (200 users & 1 Max Operators), Intended for customers who primarily use a third-party access control system but wish to manage our devices efficiently
Capacity Upgrades	
BIOSTARX-UP-DOR	Capacity Doors, in multiples of 32, Available to license holders of Essential, Advanced, Enterprise, and Elite tiers
BIOSTARX-UP-USR	Capacity Users, in multiples of 5,000, Available to license holders of Essential, Advanced, Enterprise, and Elite tiers. Device Manager license holders are limited to purchasing User Upgrades only
BIOSTARX-UP-OPR	Capacity Operators, multiples of 10, Available to license holders of Essential, Advanced, Enterprise, and Elite tiers
Feature Add-ons ★Available for individual purchase and applicable to Advanced, Enterprise, and Elite license	
BIOSTARX-ADD-MCS-BAS	BioStar X Multi Comm Server Init, Include 1 communication server, Support up to 1,000 readers
BIOSTARX-ADD-MCS-ADD	BioStar X Multi Comm Server Add-on, Adds 1 additional server, Extends reader capacity by 1,000 per add-on
BIOSTARX-ADD-GIS	BioStar X GIS Map, Areas can be configured using the GIS map
BIOSTARX-ADD-VID	Issued by per camera BioStar X Video, Required when integrating third-party VMS (not Suprema-supplied), Supports up to 1,000 integrated cameras per site
BIOSTARX-ADD-SVM	BioStar X Server Matching, Server Matching method compares the entered ID, card, fingerprint, IR face from the device to the credentials stored inside the server database
BIOSTARX-ADD-VST	BioStar X Visitor, Allowing administrators and operators to track and control visitor access
BIOSTARX-ADD-DIR	BioStar X Directory Integration

BIOSTARX-ADD-RCL	BioStar X Roll Call
Feature Add-ons ☆Available for individual purchase and applicable to all Base License☆	
BIOSTARX-ADD-MOB	BioStar X Mobile App *If external access to BioStar X server is not available, Remote Access (BIOSTARX-ADD-RAC) feature can be used together.
BIOSTARX-ADD-EVTAPI	BioStar X Event Log API, Enables the system to receive and record event logs through an external API. Direct insertion of event data from third-party applications or services for centralized logging and reporting
BIOSTARX-ADD-RAC	BioStar X Remote Access, Secure tunnel that allows the users to access BioStar X server from an external network **billed annually; required for 'Send Face Mobile Enrollment Link'; does not support video integration monitoring
BIOSTARX-ADD-PLG	BioStar X Plugin, Enables support for external plugin integration, Supports up to 10 custom plugins per system
BIOSTARX-ADD-TNA-STD	BioStar X T&A Standard, Up to 500 users
BIOSTARX-ADD-TNA-ENT	BioStar X T&A Enterprise, Unlimited users
Package	
BIOSTARX-PKG-AAC	A package of advanced access control features: Global APB, Global Fire Alarm, Intrusion Alarm, Mustering, Occupancy Limit, Elevator Control, and Interlock
Device License	
QR-LICENSE	Camera QR per device Supported Models (X-Station2 without sensor for QR reading, BioStation3)
WLOCK UZ LICENSE	Wireless Lock per device Supported Model (CoreStation 40)