

Potentiometer (POT)



Serial Print

- +Serial.begin(baud rate)
- +Serial.print(value)
- +Serial.println(*value*)

+Used to get sensor data from arduino

Analog Read & Write


+analogRead(): value ranges from 0-1023

+analogWrite(): value ranges from 0-255

RGB LED





Potentiometer Connection



- +Middle node to analog input of arduino (eg: A0, A1, A3)
- +One of side node to +5V
- +Another side node to GND

Use potentiometer values for LED





Happy Electronics!

+