
# **HA Configuration:**

After you install a Cisco ISE node, all the default services provided by the Administration, Policy Service, and Monitoring personas run on it. This node will be in a standalone state. You must log in to the Admin portal of the Cisco ISE node to configure it. You cannot edit the personas or services of a standalone Cisco ISE node. You can, however, edit the personas and services of the primary and secondary Cisco ISE nodes. You must first configure primary ISE node and then register secondary ISE nodes to the primary ISE node. HA is based on Persona, not node.

### **Deployment Prerequisites:**


All ISE nodes must be on the same version and patch number. The primary ISE Node must not be in standalone mode. We must know the admin username/password of the new node. Each node must be able to resolve the hostname of every other node in DNS. E.g. ISE1 must be able to resolve ISE2, and the other way around. The primary ISE node must trust system certificate being presented by the new node. Create DNS Entries for ISE1 & ISE2, including reverse lookup.




ISE1 FQDN	ise1.test.local
ISE2 FQDN	ise2.test.local
ISE1 IP Address	192.168.100.210
ISE2 IP Address	192.168.100.220
ISE1 and ISE2 Username/Password	Admin/Abc@12345
ISE1	Primary
ISE2	Secondary

#### **Configure Primary PAN:**

To set up distributed deployment, you must first configure a Cisco ISE node as Primary PAN. Choose Administration > System > Deployment. The Register button will be disabled initially. To enable this button, you must configure a Primary PAN.




Check the check box next to the current node, and click Edit. Click Make Primary to configure your Primary PAN. Click Save to save the node configuration.




#### Register Secondary ISE Node:

You can register ISE nodes to Primary PAN to form a multi-node deployment. Nodes in a deployment other than the Primary PAN are referred to as secondary nodes. While registering a node, you can select the personas and services that must be enabled on the node. Registered nodes can be managed from the Primary PAN such as managing the node personas, services, certificates, licenses, applying patches, and so on.

Log in to the Primary PAN. Choose Administration > System > Deployment. Click Register to initiate registration of a secondary node.



Enter the DNS-resolvable fully qualified domain name (FQDN) of the standalone node that you are going to register. The FQDN of the Primary PAN and the node being registered must be resolvable from each other. Enter the UI-based administrator credentials for the secondary node in the Username and Password fields.



If the node uses a self-signed certificate that is not trusted, a certificate warning message is displayed is displays with details about the certificate (such as, Issued-to, Issued-by, Serial number, and so on), which can be verified against the actual certificate on the node. You can select the Import Certificate and Proceed option to trust this certificate and proceed with registration.



## Warning

The node you are trying to register uses a self-signed certificate which is not trusted. Are you sure you want to trust this certificate and proceed with registration?

If you are unsure, please click 'Cancel Registration'. Manually import relevant certificate chain of Node that is being registered into 'Trusted Certificates' and ensure 'Trust within ISE' checkbox is selected.

Please note that this certificate will by default be trusted only for authentication within ISE. If the same certificate needs to be used for other purposes (e.g. client authentication and syslog), please enable those options by editing the certificate under the 'Trusted Certificates' page.

Serial Number: 60 EE E0 25 00 00 00 00 C1 19 D1 91 AB 4D 08 EF

Issued to : CN=ise2.test.local Issued by : CN=ise2.test.local

Issued On: Wed Jul 14 13:01:25 UTC 2021 Expires On: Mon Jul 13 13:01:25 UTC 2026 Signature Algorithm: SHA384withRSA

SHA-256 Fingerprint: 4B 2E 29 7C F3 D9 CF CE FC C9 7E AE 86 E1 1B 51 E9 85 B8 00 A9 D8 27 2F 22 64 DC 17

8A 50 C4 91


SHA-1 Fingerprint: E2 F3 77 6F 7A 74 D4 6C 71 FC 42 FB 78 A2 2A AC 75 7D 4D AC

MD5 Fingerprint: FC A8 E9 C3 68 2A BA 75 EE 98 0C BB FF 96 84 16


Cancel Registration

**Import Certificate and Proceed** 

#### Select the personas and services to be enabled on the node, and then click Submit



Information message popup, Node was registered successfully. Click OK.



Registration process after registration, new node is being synchronized with deployment. It will take several minutes.

#### **Deployment Nodes** / Edit Register Deregister Syncup Node Status Hostname Role(s) Services Personas ise1 Administration, Monitoring, Policy Service, pxGrid PRI(A), PRI(M) SESSION, PROFILER ise2 SESSION, PROFILER Administration, Monitoring, Policy Service SEC(A), SEC(M) In Progress

Registration process synchronization is done when status on both nodes is Connected.

**Deployment Nodes** 

