

DMSDK

Part 1: Development Toolkit Composition

Windows x64 (Windows 10+) Linux x64 (Ubuntu 22.04+)	
C++ ToolKit	C++ ToolKit
C ToolKit	C ToolKit
C# ToolKit	C# ToolKit
C/C++ platform toolset: CMake (v3.8+)/C++11 Visual Studio 2022	C/C++ platform toolset: CMake (v3.8+)/C++11 gcc (v11.4.0)
C# Framework: .NET 8.0 (Long-Term Support)	C# Framework: .NET 8.0 (Long-Term Support)
Character set: Unicode	Character set: ASCII
<i>C# Toolkit</i> Based on the corresponding system <i>C Toolkit</i> , Unsecured code needs to be enabled.	

2. Toolkit Support Scope

Modules: VD641/VD641N/VD641NT/ZE1920/ZE1920N/ZE1920NT

Models: DM30/DM30H/DM80

Three: Tool package calling method

All languages are executed asynchronously to better adapt to the development of various front-end application software.

C language uses callback functions.

C++ uses a notification interface approach.

C# uses asynchronous delegates.

Tip: C# delegates are asynchronous delegates. The context of this delegate comes from the internal C language library's multithreading.

For the program context, please switch by executing ``Dispatcher.Invoke() => {...main interface thread...}``

Change context

4: Functionality

CreateDMControlDriver		
Input parameters		
DWORD ModelType		
Parameter name	Default value	Remark
ModelType	_MODEL_ANY	_MODEL_DM30 _MODEL_DM30H _MODEL_DM80
Return value: PVOID		
Create a device control driver interface instance		
The return value is the handle of the interface instance, which serves as the first input parameter of the function.		
Suitable for C-style calling conventions that do not require notification interface support.		

CreateDMControlDriverEx		
Input parameters		
PVOID pDriverEvent,DWORD ModelType,DWORD ModuleType		
The default value for the parameter name is pDriverEvent.		Remark
		Inheriting IDMDeviceEvent pointer to the implementation class of the interface
ModelType	_MODEL_ANY	_MODEL_DM30 _MODEL_DM30H _MODEL_DM80
ModuleType	_MODULE_VD641NT _MODULE_ZE1920NT	Supports temperature measurement on all networks by default. Module
Return value: PVOID		
Create a device control driver interface instance		
The return value is the handle of the interface instance, which serves as the first input parameter of the function.		
Applicable to C++ language-style calling methods that require notification interface support.		

DestoryDMControlDriver		
Input parameters		
PVOID pDriverHandle		
The parameter name defaults to	pDriverHandle.	Remark
Return value: VOID		Interface instance handle
Release device control driver interface example		

OpenDevice		
Input parameters		
PVOID pDriverHandle, pLoginCallBack, pLogoutCallBack, LPCTSTR pCameraAddress, WORD CameraPort, LPCTSTR pUserName, LPCTSTR pPassWord, PVOID pContext		
The default value for the parameter name is		Remark
pDriverHandle.		Interface instance handle For the C++ version of the function... y. This parameter does not exist, and will not be repeated below. Repeated explanation
pLoginCallBack		callback function
pLogoutCallBack		callback function
pCameraAddress		Device IP
CameraPort		Device Port
pUserName		Device login username
pPassWord		Device login user password
pContext		Callback notification with parameters
Return value: BOOL		
Initialize and open the connection with the device.		

CloseDevice		
Input parameters		
PVOID pDriverHandle		
The parameter name defaults to	pDriverHandle.	Remark
Return value: BOOL		Interface instance handle
Log out and disconnect from the device		

SetZeroAdjust		
Input parameters		
PVOID pDriverHandle, _MV_ADJUST_TYPE AdjustType = ADJUST_MIST		
Parameter	Default value	Remark
name pDriverHandle		Interface instance handle
AdjustType	ADJUST_MIST	Default: Manual click action Optional: Automatic mode (short/medium/long/off)
Return value: BOOL		
Set infrared zeroing		

SetPreset		
Input parameters		
PVOID pDriverHandle, DWORD PresetID		
The default value for the parameter name is		Remark
pDriverHandle.		Interface instance handle
PresetID		Preset bit ID (1~255)
Return value: BOOL		
Set preset position		

DelPreset		
Input parameters		
PVOID pDriverHandle, DWORD PresetID		
The default value for the parameter name is		Remark
pDriverHandle.		Interface instance handle
PresetID		Preset bit ID (1~255)
Return value: BOOL		
Delete preset position		

CallPreset		
Input parameters		
PVOID pDriverHandle, DWORD PresetID		
The default value for the parameter name is		Remark
pDriverHandle.		Interface instance handle
PresetID		Preset bit ID (1~255)
Return value: BOOL		
Call preset bit		

SetImagePalette		
Input parameters		
PVOID pDriverHandle, DWORD PaletteID		
The default value for the parameter name is		Remark
pDriverHandle.		Interface instance handle
PaletteID		Palette ID (0~13)
Return value: BOOL		
Set the color palette		

SetOSDEnable		
Input parameters		
PVOID pDriverHandle, _STREAM_TYPE StreamChannelType, BOOL bEnable, DWORD OSDTypeMask		
The default value for the parameter name is pDriverHandle.		Remark
		Interface instance handle
StreamChannelType		Flow channel type STREAM_IR STREAM_CCD STREAM_MSX
bEnable		OSD Enable
OSDTypeMask		OSD type combination
Return Value: BOOL		
Enable OSD		

SetOSDContext		
Input parameters		
PVOID pDriverHandle, _STREAM_TYPE StreamChannelType, LPCTSTR pOSDContext, WORD x, WORD y, DWORD OSDType		
Parameter	Default value	Remark
name pDriverHandle		Interface instance handle
StreamChannelType		Flow channel type STREAM_IR STREAM_CCD STREAM_MSX
pOSDContext		OSD Content
x		OSD displays coordinates X
y		OSD displays coordinates Y
OSDType		OSD type OSD_CHANNEL OSD_CUSTOM OSD_DATETIME
Return value: BOOL		
Configure OSD content		

SetImageEnhance		
Input parameters		
PVOID pDriverHandle, _STREAM_TYPE StreamChannelType, DWORD EnhanceType, BOOL bAutoMode, BYTE Value		
Parameter name, default value, and remarks		
pDriverHandle Stream		Interface instance handle
StreamChannelType Channel Type		STREAM_IR STREAM_CCD STREAM_MSX
EnhanceType		_IMAGE_ENHANCEFILTER
bAutoMode		automatic
Value		Enhancement value
(Return Value): BOOL		
To set image enhancement, use DDE, which stands for _IMAGE_ENHANCEFILTER.IR_ENHANCE.		

SetUartEx		
Input parameters		
PVOID pDriverHandle, DWORD BaudRate, BYTE DataBits, BYTE StopBits, BYTE Parity		
Parameter	Default value	Remark
name pDriverHandle		Interface instance handle
BaudRate	CBR_9600	baud rate
DataBits	8	Data bits
StopBits	ONESTOPBIT	Stop bit ONESTOPBIT ONE5STOPBITS TWOSTOPBITS
Parity	NOPARITY	Validation type NOPARITY ODDPARITY EVENPARITY MARKPARITY SPACEPARITY
Return value: BOOL		
Configure UartEx		

SetMeasureRange		
Input parameters		
PVOID pDriverHandle, , WORD RangeType		
The default value for the parameter name is pDriverHandle.		Remark
		Interface instance handle
RangeType		0: Normal temperature setting, 1: High temperature setting 4: Ultra-high temperature setting
Return value: BOOL		
Set temperature measurement level		

SetMeasureParam		
Input parameters		
PVOID pDriverHandle, BOOL bCelsiusUnit, SHORT ReviseTemp100, SHORT SurroundTemp, WORD AimHimidity, WORD AimDistance, WORD FPara100, DWORD CrossOSDType, DWORD TempOSDType		
Parameter	Default value	Remark
name pDriverHandle		Interface instance handle
bCelsiusUnit	TRUE	Celsius temperature unit
ReviseTemp100	0	Temperature measurement correction temperature * 100
SurroundTemp	25	Ambient temperature
AimHimidity	60	Ambient humidity
AimDistance	200	Temperature measurement distance (cm)
FPara100	97	Emissivity*100
CrossOSDType	MOSD_CROSS_HIGH	MOSD_CROSS_NULL MOSD_CROSS_HIGH MOSD_CROSS_LOW
TempOSDType	MOSD_TEMP_TRACK	MOSD_TEMP_NULL MOSD_TEMP_TRACK MOSD_TEMP_ARRAY
Return value: BOOL		
Set temperature measurement parameters		

DelAllMeasure		
Input parameters		
PVOID pDriverHandle		
The parameter name defaults to		Remark
pDriverHandle. Return		Interface instance handle
value: BOOL		
Delete all temperature measurement types		

SetPointMeasure/SetPointMeasureEx		
Input parameters		
PVOID pDriverHandle, DWORD Index, BOOL bEnable, WORD x, WORD y		
Parameter name, default value, and remarks.		
pDriverHandle Temperature		Interface instance handle
Index, Measurement Point Number		
bEnable, Measurement Point Enable		
X,y the temperature measurement point		
FPara100		Emissivity*100
AimDistance Return		Temperature measurement distance
value: BOOL		
Set point temperature measurement rules When setting temperature measurement rules in the SDK, the sensor resolution and image encoding resolution are required for temperature measurement coordinates. Therefore, before setting temperature measurement rules (except for canceling temperature measurement), it is necessary to ensure that the rules have been executed. QueryDeviceSensor and QueryVideoEncoderParam. (The same applies to line/area temperature measurement below.) The Ex version allows setting the emissivity and temperature measurement distance.		

SetLineMeasure/SetLineMeasureEx		
Input parameters		
PVOID pDriverHandle, DWORD Index, BOOL bEnable, WORD x1, WORD y1, WORD x2, WORD y2		
Parameter	Default value notes	
name pDriverHandle		Interface instance handle
Index,		Temperature measuring line serial number
bEnable,		Temperature sensor wire enable
x1,y1,x2,y2		Temperature measurement line coordinates
FPara100		Emissivity*100
AimDistance		Temperature measurement distance
Return value: BOOL		
Set line temperature measurement rules		

SetAreaMeasure/SetAreaMeasureEx		
Input parameters		
PVOID pDriverHandle, DWORD Index, BOOL bEnable, WORD left, WORD top, WORD right, WORD bottom		
Parameter name, default value, and remarks.		
pDriverHandle Temperature		Interface instance handle
Index, Measurement Zone Number		
bEnable Temperature Measurement Zone Enable		
Left, top, right, bottom emissivity * 100		
FPara100		
AimDistance		Temperature measurement distance
Return value: BOOL		
Set area temperature measurement rules		

SetAreaPolygonPosMeasureEx		
SetAreaPolygonRatMeasureEx		
Input parameters		
PVOID pDriverHandle, DWORD Index, BOOL bEnable, WORD XYCounts, _ScreenPixPos_XY PosXY[], WORD FPara100, WORD AimDistance		
PVOID pDriverHandle, DWORD Index, BOOL bEnable, WORD XYCounts, _ScreenRatPos_XY RatXY[], WORD FPara100, WORD AimDistance		
Parameter name, default value, and remarks.		
pDriverHandle Temperature		Interface instance handle
Index, Measurement Zone Number		
bEnable Temperature Measurement Zone Enable		
XYCounts		Number of regional waypoints
_ScreenPixPos_XY PosXY[]		Path point pixel coordinate array
_ScreenRatPos_XY RatXY[]		Path point scale coordinate array
FPara100		Emissivity*100
AimDistance Return		Temperature measurement distance
value: BOOL		
Configure polygon temperature measurement rules (based on pixel coordinates and based on full-screen ratio).		

Call_Reboot		
Input parameters		
PVOID pDriverHandle		
The parameter name defaults to	pDriverHandle.	Remark
Return value: BOOL		Interface instance handle
Control restart device		

Call_Ptz_Reset		
Input parameters		
PVOID pDriverHandle		
The parameter name defaults to	pDriverHandle.	Remark
Return value: BOOL		Interface instance handle
Control reset pan-tilt unit		

Call_Ptz_Stop		
Input parameters		
PVOID pDriverHandle		
The parameter name defaults to	pDriverHandle.	Remark
Return value: BOOL		Interface instance handle
Control the PTZ to stop		

Call_PTZ_Angle		
Input parameters		
PVOID pDriverHandle,WORD HAnagelX100, INT VAnagelX100		
Parameter	Default value	Remark
name pDriverHandle		Interface instance handle
HAnagelX100		Azimuth angle X100
VAnagelX100		Pitch angle x100
Return Value: BOOL		
Control the angle of the gimbal		

Call_Ptz_UpLeft Call_Ptz_TiltUp Call_Ptz_UpRight		
Call_Ptz_PanLeft Call_Ptz_PanRight		
Call_Ptz_DownLeft Call_Ptz_TiltDown Call_Ptz_DownRight		
Input parameters		
PVOID pDriverHandle,DWORD Speed		
The default value for the parameter name is		Remark
pDriverHandle.		Interface instance handle
Speed	0xFFFFFFFF	top speed
Return value: BOOL		
Controls the gimbal's movement in eight directions (diagonal movement is not supported by all models).		

Call_Focus_Auto		
Input parameters		
PVOID pDriverHandle,DWORD Speed, _CAMERA_TYPE CameraType		
Parameter name notes	Default value	
pDriverHandle		Interface instance handle
Speed Maximum Speed	0xFFFFFFFF	
CameraType Controls the prepared camera by default.	CAMERA_IR	CAMERA_IR CAMERA_CCD
Return value: BOOL		
Control autofocus		

Call_Focus_Near / Call_Focus_Far		
Input parameters		
PVOID pDriverHandle,DWORD Speed, _CAMERA_TYPE CameraType		
Parameter name notes	Default value	
pDriverHandle		Interface instance handle
Speed Maximum Speed	0xFFFFFFFF	
CameraType Controls the prepared camera by default.	CAMERA_IR	CAMERA_IR CAMERA_CCD
Return value: BOOL		
Control focus +/-		

Call_Zoom_Stop		
Input parameters		
PVOID pDriverHandle,_CAMERA_TYPE CameraType		
Parameter name, default value, and remarks.		
pDriverHandle controls		Interface instance handle
CameraType the infrared camera by default.		CAMERA_IR CAMERA_CCD
Return value: BOOL		
Control zoom stop		

Call_Focus_Stop		
Input parameters		
PVOID pDriverHandle,_CAMERA_TYPE CameraType		
Parameter name, default value, and remarks.		
pDriverHandle controls		Interface instance handle
CameraType the infrared camera by default.		CAMERA_IR CAMERA_CCD
Return value: BOOL		
Control focus stop		

Call_Zoom_In / Call_Zoom_Out		
Input parameters		
PVOID pDriverHandle,DWORD Speed,_CAMERA_TYPE CameraType		
Parameter name notes	Default value	
pDriverHandle Maximum		Interface instance handle
Speed Speed	0xFFFFFFFF	
CameraType the infrared camera by default.	CAMERA_IR	CAMERA_IR CAMERA_CCD
Return value: BOOL		
Control the multiplication factor +-.		

5: Query Functions

QueryDeviceSN		
Input parameters		
PVOID pDriverHandle,pDeviceSNCallBack, PVOID pContext		
Parameter names default to pDriverHandle,		Remark
pDeviceSNCallBack, and		Interface instance handle
pContext. Return value: BOOL		Query callback
	NULL	Query callback with parameters
Query device SN		

QueryDeviceName		
Input parameters		
PVOID pDriverHandle,pDeviceNameCallBack,PVOID pContext		
The default values for the parameter names are		Remark
pDriverHandle and		Interface instance handle
pDeviceNameCallBack.		Query callback
pContext Return	NULL	Query callback with parameters
value: BOOL		
Query device name		

QueryDeviceModel		
Input parameters		
The parameters PVOID pDriverHandle, pDeviceModelCallBack, and PVOID pContext are used. The default		
values for these parameters are pDriverHandle,		Remark
pDeviceModelCallBack,		Interface instance handle
and pContext. The return value is BOOL.		Query callback
	NULL	Query callback with parameters
Query device model		

QueryDeviceModule		
Input parameters		
PVOID pDriverHandle, pDeviceModuleCallBack, PVOID pContext Parameter names Default values Remarks		
pDriverHandle query		Interface instance handle
pDeviceModuleCallBack query callback		
pContext Return	with parameters	
value: BOOL		
Query device module		

QueryDeviceSensor		
Input parameters		
The parameters PVOID pDriverHandle, pDeviceSensorCallBack, and PVOID pContext have default values of		
pDriverHandle, pDeviceSensorCallBack, and pContext. The		Remark
return value is BOOL.		Interface instance handle
		Query callback
	NULL	Query callback with parameters
Query sensor information		

QueryDeviceFirmWare		
Input parameters		
The parameters PVOID pDriverHandle, pDeviceFirmWareCallBack, and PVOID pContext are default values for		
pDriverHandle and pDeviceFirmWareCallBack.		Remark
		Interface instance handle
		Query callback
pContext Return	NULL	Query callback with parameters
value: BOOL		
Query firmware information		

QueryDeviceState		
Input parameters		
The parameters PVOID pDriverHandle, pDeviceStateCallBack, and PVOID pContext are used. The		
default values for these parameters are	pDriverHandle,	Remark
pDeviceStateCallBack,		Interface instance handle
and pContext. The return value is		Query callback
BOOL.	NULL	Query callback with parameters
Query device status		

QueryDeviceAbility		
Input parameters		
The parameters PVOID pDriverHandle, pDeviceAbilityCallBack, and PVOID pContext		
have default values of	pDriverHandle,	Remark
pDeviceAbilityCallBack,		Interface instance handle
and pContext. The return value		Query callback
is BOOL.	NULL	Query callback with parameters
Query device capability set		

QueryNetWorkBasicParam		
Input parameters		
The parameters PVOID pDriverHandle, pNetWorkBasicParamCallBack, and PVOID		
pContext are default values for:	pDriverHandle,	Remark
		Interface instance handle
pNetWorkBasicParamCallBack, and		Query callback
pContext.	NULL	Query callback with parameters
Return value: BOOL		
Query device network basic parameters		

QueryNetWorkExtParam		
Input parameters		
The parameters PVOID pDriverHandle, pNetWorkExtParamCallBack, and PVOID pContext have default values of		
pDriverHandle, pNetWorkExtParamCallBack, and	pContext. The	Remark
return value is BOOL.		Interface instance handle
		Query callback
	NULL	Query callback with parameters
Query device network extension parameters		

QueryNetWorkWifiParam		
Input parameters		
The parameters PVOID pDriverHandle, pNetWorkWifiParamCallBack, and PVOID pContext have default values of		
pDriverHandle, pNetWorkWifiParamCallBack, and	pContext. The	Remark
return value is BOOL.		Interface instance handle
		Query callback
	NULL	Query callback with parameters
Query device network WIFI parameters		

QueryNetWorkFtpParam		
Input parameters		
PVOID pDriverHandle, pNetWorkFtpParamCallBack, PVOID pContext Parameter names Default values Remarks		
pDriverHandle query		Interface instance handle
pNetWorkFtpParamCallBack query callback		
pContext Return	with NULL parameters	
value: BOOL		
Query device network FTP parameters		

QueryNetWorkSntpParam		
Input parameters		
PVOID pDriverHandle, pNetWorkSntpParamCallBack, PVOID pContext Parameter names Default values Remarks		
pDriverHandle query		Interface instance handle
pNetWorkSntpParamCallBack Query callback		
pContext	with parameters	
Return value: BOOL		
Query device network SMTP parameters		

QueryNetWorkHttpsParam		
Input parameters		
PVOID pDriverHandle, pNetWorkHttpsParamCallBack, PVOID pContext Parameter names Default values Remarks		
pDriverHandle query		Interface instance handle
pNetWorkHttpsParamCallBack query callback		
pContext	with parameters	
Return value: BOOL		
Query device network HTTP parameters		

QueryNetWorkOnvifParam		
Input parameters		
PVOID pDriverHandle, pNetWorkOnvifParamCallBack, PVOID pContext Parameter names Default values Remarks		
pDriverHandle query		Interface instance handle
pNetWorkOnvifParamCallBack Query callback		
pContext	with parameters	
Return value: BOOL		
Query device network ONVIF parameters		

QueryNetWorkGB28181Param		
Input parameters		
PVOID pDriverHandle, pNetWorkGB28181ParamCallBack, PVOID pContext Parameter names Default values		
Remarks		
pDriverHandle query		Interface instance handle
pNetWorkGB28181ParamCallBack Query callback		
pContext number	with parameters NULL	
Return value: BOOL		
Query device network GB28181 basic parameters		

QueryNetWorkGB28181State		
Input parameters		
PVOID pDriverHandle, pNetWorkGB28181StateCallBack, PVOID pContext Parameter names Default values		
Remarks		
pDriverHandle query		Interface instance handle
pNetWorkGB28181StateCallBack Query Callback		
pContext number	with Parameters NULL	
Return value: BOOL		
Query device network GB28181 status parameters		

QueryNetWorkGB28181DVID		
Input parameters		
PVOID pDriverHandle, pNetWorkGB28181DVIDCallBack, PVOID pContext Parameter names Default values		
Remarks		
pDriverHandle query		Interface instance handle
pNetWorkGB28181DVIDCallBack Query callback		
pContext number	with parameters NULL	
Return value: BOOL		
Query device network GB28181 video device parameters		

QueryTimeParam		
Input parameters		
PVOID pDriverHandle, pTimeParamCallBack, PVOID pContext Parameter names: pDriverHandle,		
	Default value notes	
pTimeParamCallBack,		Interface instance handle
pContext Return value: BOOL		Query callback
	NULL	Query callback with parameters
Query device time basic parameters		

QueryTimeNtp		
Input parameters		
PVOID pDriverHandle, pTimeNtpCallBack, PVOID pContext Parameter names: pDriverHandle,		
	Default value notes	
pTimeNtpCallBack,		Interface instance handle
pContext Return value: BOOL		Query callback
	NULL	Query callback with parameters
Query device time synchronization parameters		

QueryImageBasicParam		
Input parameters		
PVOID pDriverHandle, pImageBasicParamCallBack, _STREAM_TYPE StreamChannelType, PVOID pContext Parameter name Default		
value Remarks		
pDriverHandle query		Interface instance handle
pImageBasicParamCallBack		
StreamChannelType	STREAM_IR Infrared Stream	STREAM_IR STREAM_CCD STREAM_MSX STREAM_RAW
pContext	NULL	Query callback with parameters number
Return value: BOOL		
Query image basic parameters		

QueryImageEnhanceParam		
Input parameters		
PVOID pDriverHandle,plImageEnhanceParamCallBack, _STREAM_TYPE StreamChannelType, PVOID pContext Parameter name		
Default value Remarks		
pDriverHandle query		Interface instance handle
plImageEnhanceParamCallBack		
StreamChannelType	STREAM_IR Infrared Stream	STREAM_IR STREAM_CCD STREAM_MSX STREAM_RAW
pContext	NULL	Query callback with parameters number
Return value: BOOL		
Query image enhancement parameters		

QueryRtspStreamAddress		
Input parameters		
PVOID pDriverHandle,pRtspStreamAddressCallBack, _STREAM_TYPE StreamChannelType, BOOL bSubStream, PVOID pContext Parameter names Default		
values Remarks		
pDriverHandle query		Interface instance handle
pRtspStreamAddressCallBack		
StreamChannelType	STREAM_IR Infrared Stream	STREAM_IR STREAM_CCD STREAM_MSX STREAM_RAW
bSubStream	FALSE	Default main stream
pContext	NULL	Query callback with parameters number
Return value: BOOL		
Query the RTSP real-time bitrate address of the video.		

QueryHttpStreamAddress		
Input parameters		
PVOID pDriverHandle,pHttpStreamAddressCallBack, _STREAM_TYPE StreamChannelType, PVOID pContext Parameter name		
Default value Remarks		
pDriverHandle query		Interface instance handle
pHttpStreamAddressCallBack		
StreamChannelType	STREAM_IR Infrared Stream	STREAM_IR STREAM_CCD STREAM_MSX STREAM_RAW
bSubStream	FALSE	Default main stream
pContext	NULL	Query callback with parameters number
Return value: BOOL		
Query the HTTP (FLV) live stream address of the video.		

QueryVideoEncoderParam		
Input parameters		
PVOID pDriverHandle,pHttpStreamAddressCallBack, _STREAM_TYPE StreamChannelType, PVOID pContext Parameter name		
Default value Remarks		
pDriverHandle query		Interface instance handle
pHttpStreamAddressCallBack		
StreamChannelType	STREAM_IR Infrared Stream	STREAM_IR STREAM_CCD STREAM_MSX STREAM_RAW
bSubStream	FALSE	Default main stream
pContext	NULL	Query callback with parameters number
Return value: BOOL		
Query video encoding parameters		

QueryVideoDefaultOSD		
QueryVideoCustomOSD / QueryVideoDateTimeOSD		
Input parameters		
PVOID pDriverHandle,pVideoDefaultOSDCallBack, _STREAM_TYPE StreamChannelType, PVOID pContext Parameter name		
Default value Remarks		
pDriverHandle query		Interface instance handle
pVideoDefaultOSDCallBack pVideoCustomOSDCallBack pVideoDateTimeOSDCallBack		
StreamChannelType	STREAM_IR Infrared Stream	STREAM_IR STREAM_CCD STREAM_MSX STREAM_RAW
bSubStream	FALSE	Default main stream
pContext	NULL	Query callback with parameters number
Return value: BOOL		
Query the OSD configuration parameters of the video.		

QueryImagePalette		
Input parameters		
PVOID pDriverHandle,pImagePaletteCallBack, PVOID pContext Parameter name pDriverHandle		
	Default value notes	
pImagePaletteCallBack		Interface instance handle
		Query callback
pContext	NULL	Query callback with parameters number
Return value: BOOL		
Query Image Palette		

QueryUartExParam		
Input parameters		
PVOID pDriverHandle,pUartExParamCallBack,PVOID pContext		
	Default value notes	
Parameter name		Interface instance handle
pDriverHandle		Query callback
pUartExParamCallBack pContext	NULL	Query callback with parameters number
Return value: BOOL		
Query serial communication configuration		

QueryPTZAngleParam		
Input parameters		
PVOID pDriverHandle, pPTZAngleParamCallBack,PVOID pContext		
	Default value notes	
Parameter name		Interface instance handle
pDriverHandle		Query callback
pPTZAngleParamCallBack pContext	NULL	Query callback with parameters number
Return value: BOOL		
Query gimbal angle		

QueryLensCtrlParam		
Input parameters		
PVOID pDriverHandle,pLensCtrlParamCallBack, _CAMERA_TYPE CameraType, PVOID pContext		
	Default value notes	
Parameter name		Interface instance handle
pDriverHandle pLensCtrlParamCallBack		Query callback
CameraType	CAMERA_IR Default Infrared Lens	CAMERA_IR CAMERA_CCD
pContext	NULL	Query callback with parameters number
Return value: BOOL		
Query lens control parameters		

QueryPTZPresetList		
Input parameters		
PVOID pDriverHandle, pPTZPresetNumCallBack, pPTZPresetInfoCallBack, pPTZPresetEndCallBack, PVOID pContext Parameter		
name	Default value notes	
pDriverHandle		Interface instance handle
pPTZPresetNumCallBack		Query callback
pPTZPresetInfoCallBack		Query callback
pPTZPresetEndCallBack pContext		Query callback
	NULL	Query callback with parameters number
Return value: BOOL		
Query preset bit set		

QueryMeasureRange		
Input parameters		
PVOID pDriverHandle, pMeasureRangeParamCallBack, PVOID pContext Parameter names Default values Remarks		
pDriverHandle query		Interface instance handle
pMeasureRangeParamCallBack query callback		
pContext with parameters number	NULL	
Return value: BOOL		
Query temperature measurement range parameters		

QueryMeasureParam		
Input parameters		
PVOID pDriverHandle, pMeasureParamCallBack, PVOID pContext Parameter names Default values		
Remarks		
pDriverHandle query		Interface instance handle
pMeasureParamCallBack query callback		
pContext with parameters number	NULL	
Return value: BOOL		
Query temperature measurement parameters (emissivity, etc.)		

QueryPointMeasureParam		
Input parameters		
PVOID pDriverHandle, pPointMeasureParamCallBack, PVOID pContext Parameter		
Name	Default value notes	
pDriverHandle		Interface instance handle
pPointMeasureParamCallBack pContext		Query callback
	NULL	Query callback with parameters number
Return value: BOOL		
Query point temperature measurement rule parameter set		

QueryLineMeasureParam		
Input parameters		
PVOID pDriverHandle, pLineMeasureParamCallBack, PVOID pContext Parameter		
Name	Default value notes	
pDriverHandle		Interface instance handle
pLineMeasureParamCallBack pContext		Query callback
	NULL	Query callback with parameters number
Return value: BOOL		
Query line temperature measurement rule parameter set		

QueryAreaMeasureParam		
Input parameters		
PVOID pDriverHandle, pAreaMeasureParamNumCallBack, pAreaMeasureParamCallBack, pAreaMeasureParamEndCallBack, PVOID pContext Parameter		
name	Default value notes	
pDriverHandle		Interface instance handle
pAreaMeasureParamNumCallBack		Query callback
pAreaMeasureParamCallBack		Query callback
pAreaMeasureParamEndCallBack pContext		Query callback
	NULL	Query callback with parameters number
Return value: BOOL		
Query the set of temperature measurement rule parameters for the area		

QueryThermometryPoint		
Input parameters		
PVOID pDriverHandle, pThermometryPointNumCallBack, pThermometryPointCallBack, pThermometryPointEndCallBack PVOID pContext Parameter		
name	Default value notes	
pDriverHandle		Interface instance handle
pThermometryPointNumCallBack		Query callback
pThermometryPointCallBack		Query callback
pThermometryPointEndCallBack pContext		Query callback
	NULL	Query callback with parameters number
Return value: BOOL		
Query point temperature measurement result set		

QueryThermometryLine		
Input parameters		
PVOID pDriverHandle, pThermometryLineNumCallBack, pThermometryLineMaxCallBack, pThermometryLineAvgCallBack, pThermometryLineMinCallBack, pThermometryLineEndCallBack, PVOID pContext		
	Default value notes	
Parameter name		Interface instance handle
pDriverHandle		Query callback
pThermometryLineNumCallBack		Query callback
pThermometryLineMaxCallBack		Query callback
pThermometryLineAvgCallBack		Query callback
pThermometryLineMinCallBack		Query callback
pThermometryLineEndCallBack pContext	NULL	Query callback with parameters number
Return value: BOOL		
Query line temperature measurement result set		

QueryThermometryArea		
Input parameters		
PVOID pDriverHandle, pThermometryAreaNumCallBack, pThermometryAreaMaxCallBack, pThermometryAreaAvgCallBack, pThermometryAreaMinCallBack, pThermometryAreaEndCallBack, PVOID pContext		
	Default value notes	
Parameter name		Interface instance handle
pDriverHandle		Query callback
pThermometryAreaNumCallBack		Query callback
pThermometryAreaMaxCallBack		Query callback
pThermometryAreaAvgCallBack		Query callback
pThermometryAreaMinCallBack		Query callback
pThermometryAreaEndCallBack pContext	NULL	Query callback with parameters number
Return value: BOOL		
Query the set of temperature measurement results for the region		

QueryMMCStorageParam		
Input parameters		
PVOID pDriverHandle,pMMCStorageParamCallBack, PVOID pContext		
	Default value notes	
Parameter name		Interface instance handle
pDriverHandle		Query callback
pMMCStorageParamCallBack pContext	NULL	Query callback with parameters number
Return value: BOOL		
Query local storage parameters		

QueryNASStorageParam		
Input parameters		
PVOID pDriverHandle,pNASStorageParamCallBack,PVOID pContext		
	Default value notes	
Parameter name		Interface instance handle
pDriverHandle		Query callback
pNASStorageParamCallBack pContext	NULL	Query callback with parameters number
Return value: BOOL		
Query NAS storage parameters		

QueryMediaList		
Input parameters		
PVOID pDriverHandle, pStorageFileNumCallBack, pStorageFileInfoCallBack, pStorageFileEndCallBack, LPCTSTR pStartDateTime, LPCTSTR pEndDateTime, DWORD FirstFileID, _MEDIA_REC_SRC_MediaRecType, _MEDIA_FILE_TYPE_MediaFileType, _MEDIA_ATTRIB_TYPE_AttributeMask,PVOID pContext Parameter name pDriverHandle		
	Default value notes	
pStorageFileNumCallBack		Interface instance handle
pStorageFileInfoCallBack		Query callback
pStorageFileEndCallBack		Query callback
		Query callback

pStartDateTime		Start time
pEndDateTime		End time
FirstFileID	0	Document number
MediaRecType	NAS MEDIA Storage	Media _MEM_MEDIA_ _HDD_MEDIA_ _NAS_MEDIA_
MediaFileType	_PIC_FILE_ file type	_PIC_FILE_ _VIDEO_FILE_
AttributeMask	_ATTRIB_ALARM file	attribute type _ATTRIB_MANUAL _ATTRIB_TIMER _ATTRIB_ALARM _ATTRIB_ALL
pContext	NULL	Query callback with parameters number
Return value: BOOL		
Query media file collection		

DownloadMediaFile		
Input parameters		
PVOID pDriverHandle, pMediaFileDownloadCallBack, LPCTSTR pFilePathName, _STREAM_TYPE StreamChannelType, _MEDIA_REC_SRC_MediaRecType, _MEDIA_FILE_TYPE_MediaFileType, _MEDIA_FORMAT_TYPE_FileFormatType,PVOID pContext parameter name		
	Default value notes	
pDriverHandle		Interface instance handle
pMediaFileDownloadCallBack		Query callback
pFilePathName		File Name
StreamChannelType	STREAM_IR bitstream type	STREAM_IR STREAM_CCD STREAM_MSX STREAM_RAW
MediaRecType	_MEM_MEDIA_ storage	storage medium

		_MEM_MEDIA_ _HDD_MEDIA_ _NAS_MEDIA_
MediaFileType	_PIC_FILE_ file type	_PIC_FILE_ _VIDEO_FILE_
FileFormatType	_JPG_NORMAL file attribute type	_JPG_NORMAL _JPG_RAW_SUFFIX _JPG_GWS_SUFFIX _JPG_GWT_SUFFIX _DLV_NORMAL _FIR_NORMAL _AVI_SUFFIX
pContext	NULL	Query callback with parameters number
Return value: BOOL		
Download media files		

6: Callback Notification Function

pLoginCallBack		
C++ Notification Interface The equivalent of IDMDeviceEvent::OnOnLogin will not be explained again below.		
Input parameters		
LPCTSTR pResponseStr, BOOL bLoginSuccess, PVOID pContext		
Parameter name, default value, and remarks.		
pResponseStr is a		Response content
bLoginSuccess que login success flag.		
pContext callback with parameters number		
Return value: VOID		
Login request response callback		

pLogoutCallBack		
Input parameters		
LPCTSTR pResponseStr, BOOL bLogoutSuccess, PVOID pContext		
Parameter name, default value, and remarks.		
pResponseStr		Response content
bLogoutSuccess	Logout success indicator	
pContext	callback with parameters	
Return value: VOID		
Logout request response callback		

pDeviceSNCallBack		
Input parameters		
LPCTSTR pDeviceSN,PVOID pContext		
Parameter	Default value notes	
name pDeviceSN		Response content
pContext		Query callback with parameters
Return value: VOID		
Device SN query request response callback		

pDeviceNameCallBack		
Input parameters		
LPCTSTR pDeviceName, PVOID pContext		
Parameter name	Default value notes	
pDeviceName		Response content
pContext		Query callback with parameters
Return value: VOID		
Device Name Query Request Response Callback		

pDeviceModelCallBack		
Input parameters		
LPCTSTR pDeviceModelName, PVOID pContext		
Parameter	Default value notes	
name pDeviceModelName		Response content
pContext		Query callback with parameters number
Return value: VOID		
Device model query request response callback		

pDeviceModuleCallBack		
Input parameters		
LPCTSTR pModuleType, _CAMERA_TYPE CameraType, PVOID pContext		
Parameter	Default value notes	
name pModuleType		Module model name
CameraType		Is it an infrared module?
pContext		Query callback with parameters number
Return value: VOID		
Device module model query request response callback		

pDeviceSensorCallBack		
Input parameters		
WORD ResolutionX, WORD ResolutionY, _CAMERA_TYPE CameraType, PVOID pContext		
Parameter name	Default value notes	
ResolutionX, ResolutionY		Sensor resolution
CameraType		Is it an infrared module?
pContext		Query callback with parameters number
Return value: VOID		
Device module sensor information query request response callback		

pDeviceFirmWareCallBack		
Input parameters		
LPCTSTR pFirmWareVer, LPCTSTR pFirmWareDate,PVOID pContext		
Parameter	Default value notes	
names: pFirmWareVer,		Firmware version
pFirmWareDate,		Firmware date
pContext		Query callback with parameters number
Return value: VOID		
Device firmware information query request response callback		

pDeviceStateCallBack		
Input parameters		
BOOL bRecording, BOOL bAlarmActive,PVOID pContext		
Parameter	Default value notes	
name		Media file records
bRecording bAlarmActive		Temperature alarm triggered
pContext		Query callback with parameters number
Return value: VOID		
Device status information query request response callback		

pNetWorkBasicParamCallBack		
Input parameters		
LPCTSTR pIPAddress, LPCTSTR pNetMask, LPCTSTR pGateway, LPCTSTR pMacAddress,PVOID pContext		
Parameter name, default value, and remarks.		
pIPAddress		Device IP address
pNetMask Device IP Mask		
pGateway device gateway		
pMacAddress device MAC address		
pContext callback with parameters		
return value: VOID		
Device network configuration information query request response callback		

pDeviceAbilityCallBack		
Input parameters		
DWORD SupportMask,PVOID pContext		
Parameter name	Default value notes	
SupportMask		Capability set SUPPORT_DISTANCEADJUST SUPPORT_TLUNCH SUPPORT_TDEXT SUPPORT_WIFI SUPPORT_HT10 SUPPORT_GB28181 SUPPORT_DMMEASURE SUPPORT_STORAGE SUPPORT_IMAGE SUPPORT_SHIELD SUPPORT_BLACKBODY SUPPORT_CCD SUPPORT_PTZ SUPPORT_FACEDETECT SUPPORT_CLIENTMEASURE SUPPORT_METARAW SUPPORT_ALLABILITY
pContext		Query callback with parameters
return value: VOID		
Device capability set information query request response callback		

pNetWorkExtParamCallBack		
Input parameters		
LPCTSTR pDNSAddress, LPCTSTR pDNSAddress2, BOOL bDHCPEnable, BOOL bMulticastEnable, PVOID pContext		
Parameter	Default value notes	
name pDNSAddress		DNS
pDNSAddress2		Alternate DNS
bDHCPEnable		DHCP Enable
bMulticastEnable		Broadcast Enable
pContext		Query callback with parameters
return value: VOID		
Device network configuration extended information query request response callback		

pNetWorkWifiParamCallBack		
Input parameters		
LPCTSTR pIPAddress, LPCTSTR pPassWord, LPCTSTR pSSID, BOOL bDHCPEnable, BOOL bWiFiEnable, PVOID pContext		
Parameter name, default value, and remarks		
pIPAddress		WIFI IP
pPassWord		WiFi login password
pSSID		SSID
bDHCPEnable		DHCP Enable
bWiFiEnable		WIFI Enable
pContext		Query callback with parameters
return value: VOID		
Device network configuration extended information query request response callback		

pNetWorkFtpParamCallBack		
Input parameters		
LPCTSTR pFtpServerIP, WORD FtpPort, LPCTSTR pUserName, LPCTSTR pPassWord, LPCTSTR pStoreDirectory, BOOL bAnonymityEnable, BOOL bFTPEnable, PVOID pContext		
Parameter name, default value, and remarks		
pFtpServerIP		FTP-SERVER IP
FTPPort		FTP login password
pUserName		Login username
pPassWord		Login password
pStoreDirectory		Storage path
bAnonymityEnable		Anonymous login enabled
bFTPEnable		FTP Enable
pContext		Query callback with parameters
return value: VOID		
Device FTP service information query request response callback		

pNetWorkSmtpParamCallBack		
Input parameters		
LPCTSTR pSmtpServerIP, WORD SmtpPort, LPCTSTR pUserName, LPCTSTR pPassWord, LPCTSTR pFromAddr, LPCTSTR ReceiptAddr1, LPCTSTR ReceiptAddr2, LPCTSTR ReceiptAddr3, LPCTSTR ReceiptAddr4, BOOL bSSEnable, BOOL bSMTPEnable, PVOID pContext		
Parameter name, default value, and remarks		
pSmtpServerIP		SMTP-SERVER IP
SmtpPort		SMTP login password
pUserName		Login Username
pPassWord		Login password
pFromAddr		Sender address
ReceiptAddr1~4		Recipients 1-4
bSSEnable		SSL Enable
bSMTPEnable		SMTP Enable
pContext		Query callback with parameters
return value: VOID		
Device SMTP service information query request response callback		

pNetWorkGB28181ParamCallBack		
Input parameters		
LPCTSTR pSipServerIP, WORD SipServerPort, LPCTSTR pServerDomain, LPCTSTR pServerSipName, LPCTSTR pDeviceSipName, LPCTSTR pDeviceSipPSW, WORD LocalPort, PVOID pContext		
Parameter name, default value, and remarks		
pSipServerIP		SIP service IP
SipServerPort		SIP service port
pServerDomain		SIP service host
pServerSipName		SIP Service Name
pDeviceSipName		Device address
pDeviceSipPSW		Device password
LocalPort		Local port
pContext		Query callback with parameters
return value: VOID		
Device GB28181 Service Information Query Request Response Callback		

pNetWorkHttpsParamCallBack		
Input parameters		
BOOL bHttpsEnable, PVOID pContext		
Parameter name, default value, and remarks.		
bHttpsEnable query		HTTPS Enable
pContext	callback with parameters	
return value: VOID		
Device HTTPS service information query request response callback		

pNetWorkOnvifParamCallBack		
Input parameters		
WORD AuthType, WORD OnvifPort, BOOL bOnvifEnable, PVOID pContext		
Parameter name, default value, and remarks.		
AuthType		Verification mode
OnvifPort		ONVIF port
bOnvifEnable		ONVIF Enable
pContext		Query callback with parameters
return value: VOID		
Device ONVIF service information query request response callback		

pNetWorkGB28181StateCallBack		
Input parameters		
BOOL bRegisterStatus, WORD SessionExpires, WORD HeartBeatTime, WORD HeartBeatCount, BOOL bGB28181Enable, PVOID pContext		
Parameter	Default value	notes
name bRegisterStatus		Online
SessionExpires		Session timeout
HeartBeatTime		Heart rate interval
HeartBeatCount		Heart rate count
bGB28181Enable		GB28181 Enable
pContext		Query callback with parameters
Return value: BOOL		
Device GB28181 Service Status Inquiry Request Response Callback		

pNetWorkGB28181DVIDCallBack		
Input parameters		
WORD VideoDeviceCounts, LPCTSTR pVideoDeviceSipName[], PVOID pContext		
Parameter name	Default value notes	
VideoDeviceCounts		Number of video devices
pVideoDeviceSipName		Video device name
pContext		Query callback with parameters
Return value: BOOL		
Device GB28181 Associated Video Device Information Query Request Response Callback		

pTimeParamCallBack		
Input parameters		
LPCTSTR pTimeZone, LPCTSTR pLocalTime, LPCTSTR pUpTime PVOID pContext		
Parameter	Default value notes	
names:		Time zone
pTimeZone,		Local time
pLocalTime, pUpTime		Power-on time
pContext		Query callback with parameters
Return value: BOOL		
Device time configuration information query request response callback		

pTimeNtpCallBack		
Input parameters		
LPCTSTR pNtpServerIP, WORD NtpPort, WORD Interval, BOOL bNtpEnable, PVOID pContext		
Parameter	Default value notes	
name pNtpServerIP		Time server IP
NtpPort		Time synchronization server port
Interval		For time interval
bNtpEnable		Enabled by time
pContext		Query callback with parameters
Return value: BOOL		
Device time synchronization configuration information query request response callback		

pImageEnhanceParamCallback		
Input parameters		
_STREAM_TYPE StreamChannelType, DWORD EnhanceType, BOOL bAutoMode, BYTE Value, PVOID pContext		
Parameter name, default value, and remarks.		
StreamChannelType		Stream channel type STREAM_IR STREAM_CCD STREAM_MSX
EnhanceType		Enhancement type (by stream channel type) IR_BRIGHTNESS, IR_GAIN, IR_SHARPNESS, IR_ENHANCE, IR_FILTER, CCD_BRIGHTNESS, CCD_CONTRAST, CCD_HUE, CCD_SATURATION, CCD_WDR,
bAutoMode		Automatic mode
Value		value
pContext		Query callback with parameters
Return value: BOOL		
Image Enhancement Information Query Request Response Callback		

pHttpStreamAddressCallback		
Input parameters		
_STREAM_TYPE StreamChannelType, BOOL bSubStream, LPCTSTR pFLVStreamAddress, PVOID pContext		
pContext		
Parameter name	Default value notes	
StreamChannelType		Stream channel type STREAM_IR STREAM_CCD STREAM_MSX
bSubStream		Sub-stream flag
pFLVStreamAddress pContext		FLV real-time stream address
Return value:		Query callback with parameters
BOOL		
Video FLV real-time bitrate information query request response callback		

pImagePaletteCallBack		
Input parameters		
WORD PaletteID, PVOID pContext		
Parameter name, default value, and remarks.		
PaletteID		Palette number
pContext	lookup callback with parameters	
Return value: BOOL		
Image palette configuration information query request response callback		

pImageBasicParamCallBack		
Input parameters		
_STREAM_TYPE StreamChannelType, LPCTSTR pLanguage, BOOL bMirror, BOOL bFlip, PVOID pContext		
Parameter name	Default value notes	
StreamChannelType		Stream channel type
pLanguage		language
bMirror		Image mirroring
bFlip		Image Flip
pContext		Query callback with parameters
Return value: BOOL		
Image basic information query request response callback		

pLensCtrlParamCallBack		
Input parameters		
BYTE CameraZoom, BOOL bIRCutOn, _CAMERA_TYPE CameraType, PVOID pContext		
Parameter name	Default value notes	
CameraZoom		Current magnification of the lens
bIRCutOn		Current status of the filter
CameraType		Lens type
pContext		Query callback with parameters
Return value: BOOL		
Lens control information query request response callback		

pRtspStreamAddressCallBack		
Input parameters		
_STREAM_TYPE StreamChannelType, BOOL bSubStream, LPCTSTR pRTSPStreamAddress,PVOID pContext		
Parameter name	Default value	notes
StreamChannelType		Stream channel type STREAM_IR STREAM_CCD STREAM_MSX
bSubStream		Sub-stream flag
pRTSPStreamAddress		RTSP real-time stream address
pContext		Query callback with parameters

Return value: BOOL		
Video RTSP real-time bitrate information query request and response callback		
pVideoEncoderParamCallBack		
Input parameters		
_STREAM_TYPE StreamChannelType, BOOL bSubStream, WORD EncodeResolutionX, WORD EncodeResolutionY, WORD EncodeFrameRate, PVOID pContext		
Parameter name	Default value	notes
StreamChannelType		Stream channel type STREAM_IR STREAM_CCD STREAM_MSX
bSubStream		Sub-stream flag
EncodeResolutionX EncodeResolutionY		Encoding resolution
EncodeFrameRate		Frame rate
pContext		Query callback with parameters
Return value: BOOL		
Video encoding information query request response callback		

pVideoDefaultOSDCallBack pVideoCustomOSDCallBack pVideoDateTimeOSDCallBack		
Input parameters		
STREAM_TYPE StreamChannelType, BOOL bSubStream, _MeasurePos_XY PosXY, LPCTSTR pDisplayContent, BOOL bEnable, PVOID pContext		
Parameter name, default value, and remarks.		
StreamChannelType		Stream channel type STREAM_IR STREAM_CCD STREAM_MSX
bSubStream		Sub-stream flag
PosXY		OSD Location
pDisplayContent		OSD Content
bEnable		OSD Enable
pContext		Query callback with parameters
Return value: BOOL		
Video encoding information query request response callback		

pUartExParamCallBack		
Input parameters		
DWORD BaudRate, BYTE DataBits, BYTE StopBits, BYTE Parity, PVOID pContext		
Parameter name	Default value	notes
BaudRate		baud rate
DataBits		Data bits
StopBits		Stop bit
Parity		check
pContext		Query callback with parameters
Return value: BOOL		
Serial port configuration information query request response callback		

pPTZPresetNumCallBack pPTZPresetInfoCallBack pPTZPresetEndCallBack		
Input parameters		
WORD PresetCounts, PVOID pContext		
WORD PresetID, LPCTSTR pPresetName, BOOL bEnable, PVOID pContext		
PVOID pContext		
Parameter name	Default value notes	
PresetCounts		Preset number of positions
PresetID		Preset position number
pPresetName		Preset bit name
bEnable		Preset bit enable
pContext		Query callback with parameters
Return value: BOOL		
Preset set information query request response callback		

pThermometryAreaNumCallBack pThermometryAreaMaxCallBack pThermometryAreaAvgCallBack pThermometryAreaMinCallBack pThermometryAreaEndCallBack		
Input parameters		
WORD LineCounts, PVOID pContext		
WORD PosX, WORD PosY, INT ValueX10, PVOID pContext		
PVOID pContext		
Parameter	Default value notes	
		Temperature measurement with reference wire
name omitted. Return value: VOID		
Temperature measurement area collection information query request response callback		

pThermometryPointNumCallBack pThermometryPointCallBack pThermometryPointEndCallBack		
Input parameters		
WORD PointCounts, PVOID pContext		
WORD PosX, WORD PosY, INT ValueX10, PVOID pContext		
PVOID pContext		
Parameter name	Default value	notes
PointCounts		Number of temperature measurement points
PosX, PosY		Temperature measurement point location
ValueX10		Temperature value * 10
pContext		Query callback with parameters
return value: VOID		
Temperature measurement point set information query request response callback		

pThermometryLineNumCallBack pThermometryLineMaxCallBack pThermometryLineAvgCallBack pThermometryLineMinCallBack pThermometryLineEndCallBack		
Input parameters		
WORD LineCounts, PVOID pContext		
WORD PosX, WORD PosY, INT ValueX10, PVOID pContext		
PVOID pContext		
Parameter name	Default value	notes
LineCounts		Number of temperature measuring wires
PosX, PosY		Temperature measurement line position
ValueX10		Temperature value * 10
pContext		Query callback with parameters
return value: VOID		
Temperature measurement line collection information query request response callback		

pPointMeasureParamCallBack pLineMeasureParamCallBack pAreaMeasureParamNumCallBack pAreaMeasureParamCallBack pAreaMeasureParamEndCallBack		
Input parameters (taking point temperature measurement rule parameters as an example)		
WORD PresetID, WORD Counts, WORD PointIDArray []		
_MeasurePos_XY PosXYArray [], WORD FPara100Array [], WORD AimDistanceArray [],		
PVOID pContext		
parameter name	Default value, remarks, preset	bit ID,
PresetID		number of point
PointCounts		temperature measurement rules,
LineCounts		number of line temperature
XYCounts		measurement rules, number of area
PointIDArray []		temperature measurement rules, point
LineIDArray[]		temperature measurement rule ID, cross-line
AreaID		temperature measurement rule ID,
PosXYArray []		cross-area temperature measurement
FPara100Array []		rule ID, coordinates of temperature
AimDistanceArray[] pContext Return		measurement point, cross-
value: VOID		emissivity x100, cross-temperature measurement distance, cross-query callback with attached parameters.
Callback for the		
response to the query request for temperature measurement points/lines/areas/sets.		

pMMCStorageParamCallBack		
Input parameters		
WORD MMCStatus, LPCTSTR pTotalSize, LPCTSTR pAvailableSize, WORD FullGrade, BOOL bFullAlarmEnable, BOOL bOverWriteEnable, BOOL bStorageEnable, PVOID pContext		
Parameter name, default value, and remarks.		
MMCStatus		Memory status
pTotalSize		Total storage space
pAvailableSize		Effective storage space
FullGrade		Capacity threshold
bOverWriteEnable		Coverage Enable
bStorageEnable		Local storage enabled
pContext		Query callback with parameters
Return value: VOID		
Local storage media information query request response callback		

pNASStorageParamCallBack		
Input parameters		
WORD NASStatus, LPCTSTR pTotalSize, LPCTSTR pAvailableSize, WORD FullGrade, BOOL bFullAlarmEnable, BOOL bOverWriteEnable, BOOL bNASEnable, PVOID pContext		
Parameter name, default value, and remarks.		
NASStatus		Storage space status
pTotalSize		Total storage space
pAvailableSize		Effective storage space
FullGrade		Capacity threshold
bFullAlarmEnable		Full capacity alarm enabled
bOverWriteEnable		Coverage Enable
bNASEnable		NAS storage enabled
pContext		Query callback with parameters
return value: VOID		
NAS storage media information query request response callback		

pStorageFileNumCallBack		
pStorageFileInfoCallBack		
pStorageFileEndCallBack		
Input parameters		
DWORD FileCounts, PVOID pContext		
DWORD FileSizeBytes, LPCTSTR pFileName, PVOID pContext		
PVOID pContext		
Parameter name	Default value	notes
FileCounts		Number of files
FileSizeBytes,		File size (bytes)
pFileName,		File Name
pContext.		Query callback with parameters
Return value: VOID		
Media file collection query request response callback		

pMediaFileDownLoadCallBack		
Input parameters		
_MEDIA_REC_SRC_MediaRecType, _MEDIA_FILE_TYPE_MediaFileType, _MEDIA_FORMAT_TYPE_FileFormatType, _STREAM_TYPE_StreamChannelType, LPCTSTR pFilePathName, DWORD MediaLengthBytes, PVOID pMediaDataBuffer,PVOID pContext		
Parameter name, default value, and remarks.		
MediaRecType		File storage media type
MediaFileType file type		
FileFormatType file format		
StreamChannelType associated with the bitstream channel		
pFilePathName: File name		
MediaLengthBytes is a length (bytes)		
pMediaDataBuffer pointer to the file content cache.		
pContext callback with parameters		
return value: VOID		
Media file download request response callback		