






ROUTER

- It is use to breaks broadcast domain
- It is a layer 3 device
- It is a unicast device
- It contains routing table
- Routing table contains list of route
- It is use to connect different network




Routing table	
10.0.0.0/8 - C0	Directly connected
20.0.0.0/8 - C3	
192.168.1.0/24 - C2	



Console cable


DB9S

USB



Router modes: User / ON

Router > User $\rightarrow$ User Execution mode [Test cmd]
 Router # Privilege mode [view the configuration]
 Router(config)# Global Configuration mode



Hub