


INSTALLATION PROCEDURE:


DATE

DESCRIPTION

- 1. USE THE #8-32 SCREWS TO MOUNT THE LED INDICATOR TO THE HOLES IN THE TOP OF THE DISPLAY.
- 2. CUT OFF THE END OF THE POWER CORD AND STRIP ABOUT 1/2" OF INSULATION FROM THE ENDS OF THE WHITE AND BLACK WIRES.
- 3. ROUTE THE END OF THE WIRES TO THE WIRES ON THE RECEPTACLE ON THE SIDE OF THE DISPLAY. REMOVE THE WIRE NUTS THAT MAKE THESE CONNECTIONS AND ADD THE WIRES FROM THE LIGHT TO THE CONNECTIONS AND SECURE WITH THE WIRE NUTS. BE SURE TO MATCH BLACK TO BLACK AND WHITE.

		DAKTRONIC	CS, INC	. E	BROOKINGS,	SD 5	7006			
	PROJ: TUFF SPORT SCOREBOARDS									
	TITLE: B	INDICATOR INST		INSTALLATIO	N ON	SHOT	CLOCK			
	DES. BY: BPETERSON			BPETERSON	DATE: 03DEC02					
	REVISION	APPR. BY:		1	077 [1	O 4	17	0	$\overline{}$	
APPR.	ا ا	SCALE: 1-6			23/-E1	UΑ	- /	95U	ŏ	





INSTALLATION PROCEDURE:

- 1. DETERMINE MOUNTING LOCATION AND ATTACH MOUNTING CHANNEL WITH #12 SELF DRILLING SCREWS PROVIDED.
- 2. ATTACH THE LED INDICATOR TO THE MOUNTING CHANNEL WITH THE #8 SCREWS PROVIDED.
- 3. ROUTE POWER CORD TO THE SHOT CLOCK OR CONTROL BOX.

NOTE:

IF THIS IS THE 16 VOLT VERSION, PLUG IT INTO THE XLR JACK ON THE SHOT CLOCK OR CONTROL BOX. IF THIS IS THE 120 VOLT VERSION, PLUG IN INTO THE 120 VOLT OUTLET ON THE SHOT CLOCK.

	PROPRIE	ICEPTS EXPRESSED TARY, DO NOT REPI ED WRITTEN CONSEN	RODUCE BY	ANY MEANS,	INCLUDING	ELECTRO	NICALLY W	ITHOUT TH	ŧΕ	
		DAKTRONI	CS, INC	BRO	OKINGS,	SD 5	7006			
	PROJ: TUFF SPORT SCOREBOARDS									
	TITLE: BB-2133, LED INDICATOR INSTALLATION									
	DES. BY: BPETERSON DRAW			N BY: BPETERSON DATE: 4 DE				DEC 0	.C 02	
	REVISION	APPR. BY:		10	77 -	1 \wedge \wedge	1 -	705	$c \cap$	
PR.	00	SCALE: 1=5			37-E	IUA	\ ⁻ /	95	09	

REV. DATE DESCRIPTION BY APPR.

