Robot Vacuum Owner Manual

1. First use

Charge the vacuum on its dock for 4 hours before the first cleaning run. Remove cables and small objects from the floor.

2. Maintenance

Empty the dust bin after every run. Replace the filter every 3 months and the side brushes every 6 months. Wash the mop pad after each use.

3. Error codes

Error 1 means a wheel is stuck. Error 5 means the bumper is blocked. Error 9 means the dust bin is missing or full.