

TechMart Electronics

General User Manual

A general setup and usage guide applicable to most TechMart Electronics devices. Refer to the product-specific manual (included in the box) for detailed instructions.

Unboxing

Check that your package includes: the device, charging cable/adaptor, user guide, and warranty card. Report missing items within 48 hours of delivery.

Initial Setup

1. Charge the device fully before first use. 2. Power on and follow the on-screen setup wizard, if applicable. 3. Connect to Wi-Fi or Bluetooth as required and register the product using the TechMart companion app.

Basic Troubleshooting

- Device not turning on: charge for at least 30 minutes, then retry.
- Device not connecting: restart both the device and your phone/router.
- Overheating: stop use immediately, unplug, and contact support if it persists.

Care Instructions

Avoid exposure to extreme heat, moisture, or direct sunlight for extended periods. Use only original or certified chargers and accessories.