

Components and Functions of a Computer

```
{
  "nodes":[
    {"id":"995920819c602bf8","type":"group","x":-1720,"y":1195,"width":908,"height":819,"label":"Functions of a computer"},
    {
      "id":"4296788b43c2e967",
      "type":"group",
      "styleAttributes":{"border":"invisible"},
      "x":-1748,
      "y":180,
      "width":936,
      "height":700,
      "label":"Structure of a computer"
    },
    {
      "id":"3abc27446545bf00",
      "type":"group",
      "styleAttributes":{"border":"invisible"},
      "x":-2697,
      "y":187,
      "width":750,
      "height":693,
      "label":"Internal Structure of CPU"
    },
    {
      "id":"6c1429ae8d13e743",
      "type":"group",
      "styleAttributes":{"border":"invisible"},
      "x":-400,
      "y":20,
      "width":760,
      "height":580,
      "label":"Types of computers"
    },
    {
      "id":"3c89ba5c6b2766b9",
      "type":"group",
      "styleAttributes":{"border":"invisible"},
      "x":-400,
      "y":880,
      "width":760,
      "height":499,
```

```

"color":"6",
"label":"Structure of a General-Purpose Computer"
},
{
"id":"edb326014036526a",
"type":"text",
"text":"Computers can be built in two ways.",
"styleAttributes":{"textAlign":"center"},
"x":-195,
"y":29,
"width":355,
"height":60
},
{"id":"81ba149cc7d985d4","type":"text","text":"What makes a
computer?","x":-142,"y":-210,"width":250,"height":60,"color":"1"},
{
"id":"4f89206e71954a6d",
"type":"text",
"text":"A computer is made up of electronic devices- building blocks of a computer.",
"styleAttributes":{"
"shape":null,
"border":"invisible"
},
"x":-17,
"y":-166,
"width":282,
"height":124
},
{
"id":"de438ddd5c08f325",
"type":"text",
"text":"#### 1. Specialized Computers\n\nFor every problem, a specific computer is created to
tackle a problem.\n\n> Therefore we cannot use one specialized computer used in one case to
solve a problem of different nature.\n\nBut it works efficiently for the task it was designed to do.
\nFor example, embedded computers in various industries",
"styleAttributes":{},
"x":-370,
"y":160,
"width":350,
"height":420
},
{
"id":"5895df04dec8097d",
"type":"text",
"text":"### Computer Organization",

```

```

"styleAttributes":{
"textAlign":"center",
"border":null
},
"x":-310,
"y":1119,
"width":280,
"height":100,
"color":"2"
},
{
"id":"2bce63a8584c7d9a",
"type":"text",
"text":"## Electronic Devices",
"styleAttributes":{"textAlign":"center","border":"dashed"},
"x":-380,
"y":910,
"width":180,
"height":120
},
{
"id":"dd618b037c148b75",
"type":"text",
"text":"## General Purpose Computer",
"styleAttributes":{"textAlign":"center","border":"dashed"},
"x":-130,
"y":910,
"width":200,
"height":120
},
{
"id":"9437a7e1411d81a2",
"type":"text",
"text":"#### 2. General-Purpose Computers\n\nThe most common type of computers we use today.\n\nWe can use general purpose computers in specific tasks with the use of software that is developed differently for each task.\n> This is the role of Operating System and Application Software.\n\nEssentially, computer do not need to be specialized; only the software needs to be!",
"styleAttributes":{},
"x":-20,
"y":160,
"width":350,
"height":420,
"color":"6"
},
{

```

```
"id": "8cf6c4db7e8ddbb8",
"type": "text",
"text": "",
"styleAttributes": {"border": "invisible"},
"x": 126,
"y": 883,
"width": 60,
"height": 60
},
{
  "id": "4b5dc8dab277e50d",
  "type": "text",
  "text": "## Computer Applications",
  "styleAttributes": {"textAlign": "center", "border": "dashed"},
  "x": 150,
  "y": 910,
  "width": 200,
  "height": 120
},
{
  "id": "ce8936c87147a409",
  "type": "text",
  "text": "Studies the structure and behaviour of a computer and how electronic devices work in tandem with each other to constitute a general purpose computer",
  "styleAttributes": {
    "shape": null,
    "textAlign": null,
    "border": "invisible"
  },
  "x": -390,
  "y": 1219,
  "width": 370,
  "height": 140
},
{
  "id": "b6b17756cf868b79",
  "type": "text",
  "text": "### Operating System & Application Software",
  "styleAttributes": {"textAlign": "center", "border": "dashed"},
  "x": -10,
  "y": 1119,
  "width": 280,
  "height": 100,
  "color": "2"
},
```

```

{
  "id": "776dd7870303826c",
  "type": "text",
  "text": "### Structure of a Computer\n\n>The hierarchical organization of (sub-)components that help build the computer and they work together in relationships\n\n#### 1. CPU (Central Processing Unit)\nControls the operations of the computer and its data processing functions.\n\n#### 2. Memory\nThe storage region of the computer; it has all the data required for operations of the computer. Software programs that run on the computer are also considered part of the data\n\n#### 3. I/O\nInput devices where the system bus receives input data, and output devices where the system bus carries the output data",
  "styleAttributes": {"border": "invisible"},
  "x": -1304,
  "y": 187,
  "width": 484,
  "height": 683
},
{
  "id": "eb7937163e621b61",
  "type": "text",
  "text": "#### System bus\n\nSystem bus is an internal communication pathway that connects all core components of the computer. It carries signals and data between the CPU, memory, and I/O devices, coordinating their interactions.",
  "styleAttributes": {"border": "invisible"},
  "x": -1701,
  "y": 620,
  "width": 397,
  "height": 240
},
{
  "id": "90b455c83b1973b7",
  "type": "text",
  "text": "## Memory",
  "styleAttributes": {"textAlign": "center", "shape": "diamond"},
  "x": -1592,
  "y": 236,
  "width": 147,
  "height": 150
},
{
  "id": "526990343e502ca8",
  "type": "text",
  "text": "## CPU",
  "styleAttributes": {"textAlign": "center", "shape": "diamond"},
  "x": -1701,
  "y": 351,

```

```
"width":149,
"height":150
},
{
"id":"b7694db019392721",
"type":"text",
"text":"## System Bus",
"styleAttributes":{"textAlign":"center",
"shape":"diamond",
"border":null
},
"x":-1481,
"y":351,
"width":150,
"height":150
},
{
"id":"2f970301e5764d4d",
"type":"text",
"text":"## I/O",
"styleAttributes":{"textAlign":"center","shape":"diamond"},
"x":-1586,
"y":459,
"width":135,
"height":139
},
{
"id":"4623ed26baf70fef",
"type":"text",
"text":"Studies the implementation of OS and Application software that allows application of a
computer in specific/specialized tasks",
"styleAttributes":{"shape":null,
"textAlign":"right",
"border":"invisible"
},
"x":-20,
"y":1219,
"width":370,
"height":140
},
{
"id":"80030fd17620711c",
"type":"text",
```

```
"text":"#### Data Processing\n\nThe ability to process many forms of data, images, videos, numbers etc.\n\nThe computer needs to process data to enable the computer to be able to manipulate, modify the data.",
"styleAttributes":{},
"x":-1688,
"y":1315,
"width":414,
"height":326
},
{
  "id":"b663c00ed3d0739c",
  "type":"text",
  "text":"#### Data Movement\n\nStorage without data transfer is useless. So computers need to be able to handle data throughput to and from the input the output devices.\n\nOnly through the interaction with the outside world can computers be applied in real-life.",
  "styleAttributes":{},
  "x":-1688,
  "y":1661,
  "width":414,
  "height":326
},
{
  "id":"e6f73040d124d612",
  "type":"text",
  "text":"#### Data Control\n\nGeneral purpose computers have multiple software as well as multiple I/O devices running and connect at a time. \n\nTherefore, restriction and control of data is important so we keep data secure and separate from each device.",
  "styleAttributes":{},
  "x":-1262,
  "y":1661,
  "width":414,
  "height":326
},
{
  "id":"3faa8b6532693c6e",
  "type":"text",
  "text":"> Basically denotes the collective outcome or the result of the operations that are performed collaboratively by the different components of the computer.",
  "styleAttributes":{"border":"invisible"},
  "x":-1704,
  "y":1215,
  "width":884,
  "height":100
},
{
```

```

"id": "58f08f4c415077e6",
"type": "text",
"text": "#### Data Storage\n\nComputer also needs to store the different types of data for short or long term in memory.\nMost users use computers for storage and retrieval of data in electronic form.",
"styleAttributes": {},
"x": -1262,
"y": 1315,
"width": 414,
"height": 326
},
{
"id": "7364749b7bc615eb",
"type": "text",
"text": "#### 1. Control Unit\nControls the operations of the CPU and therefore the operation of the computer. When a software program executes on a computer, CU orchestrates this entire execution.",
"styleAttributes": {},
"x": -2677,
"y": 210,
"width": 714,
"height": 156
},
{
"id": "9d7f9468ef7ccb76",
"type": "text",
"text": "#### 2. Arithmetic & Logic Unit\nHas circuitry to carry out arithmetic operations and logical operations. Contains some temp registers for temporary storage of data. Also has flags to indicate the nature of the result.",
"styleAttributes": {},
"x": -2677,
"y": 371,
"width": 714,
"height": 158
},
{
"id": "0a2e70ea8ca9dd0f",
"type": "text",
"text": "#### 3. Registers\nCPU requires some internal storage for ALU and CU to store data and operands. This is stored in fixed sized registers. bitlength and total number of registers vary from CPU to CPU",
"styleAttributes": {},
"x": -2678,
"y": 536,
"width": 714,

```



```
"height":155
},
{
  "id":"5d72a8351f77e63c",
  "type":"text",
  "text":"#### 4. Internal Bus\nJust like how system bus allows communication across different main components, the internal bus of the CPU connects the CU, ALU and the registers.",
  "styleAttributes":{},
  "x":-2678,
  "y":701,
  "width":714,
  "height":156
}
],
"edges":[
{
  "id":"6b75d72b4589066d",
  "styleAttributes":{"pathfindingMethod":"direct"},
  "toFloating":false,
  "fromNode":"2bce63a8584c7d9a",
  "fromSide":"right",
  "toNode":"dd618b037c148b75",
  "toSide":"left",
  "color":"6"
},
{
  "id":"c4a9fda0985843b9",
  "styleAttributes":{},
  "toFloating":false,
  "fromNode":"dd618b037c148b75",
  "fromSide":"right",
  "toNode":"4b5dc8dab277e50d",
  "toSide":"left",
  "color":"6"
},
{
  "id":"29acf57b77d54d77",
  "styleAttributes":{},
  "toFloating":false,
  "fromFloating":false,
  "fromNode":"b6b17756cf868b79",
  "fromSide":"top",
  "toNode":"dd618b037c148b75",
  "toSide":"bottom",
  "color":"2"
```

```
},
{
  "id":"bd50360f31f13bc6",
  "styleAttributes":{},
  "toFloating":false,
  "fromFloating":false,
  "fromNode":"b6b17756cf868b79",
  "fromSide":"top",
  "toNode":"4b5dc8dab277e50d",
  "toSide":"bottom",
  "color":"2"
},
{
  "id":"efde287dd3a11941",
  "styleAttributes":{},
  "toFloating":false,
  "fromFloating":false,
  "fromNode":"5895df04dec8097d",
  "fromSide":"top",
  "toNode":"dd618b037c148b75",
  "toSide":"bottom",
  "color":"2"
},
{
  "id":"8cdd64a971cd48c5",
  "styleAttributes":{},
  "toFloating":false,
  "fromFloating":false,
  "fromNode":"5895df04dec8097d",
  "fromSide":"top",
  "toNode":"2bce63a8584c7d9a",
  "toSide":"bottom",
  "color":"2"
},
{
  "id":"e989cf1b6f183672",
  "styleAttributes":{},
  "toFloating":false,
  "fromNode":"edb326014036526a",
  "fromSide":"bottom",
  "toNode":"9437a7e1411d81a2",
  "toSide":"top"
},
{
  "id":"e46dcb286321f94a",
```

```
"styleAttributes":{},
"toFloating":false,
"fromNode":"edb326014036526a",
"fromSide":"bottom",
"toNode":"de438ddd5c08f325",
"toSide":"top"
},
{
  "id":"c477ea2437b23925",
  "styleAttributes":{},
  "toFloating":false,
  "fromFloating":false,
  "fromNode":"9437a7e1411d81a2",
  "fromSide":"bottom",
  "toNode":"8cf6c4db7e8ddbb8",
  "toSide":"top"
},
{
  "id":"01b414967a1c2c1e",
  "styleAttributes":{},
  "toFloating":false,
  "fromNode":"81ba149cc7d985d4",
  "fromSide":"bottom",
  "toNode":"edb326014036526a",
  "toSide":"top"
},
{
  "id":"9e29c750fae1b13c",
  "styleAttributes":{"
    "pathfindingMethod":null
  },
  "toFloating":false,
  "fromNode":"5895df04dec8097d",
  "fromSide":"left",
  "toNode":"776dd7870303826c",
  "toSide":"right"
},
{
  "id":"fe22a8d390746dd6",
  "styleAttributes":{"pathfindingMethod":"square"},
  "toFloating":false,
  "fromFloating":false,
  "fromNode":"526990343e502ca8",
  "fromSide":"right",
  "toNode":"b7694db019392721",
```

```
"toSide":"left",
"fromEnd":"arrow"
},
{
  "id":"8cf700a1ea389222",
  "styleAttributes":{"pathfindingMethod":"square"},
  "toFloating":false,
  "fromNode":"2f970301e5764d4d",
  "fromSide":"right",
  "toNode":"b7694db019392721",
  "toSide":"bottom",
  "fromEnd":"arrow"
},
{
  "id":"c52f2f16688ec5e4",
  "styleAttributes":{"pathfindingMethod":"square"},
  "toFloating":false,
  "fromFloating":false,
  "fromNode":"90b455c83b1973b7",
  "fromSide":"right",
  "toNode":"b7694db019392721",
  "toSide":"top",
  "fromEnd":"arrow"
},
{
  "id":"1a444ebc42049184",
  "styleAttributes":{},
  "toFloating":false,
  "fromNode":"526990343e502ca8",
  "fromSide":"left",
  "toNode":"3abc27446545bf00",
  "toSide":"right"
},
{
  "id":"be00e17cbadfe709",
  "styleAttributes":{},
  "toFloating":false,
  "fromNode":"5895df04dec8097d",
  "fromSide":"left",
  "toNode":"995920819c602bf8",
  "toSide":"right"
}
],
"metadata":{
  "version":"1.0-1.0",
```

```
"frontmatter": {},  
"startNode": "8415e5237d58188d"  
}  
}
```