

Arista Access Switch ALARM_4644 - Critical Alarm Procedure

Node: Arista-Access-Chennai-TN-86 | **Vendor:** Arista | **Severity:** Critical | **Alarm Code:** ALARM_4644

Description

This Standard Operating Procedure (SOP) outlines the steps to diagnose and resolve the Critical Alarm ALARM_4644 on Arista Access Switch Node ID: Arista-Access-Chennai-TN-86.

Potential Root Causes

Cause	Probability
Hardware failure on Arista-Access-Chennai-TN-86	High
Incorrect configuration on Arista-Access-Chennai-TN-86	Medium
Software issue on Arista-Access-Chennai-TN-86	Low

Diagnostic Commands

```
show system internal switch 1 detail
show system internal switch 1 counters
show system internal switch 1 memory
show system internal switch 1 environment
show system internal switch 1 fans
show system internal switch 1 power
```

Resolution Steps

- Step 1: {'Step': '1. Check the switch logs for any errors related to the alarm', 'Action': 'show system internal switch 1 log'}
- Step 2: {'Step': '2. Verify the switch configuration', 'Action': 'show running-config'}
- Step 3: {'Step': '3. Check the switch hardware status', 'Action': 'show system internal switch 1 detail'}
- Step 4: {'Step': '4. Replace the faulty hardware component', 'Action': 'Replace the faulty hardware component with a known good one'}
- Step 5: {'Step': '5. Reboot the switch', 'Action': 'reload'}
- Step 6: {'Step': '6. Verify the switch is functioning correctly', 'Action': 'show system internal switch 1 detail'}

Post-Check Verification

```
show system internal switch 1 detail
show system internal switch 1 counters
show system internal switch 1 memory
show system internal switch 1 environment
show system internal switch 1 fans
show system internal switch 1 power
```