

Standard Operating Procedure for ALARM_8414 on Arista-Access-Chennai-TN-88

Node: Arista-Access-Chennai-TN-88 | **Vendor:** Arista | **Severity:** Warning | **Alarm Code:** ALARM_8414

Description

Alarm ALARM_8414 on Arista-Access-Chennai-TN-88 indicates a Warning condition. This procedure outlines steps to diagnose, resolve, and verify the issue.

Potential Root Causes

Cause	Probability
High CPU utilization	High
Insufficient memory	Medium
Misconfigured VLANs	Low

Diagnostic Commands

```
show system resources
show memory usage
show vlan summary
show interface status
show cpu utilization
```

Resolution Steps

- Step 1: {'Step': 1, 'Description': 'Check CPU utilization and memory usage', 'CLI_Commands': 'show system resources | show memory usage'}
- Step 2: {'Step': 2, 'Description': 'Verify VLAN configurations', 'CLI_Commands': 'show vlan summary | show interface status'}
- Step 3: {'Step': 3, 'Description': 'Adjust CPU and memory settings if necessary', 'CLI_Commands': 'set system resources cpu-limit | set system resources memory-limit '}
- Step 4: {'Step': 4, 'Description': 'Check for any misconfigured VLANs and adjust if necessary', 'CLI_Commands': 'configure terminal | vlan '}

Post-Check Verification

```
show system resources | show memory usage
```

```
show vlan summary | show interface status  
show cpu utilization
```