

Arista Access Switch Alarm SOP: ALARM_6540

Node: Arista-Access-Delhi-NCR-34 | **Vendor:** Arista | **Severity:** Critical | **Alarm Code:** ALARM_6540

Description

Resolving Critical Alarm on Arista Access Switch (Arista-Access-Delhi-NCR-34)

Potential Root Causes

Cause	Probability
High CPU utilization due to software bugs or misconfiguration	High
Interface flapping or misconfigured network settings	Medium
Power supply issues or hardware failure	Low

Diagnostic Commands

```
show system resource | include cpu
show interface detail | include status
show power consumption
```

Resolution Steps

- Step 1: {'Step': 'Restart the switch', 'Action': "execute command: 'reload' (confirm with 'yes')"}
Step 2: {'Step': 'Verify and adjust the switch configuration', 'Action': "use command: 'show running-config' to inspect the configuration, and then adjust as necessary"}
Step 3: {'Step': 'Swap or replace the power supply (if required)', 'Action': "execute command: 'show power supply' to identify the faulty power supply, then execute 'power supply swap' or 'power supply replace' as required"}
Step 4: {'Step': 'Verify the CPU utilization and adjust resource allocation if necessary', 'Action': "use command: 'show system resource | include cpu' to verify CPU utilization, then adjust resource allocation using 'show system resource | include cpu' as reference"}

Post-Check Verification

```
show alarm all
show system resource | include cpu
show interface detail | include status
```