

Standard Operating Procedure: Resolve Critical Alarm on Arista Access Switch (ALARM_8112)

Node: Arista-Access-Delhi-NCR-34 | **Vendor:** Arista | **Severity:** Critical | **Alarm Code:** ALARM_8112

Description

This SOP outlines the steps to resolve the critical alarm ALARM_8112 on Arista Access Switch (Node ID: Arista-Access-Delhi-NCR-34).

Potential Root Causes

Cause	Probability
Physical Layer Issues (e.g., cable problems, port errors)	High
Software or Firmware Issues (e.g., bugs, incompatibilities)	Medium
Misconfigured or Malfunctioning Network Interface Cards (NICs)	Low

Diagnostic Commands

```
show interface status
show interface details
show log | exclude ALARM_8112
show system resource usage
```

Resolution Steps

- Step 1: {'Step': '1. Check Physical Layer Issues', 'Action': 'Verify cable connections and check for any physical damage.', 'CLI_Command': 'show interface status'}
- Step 2: {'Step': '2. Check Software or Firmware Issues', 'Action': 'Verify software and firmware versions are up-to-date and compatible.', 'CLI_Command': 'show version'}
- Step 3: {'Step': '3. Check Misconfigured or Malfunctioning NICs', 'Action': 'Verify NIC configurations and check for any malfunctions.', 'CLI_Command': 'show interface details'}
- Step 4: {'Step': '4. Reset the Switch (if necessary)', 'Action': 'Reset the switch to its default configuration.', 'CLI_Command': 'reload'}

Post-Check Verification

```
show interface status
show log | exclude ALARM_8112
show system resource usage
```