

Standard Operating Procedure for Resolving ALARM_6134 on Arista Access Switch Kolkata WB 116

Node: Arista-Access-Kolkata-WB-116 | **Vendor:** Arista | **Severity:** Minor | **Alarm Code:** ALARM_6134

Description

This SOP outlines the steps to diagnose, resolve, and verify the fix for ALARM_6134, a minor alarm indicating a potential issue on the Arista Access Switch Kolkata WB 116.

Potential Root Causes

Cause	Probability
Physical Interface Issues	High
Software Configuration Errors	Medium
Hardware Failures	Low

Diagnostic Commands

```
show interface status
show interface details
show environment temperature
show system resources
```

Resolution Steps

- Step 1: {'Step': '1. Check Physical Interface Status', 'Action': "Run 'show interface status' command to verify interface status and look for any errors."}
- Step 2: {'Step': '2. Verify System Resources', 'Action': "Run 'show system resources' command to check for any resource utilization issues."}
- Step 3: {'Step': '3. Check Software Configuration', 'Action': "Verify software configuration and look for any configuration errors. Run 'show running-config' command to view the current configuration."}
- Step 4: {'Step': '4. Check for Hardware Failures', 'Action': "Run 'show environment temperature' command to check for any temperature-related issues. Also, check for any hardware failure alarms."}

Post-Check Verification

```
show interface status
show interface details
```

```
show system resources
show running-config
```