

Arista Access Switch - Alarm Handling SOP:

ALARM_2559

Node: Arista-Access-Kolkata-WB-120 | **Vendor:** Arista | **Severity:** Minor | **Alarm Code:** ALARM_2559

Description

This document outlines the Standard Operating Procedure for handling the ALARM_2559 alarm on Arista Access Switch Node ID: Arista-Access-Kolkata-WB-120. The alarm is triggered due to a minor issue.

Potential Root Causes

Cause	Probability
Physical Layer Issues	Medium
Switch Configuration Errors	Low
Hardware Malfunction	High

Diagnostic Commands

```
show interface status
show logging
show system internal error-disable
show version
```

Resolution Steps

- Step 1: {'Step': '1. Check the Physical Layer', 'Description': "Verify the integrity of all cables and connections. Use the command 'show interface status' to check for any issues.", 'Commands': ['show interface status']}
- Step 2: {'Step': '2. Check Switch Configuration', 'Description': "Verify switch configuration for any errors. Use the command 'show running-config' to check for any inconsistencies.", 'Commands': ['show running-config']}
- Step 3: {'Step': '3. Check for Hardware Issues', 'Description': "Verify the hardware for any malfunctions. Use the command 'show system internal error-disable' to check for any issues.", 'Commands': ['show system internal error-disable']}
- Step 4: {'Step': '4. Perform a System Restart', 'Description': "Restart the system to resolve any software-related issues. Use the command 'reload' to restart the system.", 'Commands': ['reload']}

Post-Check Verification

```
show interface status
show logging
show system internal error-disable
```