

Arista Access Switch SOP for Alarm ALARM_1768

Node: Arista-Access-Mumbai-MH-48 | **Vendor:** Arista | **Severity:** Major | **Alarm Code:** ALARM_1768

Description

This Standard Operating Procedure (SOP) outlines the steps to diagnose and resolve the ALARM_1768 (Major) on Arista-Access-Mumbai-MH-48, an Arista Access Switch.

Potential Root Causes

Cause	Probability
Switch Software Crash	High
Hardware Failure (e.g., fan, power supply)	Medium
Misconfigured or Malfunctioning Interface	Low

Diagnostic Commands

```
show system internal error
show interface status
show environment all
show system resources
```

Resolution Steps

- Step 1: {'Step': '1. Reload the switch to clear the current software state and restart the system.', 'Action': 'Reload the switch using the command: "no shutdown" and then "reload"')}
- Step 2: {'Step': '2. Inspect the switch logs for any error messages related to the alarm.', 'Action': 'Use the command: "show log" to view the switch logs.'}
- Step 3: {'Step': '3. Check for any hardware issues such as faulty fans or power supplies.', 'Action': 'Use the command: "show environment all" to view the switch\'s environmental status.'}
- Step 4: {'Step': '4. Verify the switch's interface configuration and ensure it is not misconfigured.', 'Action': 'Use the command: "show interface status" to view the switch\'s interface status.'}
- Step 5: {'Step': '5. If none of the above steps resolve the issue, contact the Arista support team for further assistance.', 'Action': 'Contact the Arista support team via phone or email.'}

Post-Check Verification

```
show system internal error
show interface status
```

```
show environment all  
show system resources
```