

Arista Access Switch SOP - Alarm Code

ALARM_6462

Node: Arista-Access-Mumbai-MH-48 | **Vendor:** Arista | **Severity:** Major | **Alarm Code:** ALARM_6462

Description

This Standard Operating Procedure outlines the steps to identify, diagnose, and resolve an issue on the Arista Access Switch Node ID: Arista-Access-Mumbai-MH-48, triggered by Alarm Code ALARM_6462, a Major severity alarm.

Potential Root Causes

Cause	Probability
Hardware Failure in the Switching Module	High
Software Bug in the Switching Module	Medium
Misconfigured Ports or Interfaces	Low

Diagnostic Commands

```
show system internal switch detail
show hardware switch detail
show version
show system internal software detail
```

Resolution Steps

- Step 1: {'Step': 'Check the Hardware Switch Detail', 'Action': 'Run the command "show hardware switch detail"', 'Expected_Output': 'Verify the switch module is functioning correctly'}
- Step 2: {'Step': 'Check the System Internal Software Detail', 'Action': 'Run the command "show system internal software detail"', 'Expected_Output': 'Verify the software version is up-to-date and not experiencing any bugs'}
- Step 3: {'Step': 'Verify Port Configurations', 'Action': 'Run the command "show interface "', 'Expected_Output': 'Verify the port configurations are correct and not misconfigured'}
- Step 4: {'Step': 'Replace the Switching Module (if hardware failure is confirmed)', 'Action': 'Replace the faulty switching module with a new one and follow the standard procedures for module replacement', 'Expected_Output': 'Verify the new module is functioning correctly'}

Post-Check Verification

```
show system internal switch detail
```

```
show hardware switch detail
show version
show system internal software detail
```