

Arista PE Bangalore KA 76 - Alarm 3828 SOP

Node: Arista-PE-Bangalore-KA-76 | **Vendor:** Arista | **Severity:** Warning | **Alarm Code:** ALARM_3828

Description

Alarm 3828 on Arista PE Bangalore KA 76 (Arista-PE-Bangalore-KA-76) is a Warning-level alarm indicating a potential issue with the Provider Edge Router.

Potential Root Causes

Cause	Probability
Link Down	Medium
Neighbor Down	Medium
Hardware Failure	Low

Diagnostic Commands

```
show interface | exclude down
show lldp neighbors
show ip bgp summary
show hardware
show version
```

Resolution Steps

- Step 1: {'Step': 'Verify Interface Status', 'Action': "Run 'show interface | exclude down' command to check for any interface errors"}
- Step 2: {'Step': 'Verify Neighbor Status', 'Action': "Run 'show lldp neighbors' command to check for any neighbor issues"}
- Step 3: {'Step': 'Verify BGP Status', 'Action': "Run 'show ip bgp summary' command to check for any BGP issues"}
- Step 4: {'Step': 'Verify Hardware Status', 'Action': "Run 'show hardware' command to check for any hardware issues"}
- Step 5: {'Step': 'Replace Hardware if Failed', 'Action': 'Replace hardware if it has failed, and verify the fix with the commands below'}
- Step 6: {'Step': 'Save Configuration', 'Action': "Save the configuration with 'copy running-config startup-config' command"}
- Step 7: {'Step': 'Reboot Router', 'Action': "Reboot the router with 'reload' command"}

Post-Check Verification

```
show interface | exclude down
show lldp neighbors
show ip bgp summary
show hardware
show version
```