

Arista-PE-Bangalore-KA-81 Provider Edge Router Alarm Resolution SOP

Node: Arista-PE-Bangalore-KA-81 | **Vendor:** Arista | **Severity:** Warning | **Alarm Code:** ALARM_8168

Description

ALARM_8168 Warning: Interface Down on Arista-PE-Bangalore-KA-81

Potential Root Causes

Cause	Probability
Physical Interface Failure	High
Cabling Issue	Medium
Software Configuration Error	Low

Diagnostic Commands

```
show interface Ethernet1/1 detail
show interface status
show log | include ALARM_8168
```

Resolution Steps

- Step 1: {'Step': '1. Check Physical Interface and Cabling', 'Action': 'Verify that the physical interface and cabling are secure and properly connected.'}
- Step 2: {'Step': '2. Check Interface Configuration', 'Action': '"Verify that the interface is configured properly by running the command 'show running-config interface Ethernet1/1'."}
- Step 3: {'Step': '3. Check for Software Configuration Errors', 'Action': '"Verify that there are no software configuration errors by checking the system log and running the command 'show log | include ALARM_8168'."}
- Step 4: {'Step': '4. Restart the Interface', 'Action': '"Restart the interface by running the command 'no shutdown' and 'shutdown' on the interface.'}
- Step 5: {'Step': '5. Verify the Interface', 'Action': '"Verify that the interface is up and running by running the command 'show interface Ethernet1/1 detail'."}

Post-Check Verification

```
show interface Ethernet1/1 detail
show log | include ALARM_8168
```