

Standard Operating Procedure: Troubleshooting Cisco-Access-Bangalore-KA-72 (ALARM_6588)

Node: Cisco-Access-Bangalore-KA-72 | **Vendor:** Cisco | **Severity:** Critical | **Alarm Code:** ALARM_6588

Description

This SOP outlines the steps to identify and resolve the ALARM_6588 on Cisco-Access-Bangalore-KA-72, a critical alarm indicating a potentially severe issue.

Potential Root Causes

Cause	Probability
High CPU Utilization	High
Misconfigured VLANs	Medium
Faulty Network Interface Card (NIC)	Low

Diagnostic Commands

```
show processes cpu
show interfaces status
show vlan brief
show logging
show tech-support
```

Resolution Steps

- Step 1: {'Step': '1. Check CPU Utilization', 'Action': "Run 'show processes cpu' to verify CPU utilization", 'CLI_Command': 'show processes cpu'}
- Step 2: {'Step': '2. Verify VLAN Configuration', 'Action': "Run 'show vlan brief' to ensure VLANs are correctly configured", 'CLI_Command': 'show vlan brief'}
- Step 3: {'Step': '3. Inspect NIC Status', 'Action': "Run 'show interfaces status' to verify NIC status", 'CLI_Command': 'show interfaces status'}
- Step 4: {'Step': '4. Clear System Logs', 'Action': "Run 'clear logging' to clear system logs and restart the logging process", 'CLI_Command': 'clear logging'}
- Step 5: {'Step': '5. Restart the Switch', 'Action': "Run 'shutdown' followed by 'no shutdown' to restart the switch", 'CLI_Command': 'shutdown; no shutdown'}

Post-Check Verification

```
show processes cpu
show interfaces status
show vlan brief
show logging
```