

SOP for Resolving Critical Alarm ALARM_7516 on Cisco Access Switch

Node: Cisco-Access-Chennai-TN-100 | **Vendor:** Cisco | **Severity:** Critical | **Alarm Code:** ALARM_7516

Description

Critical alarm ALARM_7516 on Cisco Access Switch indicates a high severity issue that requires immediate attention. This SOP outlines the steps to diagnose and resolve the issue.

Potential Root Causes

Cause	Probability
Power Supply Failure	High
Fan Failure	Medium
Hardware Failure (e.g., motherboard, CPU, memory)	Low

Diagnostic Commands

```
show power inline
show environment detail
show system resources
show tech-support
```

Resolution Steps

- Step 1: {'Step': '1. Identify the affected power supply and replace it if necessary', 'Command': 'show power inline'}
- Step 2: {'Step': '2. Check the fan status and replace the fan if necessary', 'Command': 'show environment detail'}
- Step 3: {'Step': '3. Run a diagnostic test on the affected hardware components', 'Command': 'diag test '}
- Step 4: {'Step': '4. Replace the affected hardware component if necessary', 'Command': 'no '}

Post-Check Verification

```
show power inline
show environment detail
show system resources
show tech-support
```