

Cisco-Access-Chennai-TN-108 SOP: ALARM_6462 - Warning

Node: Cisco-Access-Chennai-TN-108 | **Vendor:** Cisco | **Severity:** Warning | **Alarm Code:** ALARM_6462

Description

Alarm Code ALARM_6462 indicates a potential issue with the Cisco Access Switch (Node ID: Cisco-Access-Chennai-TN-108). This SOP outlines the steps to diagnose and resolve the issue.

Potential Root Causes

Cause	Probability
Incorrect configuration of VLAN settings	Medium
Interface mismatch or faulty connections	Low
Software or firmware issues	High

Diagnostic Commands

```
show vlan | include "VLAN\s+\d+"
show interface status | include "up/down"
show version | include "Software\s+\d+\.\d+"
debug switch 6462
```

Resolution Steps

- Step 1: {'Step': 'Check VLAN settings', 'Action': "Verify VLAN configuration using 'show vlan' command", 'CLI_Command': 'show vlan'}
- Step 2: {'Step': 'Check interface status', 'Action': "Verify interface status using 'show interface status' command", 'CLI_Command': 'show interface status'}
- Step 3: {'Step': 'Upgrade firmware/software', 'Action': 'Download and apply the latest firmware/software version', 'CLI_Command': 'boot system flash slot0:/cisco_ios-advipservicesk9-mz.SPA.163-1.0a.bin'}
- Step 4: {'Step': 'Restart the switch', 'Action': 'Restart the switch to apply configuration changes', 'CLI_Command': 'reload'}

Post-Check Verification

```
show vlan | include "VLAN\s+\d+"
show interface status | include "up/down"
```

```
show version | include "Software\s+\d+\\.d+"
```