

Cisco Access Switch Alarm Resolution SOP for ALARM_1920

Node: Cisco-Access-Delhi-NCR-16 | **Vendor:** Cisco | **Severity:** Major | **Alarm Code:** ALARM_1920

Description

This SOP outlines the steps to resolve the ALARM_1920 on Cisco Access Switch Node ID: Cisco-Access-Delhi-NCR-16. The alarm is triggered due to a Major issue.

Potential Root Causes

Cause	Probability
High CPU Utilization	High
Buffer Overflows	Medium
Misconfigured VLANs	Low

Diagnostic Commands

```
show processes cpu | exclude System
show interface switchport
show buffers
show vlan
debug platform software switch
```

Resolution Steps

- Step 1: {'Step': '1. Check CPU Utilization', 'Action': 'Run the command: show processes cpu | exclude System', 'CLI_Command': 'show processes cpu | exclude System'}
- Step 2: {'Step': '2. Check Buffer Overflows', 'Action': 'Run the command: show buffers', 'CLI_Command': 'show buffers'}
- Step 3: {'Step': '3. Check VLAN Configuration', 'Action': 'Run the command: show vlan', 'CLI_Command': 'show vlan'}
- Step 4: {'Step': '4. Clear Buffer Overflows', 'Action': 'Run the command: clear buffers', 'CLI_Command': 'clear buffers'}
- Step 5: {'Step': '5. Save Configuration', 'Action': 'Run the command: copy running-config startup-config', 'CLI_Command': 'copy running-config startup-config'}

Post-Check Verification

```
show processes cpu | exclude System
show interface switchport
show buffers
show vlan
show alarm history
```