

SOP: Resolving ALARM_3730 on Cisco-Access-Delhi-NCR-16

Node: Cisco-Access-Delhi-NCR-16 | **Vendor:** Cisco | **Severity:** Major | **Alarm Code:** ALARM_3730

Description

ALARM_3730 on Cisco-Access-Delhi-NCR-16 indicates a major issue with the access switch causing link flap or misconfiguration.

Potential Root Causes

Cause	Probability
Physical Layer Cable Issues	High
Incorrect Configuration	Medium
Hardware Failure	Low

Diagnostic Commands

```
show interface qiqabithernet 0/1/0
show interface status
show run | include interface qiqabithernet 0/1/0
show logging | include alarm_3730
```

Resolution Steps

- Step 1: {'Step': 1, 'Action': 'Check the physical connections and cables for any issues or damage', 'Command': 'show interface gigabitethernet 0/1/0'}
- Step 2: {'Step': 2, 'Action': 'Verify the configuration for the interface', 'Command': 'show run | include interface gigabitethernet 0/1/0'}
- Step 3: {'Step': 3, 'Action': 'Check for any hardware issues or failure', 'Command': 'show logging | include alarm_3730'}
- Step 4: {'Step': 4, 'Action': 'Reset the interface and re-configure it if necessary', 'Command': 'interface gigabitethernet 0/1/0\nno shutdown'}

Post-Check Verification

```
show interface qiqabithernet 0/1/0 | exclude up/down
show interface status | include qiqabithernet 0/1/0
show run | include interface gigabitethernet 0/1/0
```