

Cisco Access Switch Node SOP for Alarm Code ALARM_5546

Node: Cisco-Access-Delhi-NCR-18 | **Vendor:** Cisco | **Severity:** Minor | **Alarm Code:** ALARM_5546

Description

This SOP outlines the procedures to investigate, diagnose, and resolve the Cisco Access Switch Node (Node ID: Cisco-Access-Delhi-NCR-18) with Alarm Code ALARM_5546 of Severity Minor.

Potential Root Causes

Cause	Probability
Misconfigured Switch Port	High
Link Failure between Switches	Medium
Switch Hardware Failure	Low

Diagnostic Commands

```
show interface status
show interface brief
show ip interface brief
show ip cef
show spanning-tree detail
```

Resolution Steps

- Step 1: {'Step': 'Verify switch port configuration', 'Action': "Check switch port configuration using 'show interface' command."}
- Step 2: {'Step': 'Check link status between switches', 'Action': "Verify the link status between connected switches using 'show interface status' command."}
- Step 3: {'Step': 'Check switch hardware status', 'Action': "Check switch hardware status using 'show diag' command."}
- Step 4: {'Step': 'Reset switch port', 'Action': "Reset the switch port using 'no shutdown' command."}
- Step 5: {'Step': 'Replace faulty switch hardware', 'Action': 'Replace the faulty switch hardware with a new one.'}

Post-Check Verification

```
show interface status
```

```
show interface brief
show ip interface brief
show ip cef
show spanning-tree detail
```