

Troubleshooting SOP for ALARM_5857 on Cisco-Access-Delhi-NCR-20

Node: Cisco-Access-Delhi-NCR-20 | **Vendor:** Cisco | **Severity:** Minor | **Alarm Code:** ALARM_5857

Description

This SOP outlines the procedure to troubleshoot and resolve the ALARM_5857, a minor alarm on Cisco-Access-Delhi-NCR-20.

Potential Root Causes

Cause	Probability
High CPU usage due to excessive traffic	High
Misconfigured spanning tree protocol	Medium
Hardware failure on the access switch	Low

Diagnostic Commands

```
show processes cpu sorted
show spanning-tree detail
show logging | include ALARM_5857
show tech-support
```

Resolution Steps

Step 1: {'Step': '1. Check CPU usage and traffic', 'Action': 'Run show processes cpu sorted to identify high CPU usage processes. Then, check traffic on the access switch using show interface stats.', 'CLI': 'show processes cpu sorted; show interface stats'}

Step 2: {'Step': '2. Verify spanning tree configuration', 'Action': 'Run show spanning-tree detail to verify if the spanning tree protocol is configured correctly. Make necessary changes to resolve any issues.', 'CLI': 'show spanning-tree detail'}

Step 3: {'Step': '3. Check for hardware failure', 'Action': 'Run show tech-support to gather information about the access switch's hardware. Replace the access switch if necessary.', 'CLI': 'show tech-support'}

Step 4: {'Step': '4. Clear the alarm', 'Action': 'Run clear alarm ALARM_5857 to clear the alarm.', 'CLI': 'clear alarm ALARM_5857'}

Post-Check Verification

```
show alarm ALARM_5857
```

```
show processes cpu sorted  
show spanning-tree detail
```