

Standard Operating Procedure: Resolving ALARM_6086 on Cisco-Access-Mumbai-MH-38

Node: Cisco-Access-Mumbai-MH-38 | **Vendor:** Cisco | **Severity:** Warning | **Alarm Code:** ALARM_6086

Description

The ALARM_6086 is a warning alarm indicating a high system resource utilization on the Cisco-Access-Mumbai-MH-38 access switch. This SOP outlines the steps to diagnose and resolve the issue.

Potential Root Causes

Cause	Probability
High CPU utilization due to CPU-intensive processes	High
High memory utilization due to memory-intensive processes	Medium
Insufficient system resources (CPU, memory, or both)	Low

Diagnostic Commands

```
show processes cpu sorted | exclude snmp
show memory | include Total
show system resources
```

Resolution Steps

- Step 1: {'Step': '1. Verify CPU utilization', 'Action': "Run the command 'show processes cpu sorted | exclude snmp' to identify CPU-intensive processes. If CPU utilization is high, proceed to Step 2."}
- Step 2: {'Step': '2. Verify memory utilization', 'Action': "Run the command 'show memory | include Total' to identify memory-intensive processes. If memory utilization is high, proceed to Step 3."}
- Step 3: {'Step': '3. Check system resources', 'Action': "Run the command 'show system resources' to verify if the system has sufficient resources. If not, upgrade or replace the device as necessary."}
- Step 4: {'Step': '4. Kill CPU-intensive processes', 'Action': "Run the command 'kill ' to terminate CPU-intensive processes."}
- Step 5: {'Step': '5. Adjust system parameters', 'Action': "Run the command 'conf t' to access global configuration mode, then 'no system resource' to adjust system resource allocation."}

Post-Check Verification

```
show processes cpu sorted | exclude snmp
```

```
show memory | include Total  
show system resources
```