

Cisco Access Switch Alarm Resolution Procedure

Node: Cisco-Access-Mumbai-MH-40 | **Vendor:** Cisco | **Severity:** Warning | **Alarm Code:** ALARM_5120

Description

This SOP describes the steps to resolve the ALARM_5120 warning alarm on the Cisco-Access-Mumbai-MH-40 access switch.

Potential Root Causes

Cause	Probability
High CPU utilization on the switch due to excessive packet processing.	High
Hardware issues with the switch's CPU or memory.	Medium
Misconfigured or malfunctioning network interfaces.	Low

Diagnostic Commands

```
show processes cpu | include Packet
show memory | include free
show interface status | include errors
show tech-support
```

Resolution Steps

- Step 1: {'Step': 'Verify CPU utilization and check for any CPU-intensive processes.', 'Action': "Run the command 'show processes cpu | include Packet' and check for any processes consuming excessive CPU resources."}
- Step 2: {'Step': 'Check memory usage and free memory.', 'Action': "Run the command 'show memory | include free' and check if there is sufficient free memory available."}
- Step 3: {'Step': 'Verify interface status and check for any errors.', 'Action': "Run the command 'show interface status | include errors' and check for any interface errors."}
- Step 4: {'Step': 'Collect and analyze system logs.', 'Action': "Run the command 'show tech-support' and analyze the system logs for any errors or issues."}
- Step 5: {'Step': 'Reset or replace the switch if hardware issues are confirmed.', 'Action': 'Reset the switch if hardware issues are confirmed or replace it if necessary.'}
- Step 6: {'Step': 'Configure interfaces and check for any misconfigurations.', 'Action': 'Configure the interfaces correctly and check for any misconfigurations.'}

Post-Check Verification

```
show processes cpu | include Packet
show memory | include free
show interface status | include errors
show tech-support
```