

Standard Operating Procedure for Cisco Access Switch Alarm ALARM_5631

Node: Cisco-Access-Mumbai-MH-40 | **Vendor:** Cisco | **Severity:** Critical | **Alarm Code:** ALARM_5631

Description

Alarm ALARM_5631 indicates a critical issue on Cisco-Access-Mumbai-MH-40, indicating a potential hardware or software failure.

Potential Root Causes

Cause	Probability
Hardware failure on the switch or connected devices	High
Software bug or configuration error	Medium
Environmental factors such as power fluctuations or overheating	Low

Diagnostic Commands

```
show logging | include ALARM_5631
show tech-support
show version
show inventory
show environment
```

Resolution Steps

- Step 1: {'Step': '1. Restart the switch', 'Description': 'Run the command 'reload' to restart the switch and see if the alarm clears.', 'Commands': ['reload']}
- Step 2: {'Step': '2. Check for hardware issues', 'Description': 'Verify the hardware components are functioning properly and replace if necessary.', 'Commands': ['show inventory', 'show environment']}
- Step 3: {'Step': '3. Investigate software issues', 'Description': 'Run the command 'show tech-support' to gather detailed information about the software and configuration.', 'Commands': ['show tech-support']}
- Step 4: {'Step': '4. Review configuration and firmware', 'Description': 'Verify that the configuration and firmware are up-to-date and correct.', 'Commands': ['show running-config', 'show version']}
- Step 5: {'Step': '5. Replace the switch if necessary', 'Description': 'If the above steps do not resolve the issue, replace the switch with a new one.', 'Commands': []}

Post-Check Verification

```
show logging | include ALARM_5631  
show clock
```