

Standard Operating Procedure: Cisco Access Switch - ALARM_5025

Node: Cisco-Access-Mumbai-MH-52 | **Vendor:** Cisco | **Severity:** Major | **Alarm Code:** ALARM_5025

Description

This SOP outlines the steps to diagnose and resolve the Cisco Access Switch ALARM_5025, a major alarm indicating a critical hardware or software failure.

Potential Root Causes

Cause	Probability
Power Supply Failure	High
Fan Tray Failure	Medium
Software Crash	Low

Diagnostic Commands

```
show logging | include ALARM_5025
show tech-support
show environment
show power
```

Resolution Steps

Step 1: {'Step': '1. Check Power Supply Status', 'Action': "Run the command 'show power' to verify the power supply status. If the power supply is not functioning, replace it with a new one.", 'CLI_Command': 'show power'}

Step 2: {'Step': '2. Check Fan Tray Status', 'Action': "Run the command 'show environment' to verify the fan tray status. If the fan tray is not functioning, replace it with a new one.", 'CLI_Command': 'show environment'}

Step 3: {'Step': '3. Check System Logs', 'Action': "Run the command 'show logging | include ALARM_5025' to check the system logs for any error messages. If the error message indicates a software crash, restart the switch.", 'CLI_Command': 'show logging | include ALARM_5025'}

Post-Check Verification

```
show version
show inventory
show environment
```

show power