

Cisco-PE-Delhi-NCR-33: ALARM_5595 Major Alarm SOP

Node: Cisco-PE-Delhi-NCR-33 | **Vendor:** Cisco | **Severity:** Major | **Alarm Code:** ALARM_5595

Description

This SOP outlines the steps to diagnose and resolve a Major Alarm_5595 on Cisco-PE-Delhi-NCR-33, a Cisco Provider Edge Router.

Potential Root Causes

Cause	Probability
High CPU Utilization	High
Memory Leak	Medium
BGP Session Down	Low

Diagnostic Commands

```
show processes cpu
show mem
show ip bgp summary
show ip bgp neighbors detail
```

Resolution Steps

- Step 1: {'Step': '1. Check CPU Utilization', 'Action': "Run the 'show processes cpu' command to check CPU utilization. If CPU utilization is high, proceed to step 2.", 'CLI_Command': 'show processes cpu'}
- Step 2: {'Step': '2. Check Memory Utilization', 'Action': "Run the 'show mem' command to check memory utilization. If memory utilization is high, proceed to step 3.", 'CLI_Command': 'show mem'}
- Step 3: {'Step': '3. Restart BGP Process', 'Action': "Run the 'clear bgp *' command to restart the BGP process.", 'CLI_Command': 'clear bgp *'}
- Step 4: {'Step': '4. Verify BGP Session', 'Action': "Run the 'show ip bgp neighbors detail' command to verify the BGP session.", 'CLI_Command': 'show ip bgp neighbors detail'}

Post-Check Verification

```
show ip bgp summary
show ip bgp neighbors detail
show processes cpu
```

show mem