

# SOP: Troubleshooting ALARM\_4000 on Cisco-PE-Kolkata-WB-112

**Node:** Cisco-PE-Kolkata-WB-112 | **Vendor:** Cisco | **Severity:** Minor | **Alarm Code:** ALARM\_4000

## Description

Minor Alarm on Cisco-PE-Kolkata-WB-112 due to potential interface or routing protocol issues.

## Potential Root Causes

| Cause                            | Probability |
|----------------------------------|-------------|
| Interface configuration issues   | Medium      |
| Routing protocol neighbor issues | Medium      |
| Hardware failure on interface    | Low         |

## Diagnostic Commands

```
show ip int brief
show ip bgp summary
show ip bgp neighbors
```

## Resolution Steps

- Step 1: {'Step': 'Verify interface configuration', 'Action': "Check interface IP address, subnet mask, and enable status using the command 'show ip int brief'.", 'CLI\_Command': 'show ip int brief'}
- Step 2: {'Step': 'Verify routing protocol neighbor status', 'Action': "Check BGP neighbor status using the command 'show ip bgp neighbors'.", 'CLI\_Command': 'show ip bgp neighbors'}
- Step 3: {'Step': 'Check for interface hardware issues', 'Action': "Check interface hardware status using the command 'show diag'.", 'CLI\_Command': 'show diag'}
- Step 4: {'Step': 'Update interface configuration if necessary', 'Action': 'Update interface IP address or subnet mask as required.', 'CLI\_Command': 'interface GigabitEthernet0/0/0 | GigabitEthernet0/0/1'}
- Step 5: {'Step': 'Clear BGP neighbor session if necessary', 'Action': "Clear BGP neighbor session using the command 'clear ip bgp '.", 'CLI\_Command': 'clear ip bgp 10.10.10.1'}

## Post-Check Verification

```
show ip int brief
show ip bgp summary
show ip bgp neighbors
```