

Cisco PE Router SOP for ALARM_4732: Critical Alarm on Node Cisco-PE-Kolkata-WB-124

Node: Cisco-PE-Kolkata-WB-124 | **Vendor:** Cisco | **Severity:** Critical | **Alarm Code:** ALARM_4732

Description

This SOP outlines the steps to diagnose and resolve a Critical alarm ALARM_4732 on Provider Edge Router Cisco-PE-Kolkata-WB-124.

Potential Root Causes

Cause	Probability
Hardware Failure	High
Misconfigured BGP Session	Medium
Software Bug	Low

Diagnostic Commands

```
show ip bgp summary
show ip bgp neighbors
show log | include ALARM_4732
show version
show hardware
show diag
```

Resolution Steps

- Step 1: {'Step': '1', 'Action': 'Restart the BGP process and verify the session'}
- Step 2: {'Step': '2', 'Action': 'Check the BGP configuration and correct any misconfigurations'}
- Step 3: {'Step': '3', 'Action': 'Replace the faulty hardware component'}
- Step 4: {'Step': '4', 'Action': 'Upgrade the software to the latest version'}

Post-Check Verification

```
show ip bgp summary
show ip bgp neighbors
show log | include ALARM_4732
ping
```