

Ericsson Access Switch Node - ALARM_5023: Warning Severity Alarm SOP

Node: Ericsson-Access-Bangalore-KA-64 | **Vendor:** Ericsson | **Severity:** Warning | **Alarm Code:** ALARM_5023

Description

This SOP outlines the steps to diagnose and resolve a Warning severity Alarm (ALARM_5023) on the Ericsson Access Switch Node (Node ID: Ericsson-Access-Bangalore-KA-64).

Potential Root Causes

Cause	Probability
High CPU Utilization	High
Memory Issues	Medium
Interface Errors	Low

Diagnostic Commands

```
show cpu-usage
show memory-usage
show interface-status
show alarm-history
```

Resolution Steps

- Step 1: {'Step': '1. Check CPU Utilization', 'Description': 'If CPU utilization is high, consider upgrading the hardware or optimizing the configuration.', 'CLI_Commands': 'show cpu-usage | include average'}
- Step 2: {'Step': '2. Check Memory Issues', 'Description': 'If memory issues are detected, consider increasing the memory allocation or optimizing the configuration.', 'CLI_Commands': 'show memory-usage | include used'}
- Step 3: {'Step': '3. Check Interface Errors', 'Description': 'If interface errors are detected, consider restarting the interface or replacing the hardware.', 'CLI_Commands': 'show interface-status | include error'}
- Step 4: {'Step': '4. Clear Alarm', 'Description': 'Clear the alarm after resolving the issue.', 'CLI_Commands': 'clear alarm ALARM_5023'}

Post-Check Verification

```
show alarm-history
```

```
show cpu-usage  
show memory-usage  
show interface-status
```