

Ericsson Access Switch ALARM_3238 SOP

Node: Ericsson-Access-Delhi-NCR-28 | **Vendor:** Ericsson | **Severity:** Critical | **Alarm Code:** ALARM_3238

Description

ALARM_3238: Critical Alarm on Ericsson Access Switch (Node ID: Ericsson-Access-Delhi-NCR-28)

Potential Root Causes

Cause	Probability
High CPU Utilization	High
Interface Flapping	Medium
Software Crashes	Low

Diagnostic Commands

```
show cpu utilization
show interface status
show system crash dump
```

Resolution Steps

- Step 1: {'Step': 'Restart the affected interface', 'Action': 'interface shutdown, then interface no shutdown'}
- Step 2: {'Step': 'Update software to the latest version', 'Action': 'software version'}
- Step 3: {'Step': 'Verify CPU utilization', 'Action': 'show cpu utilization'}

Post-Check Verification

```
show interface status
show system crash dump
show cpu utilization
```