

Ericsson Access Switch Node Alarm SOP - ALARM_1870

Node: Ericsson-Access-Kolkata-WB-128 | **Vendor:** Ericsson | **Severity:** Major | **Alarm Code:** ALARM_1870

Description

This SOP outlines the steps to be taken when a Major alarm ALARM_1870 is raised on the Ericsson Access Switch Node Ericsson-Access-Kolkata-WB-128.

Potential Root Causes

Cause	Probability
Invalid or missing configuration for the Access Switch Node	High
Hardware failure in the Access Switch Node	Medium
Software issue with the Access Switch Node	Low

Diagnostic Commands

```
show system status
show node status
show alarm details ALARM_1870
show hardware status
show software version
```

Resolution Steps

- Step 1: {'Step': '1. Check the configuration for the Access Switch Node', 'Action': "Verify the configuration for the Access Switch Node using the command 'show system status' and check for any discrepancies."}
- Step 2: {'Step': '2. Check for hardware failures', 'Action': "Run the command 'show hardware status' to check for any hardware failures and perform necessary repairs."}
- Step 3: {'Step': '3. Check for software issues', 'Action': "Run the command 'show software version' to check for any software issues and perform necessary upgrades."}
- Step 4: {'Step': '4. Clear the alarm', 'Action': "Clear the alarm using the command 'clear alarm ALARM_1870' once the issue has been resolved."}

Post-Check Verification

```
show system status
```

```
show node status
show alarm details ALARM_1870
show hardware status
show software version
```