

Huawei Access Node Alarm Handling Procedure - ALARM_2698

Node: Huawei-Access-Delhi-NCR-12 | **Vendor:** Huawei | **Severity:** Critical | **Alarm Code:** ALARM_2698

Description

Procedure for resolving critical alarm ALARM_2698 on Huawei Access Switch Node ID: Huawei-Access-Delhi-NCR-12

Potential Root Causes

Cause	Probability
Hardware Failure	High
Software Misconfiguration	Medium
Environmental Factors (e.g. temperature, power supply)	Low

Diagnostic Commands

```
display alarm all
display fault all
show system internal fault
show system internal alarm
```

Resolution Steps

- Step 1: {'Step': '1. Power cycle the node', 'Action': 'power off the node, wait 30 seconds, and then power it back on'}
- Step 2: {'Step': '2. Check for hardware failure', 'Action': 'replace the faulty hardware component (if identified)'}
- Step 3: {'Step': '3. Verify software configuration', 'Action': 'check the configuration files for any errors or inconsistencies', 'CLI_Command': 'display current-configuration'}
- Step 4: {'Step': '4. Check environmental factors', 'Action': 'verify that the node is within the recommended temperature and power supply ranges'}
- Step 5: {'Step': '5. Clear alarms and faults', 'Action': 'clear the alarms and faults using the following CLI command: clear alarm all'}

Post-Check Verification

```
display alarm all  
display fault all  
show system internal fault  
show system internal alarm
```