

Huawei Access Switch Alarm SOP: ALARM_6700

Node: Huawei-Access-Delhi-NCR-12 | **Vendor:** Huawei | **Severity:** Minor | **Alarm Code:** ALARM_6700

Description

Huawei Access Switch Alarm ALARM_6700 of Severity Minor is triggered on Node ID Huawei-Access-Delhi-NCR-12.

Potential Root Causes

Cause	Probability
High CPU Usage on Switch	High
Incorrect Configuration	Medium
Hardware Failure	Low

Diagnostic Commands

```
display fault
display cpu usage
display interface brief
```

Resolution Steps

Step 1: {'Step': 'Check CPU Usage', 'Action': 'Run `display cpu usage` command to view CPU usage.', 'CLI_Command': 'display cpu usage'}

Step 2: {'Step': 'Verify Configuration', 'Action': 'Verify configuration using `display current-configuration` command.', 'CLI_Command': 'display current-configuration'}

Step 3: {'Step': 'Restart Switch', 'Action': 'Restart the switch using `reboot` command.', 'CLI_Command': 'reboot'}

Step 4: {'Step': 'Check Interfaces', 'Action': 'Verify interface status using `display interface brief` command.', 'CLI_Command': 'display interface brief'}

Post-Check Verification

```
display fault
display cpu usage
display interface brief
```