

Huawei Access Switch ALARM_9187 SOP

Node: Huawei-Access-Delhi-NCR-12 | **Vendor:** Huawei | **Severity:** Major | **Alarm Code:** ALARM_9187

Description

This SOP outlines the steps to diagnose and resolve the Huawei Access Switch ALARM_9187, which is a Major alarm indicating a critical issue with the node.

Potential Root Causes

Cause	Probability
Optical Layer Issue	High
Software Bug	Medium
Hardware Failure	Low

Diagnostic Commands

```
display faultman info
display fault alarm
ping
show interface brief
```

Resolution Steps

- Step 1: {'Step': '1. Check the alarm log for any obvious issues', 'Action': "Use the command 'display alarm log' to view the alarm log"}
- Step 2: {'Step': '2. Verify the optical link is stable', 'Action': "Use the command 'display optical link' to verify the optical link status"}
- Step 3: {'Step': '3. Check for software bugs', 'Action': "Use the command 'display version' to verify the software version and 'checkpatch' to check for software bugs"}
- Step 4: {'Step': '4. Check for hardware failures', 'Action': "Use the command 'display device info' to verify the hardware status and 'ping' to check for connectivity issues"}
- Step 5: {'Step': '5. Reset the node to default settings', 'Action': "Use the command 'reset system default' to reset the node to default settings"}

Post-Check Verification

```
verify alarm status
ping
```

```
show interface brief
```