

SOP for Resolving Huawei Access Switch Alarm

ALARM_3902 - Delhi-NCR-16

Node: Huawei-Access-Delhi-NCR-16 | **Vendor:** Huawei | **Severity:** Major | **Alarm Code:** ALARM_3902

Description

This SOP outlines the procedures for diagnosing and resolving the ALARM_3902 issue on Huawei Access Switch (Huawei-Access-Delhi-NCR-16).

Potential Root Causes

Cause	Probability
Inconsistent database or incomplete database synchronization	High
Corrupted or inconsistent configuration files	Medium
Hardware failure or faulty components	Low

Diagnostic Commands

```
display version
display db
display db sync status
display sysinfo
display error-interval all
```

Resolution Steps

- Step 1: {'Step': 'Backup the switch configuration', 'Description': 'Copy the current configuration to a remote server or local file system.', 'Command': 'copy running-config backup://config-backup'}
- Step 2: {'Step': 'Clear database inconsistencies', 'Description': 'Clear the database to remove any inconsistencies.', 'Command': 'clear db'}
- Step 3: {'Step': 'Verify database synchronization', 'Description': 'Verify that the database is synchronized across all nodes.', 'Command': 'display db sync status'}
- Step 4: {'Step': 'Check configuration files for corruption', 'Description': 'Verify that the configuration files are consistent and not corrupted.', 'Command': 'display config'}
- Step 5: {'Step': 'Replace faulty components (if necessary)', 'Description': 'Replace any faulty hardware components and reconfigure the switch.', 'Command': 'replace hw-component'}

Post-Check Verification

```
display version
display db
display db svnc status
display sysinfo
display error-interval all
```